

Mattel M5973

Mattel Hot Wheels Speed Racer Big Sounds Mach 6 Toy Car User Manual

1. INTRODUCTION

Thank you for purchasing the Mattel Hot Wheels Speed Racer Big Sounds Mach 6 toy car. This vehicle is designed to recreate the action-packed racing experience from the Speed Racer movie with its impressive size, scale, and movie-inspired racing sounds. Please read this manual carefully before use to ensure proper setup, operation, and maintenance.



Image: The Hot Wheels Speed Racer Big Sounds Mach 6 toy car, a large-scale replica of the iconic Mach 6 vehicle, shown from a dynamic angle.

2. SAFETY INFORMATION

- **Age Recommendation:** This toy is suitable for children aged 36 months (3 years) to 180 months (15 years).
- **Battery Safety:** Always follow battery installation instructions. Do not mix old and new batteries, or different types of batteries. Remove batteries if the toy will not be used for an extended period. Dispose of used batteries responsibly.
- **Choking Hazard:** This toy contains small parts (batteries) that could be a choking hazard for young children. Adult supervision is recommended.
- **Supervision:** Adult supervision is advised during play to ensure safe use.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Hot Wheels Speed Racer Big Sounds Mach 6 Car
- 2 x AA Batteries (pre-installed or included separately)

4. SETUP: BATTERY INSTALLATION

The Hot Wheels Speed Racer Big Sounds Mach 6 car requires 2 AA batteries for its sound features. Batteries may be pre-installed or included separately.

1. Locate the battery compartment on the underside of the vehicle.
2. Using a Phillips head screwdriver (not included), carefully unscrew the battery compartment cover.
3. Insert 2 new AA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw. Do not overtighten.

Note: If the toy does not function after battery installation, ensure batteries are inserted correctly and are fresh.

5. OPERATING INSTRUCTIONS

The Hot Wheels Speed Racer Big Sounds Mach 6 car is designed for push-and-play operation with integrated sound effects.

- **Push Operation:** Simply push the car along a flat surface to make it move.
- **Activating Sounds:** The car features movie-inspired racing sounds. These sounds are typically activated by pressing a button on the vehicle or by specific movements of the car. Refer to the packaging for exact sound activation methods if not immediately apparent.

6. MAINTENANCE

- **Cleaning:** Wipe the car with a clean, damp cloth. Do not immerse the toy in water or use harsh cleaning agents.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight when not in use.
- **Battery Replacement:** Replace batteries when sounds become faint or stop working.

7. TROUBLESHOOTING

- **No Sound:**
 - Check if the batteries are installed correctly with the correct polarity.
 - Replace old or depleted batteries with new AA batteries.
 - Ensure the sound activation button (if present) is being pressed firmly.
- **Car Not Moving Smoothly:**
 - Check wheels for any obstructions or debris.
 - Ensure the play surface is flat and clean.

8. SPECIFICATIONS

Feature	Detail
Brand	Mattel / Hot Wheels
Model Name	Mach 6
Model Number	M5973
Power Source	Battery Powered

Batteries Required	2 x AA (included)
Material Type	Plastic
Item Dimensions (L x W x H)	17.5 x 7.5 x 7 inches
Operation Mode	Push
Theme	Hot Wheels, Speed Racer
Minimum Age	36 Months

9. WARRANTY AND SUPPORT

This product is covered by a manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact Mattel customer support. For further assistance or inquiries, please visit the official Mattel website or contact their customer service department.

© 2023 Mattel. All rights reserved. Hot Wheels and associated trademarks are owned by Mattel.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question