

Sinbo SHB 3002

Sinbo SHB 3002 Immersion Blender User Manual

Model: SHB 3002

[Safety Instructions](#) [Product Overview](#) [Setup](#) [Operation](#) [Cleaning & Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. SAFETY INSTRUCTIONS

Please read all instructions carefully before using the Sinbo SHB 3002 Immersion Blender. Retain this manual for future reference.

- **Electrical Safety:** Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting. Do not immerse the motor unit, cord, or plug in water or other liquids. Always unplug the appliance from the power outlet before cleaning, assembling, or disassembling parts, and when not in use.
- **Blade Safety:** The blending blade is very sharp. Handle with extreme care to avoid injury. Never touch the blade while the appliance is plugged in.
- **Children and Supervision:** This appliance is not intended for use by children. Close supervision is necessary when any appliance is used near children.
- **Usage Environment:** Use the appliance on a stable, flat, dry surface. Do not use outdoors.
- **Overheating:** Do not operate the blender continuously for more than 1 minute. Allow it to cool down before resuming use.
- **Damaged Cord/Plug:** Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.
- **Attachments:** Only use attachments recommended or sold by the manufacturer.
- **Hot Liquids:** Exercise extreme caution when blending hot liquids to prevent splashing and scalding.

2. PRODUCT OVERVIEW

The Sinbo SHB 3002 Immersion Blender consists of the following main components:

1. **Motor Unit:** The main body containing the motor and control buttons.
2. **Blending Shaft:** The detachable shaft with a protective guard and sharp blending blade at the end.
3. **Power Cord:** For connecting the appliance to an electrical outlet.



Image 1: Sinbo SHB 3002 Immersion Blender. This image shows the compact design of the immersion blender, highlighting the motor unit and the blending shaft with its protective blade guard.

3. SETUP

Before first use, clean all parts that will come into contact with food as described in the "Cleaning and Maintenance" section.

1. **Assemble the Blending Shaft:** Align the blending shaft with the motor unit. Push and twist gently until it locks securely into place. Ensure it is firmly attached before use.
2. **Prepare Ingredients:** Cut larger food items into smaller pieces for easier blending. Place ingredients into a suitable container, such as a tall beaker or pot.
3. **Connect to Power:** Plug the power cord into a standard electrical outlet.

4. OPERATING INSTRUCTIONS

The Sinbo SHB 3002 Immersion Blender is designed for mixing, pureeing, and emulsifying various food items.

- **Blending Technique:**

1. Immerse the blending shaft into the ingredients before turning on the appliance. Ensure the blade guard is fully submerged to prevent splashing.
2. Press and hold the power button to start blending.
3. Move the blender up and down gently and in circular motions to ensure all ingredients are processed evenly.
4. Release the power button to stop the appliance.
5. Wait for the blade to stop completely before removing the blender from the ingredients.

- **Recommended Uses:** Ideal for making soups, sauces, smoothies, baby food, and purees directly in the pot or container.

- **Important Notes:**

- Do not operate the blender in an empty container.
- Avoid blending hard ingredients like ice cubes or coffee beans, as this can damage the blade and motor.

- For best results, ensure liquids are present when blending solid ingredients.

5. CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity and hygienic use of your immersion blender.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Detach Blending Shaft:** Twist and pull the blending shaft to detach it from the motor unit.
3. **Clean Blending Shaft:** Wash the blending shaft under running water with a mild detergent. Use a brush to carefully clean around the blade. The blending shaft is generally dishwasher-safe, but hand washing is recommended for optimal care.
4. **Clean Motor Unit:** Wipe the motor unit with a damp cloth. **Never immerse the motor unit in water or any other liquid.**
5. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing.
6. **Storage:** Store the assembled or disassembled blender in a dry place, away from direct sunlight and out of reach of children.

6. TROUBLESHOOTING

If you encounter issues with your Sinbo SHB 3002 Immersion Blender, refer to the following table:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in correctly. Power outlet is not working. Blending shaft not securely attached.	Ensure the plug is fully inserted into the outlet. Test the outlet with another appliance. Reattach the blending shaft until it locks.
Poor blending performance.	Too little liquid. Ingredients are too large or too hard. Overfilling the container.	Add more liquid to the mixture. Cut ingredients into smaller pieces. Avoid hard ingredients. Reduce the amount of ingredients in the container.
Motor stops during operation.	Overheating protection activated.	Unplug the blender and let it cool down for at least 15-20 minutes before resuming use.

If the problem persists after trying these solutions, please contact customer support.

7. SPECIFICATIONS

- **Model:** Sinbo SHB 3002
- **Power Source:** Electric Cord
- **Recommended Uses:** Mixing, Pureeing
- **ASIN:** B001AXLD8Y
- *Note: Specific wattage and voltage details are typically found on the product's rating label.*

8. WARRANTY AND SUPPORT

Sinbo products are manufactured with high-quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official Sinbo website. Keep your purchase receipt as proof of purchase.

For technical support, spare parts, or service inquiries, please contact Sinbo customer service through their official channels. Contact details can usually be found on the product packaging or the official Sinbo website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question