

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [WENKO](#) /

› [WENKO Power-Loc Sion Chrome Toilet Paper Holder Model 17815 Instruction Manual](#)

## WENKO 17815

# WENKO Power-Loc Sion Chrome Toilet Paper Holder Model 17815 Instruction Manual

Model: 17815

## PRODUCT OVERVIEW

The WENKO Power-Loc Sion Chrome Toilet Paper Holder is designed for easy, drill-free installation using the advanced Power-Loc adhesive system. This system ensures a strong, permanent hold on various surfaces without the need for screws or drilling. The holder features a protective lid and a sophisticated chrome finish, providing both functionality and aesthetic appeal to your bathroom.

- **Drill-Free Installation:** Utilizes the Power-Loc adhesive system for secure mounting without drilling.
- **Strong Hold:** Capable of bearing heavy loads on surfaces like tiles, natural stone, concrete, wood, and many plastics.
- **Protective Lid:** Features a cover to protect the toilet roll from dust.
- **Durable Materials:** Constructed from steel and Acrylonitrile-Butadiene-Styrene (ABS) for longevity.
- **Removable:** Can be removed without leaving residue and repositioned if needed.

## SETUP AND INSTALLATION

Follow these steps for proper installation of your WENKO Power-Loc Sion Toilet Paper Holder. Ensure the mounting surface is clean and dry before beginning.

1. **Prepare the Surface:** Clean the desired mounting surface thoroughly with a suitable cleaner to remove any dirt, grease, or soap residue. Ensure the surface is completely dry before proceeding.
2. **Apply Adhesive:** Carefully apply the Power-Loc adhesive to the back of the mounting elements. Ensure an even application.
3. **Attach Mounting Elements:** Press the mounting elements firmly onto the prepared wall surface at the desired location. Ensure the screws on the back of the mounting elements are correctly seated in their respective housings.
4. **Curing Time:** Allow the adhesive to cure for a minimum of **24 hours** before attaching the toilet paper holder or applying any load. This curing period is essential for achieving maximum adhesive strength.
5. **Mount the Holder:** After the curing time, align the toilet paper holder with the mounting elements and

secure it in place.



*Image: The WENKO Power-Loc Sion Chrome Toilet Paper Holder securely installed on a tiled bathroom wall, holding a roll of toilet paper.*

## OPERATING INSTRUCTIONS

Using your WENKO toilet paper holder is straightforward:

- 1. Loading a Toilet Roll:** Lift the protective lid. Simply hang a standard toilet paper roll onto the holder's arm.
- 2. Dispensing:** Pull the desired amount of toilet paper from the roll. The protective lid helps keep the roll clean.

## MAINTENANCE AND CARE

To ensure the longevity and appearance of your WENKO toilet paper holder, follow these care instructions:

- Cleaning:** Wipe the chrome surfaces regularly with a soft, damp cloth. For stubborn spots, use a mild, non-abrasive cleaner specifically designed for chrome finishes.
- Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, or strong chemical detergents, as these can damage the chrome finish and ABS components.

- **Drying:** After cleaning, dry the holder thoroughly with a soft, dry cloth to prevent water spots and maintain its shine.

## TROUBLESHOOTING

If you encounter any issues with your toilet paper holder, refer to the following common solutions:

Problem	Possible Cause	Solution
Holder does not stick securely.	Surface was not clean or dry; adhesive did not cure for 24 hours; surface is unsuitable.	Ensure the surface is thoroughly cleaned and dried. Allow the adhesive to cure for the full 24 hours without load. The Power-Loc system is designed for smooth, non-porous surfaces. If the surface is highly textured or porous, the adhesive may not bond effectively.
Toilet roll does not fit or rotate smoothly.	Roll is too large or improperly placed.	Ensure you are using a standard-sized toilet paper roll. Verify the roll is correctly hung on the holder's arm, allowing it to rotate freely.
Protective lid is loose or damaged.	Wear and tear or improper handling.	Inspect the lid's hinges or attachment points. If damaged, contact WENKO customer support for replacement parts or further assistance.

## SPECIFICATIONS

<b>Brand:</b>	WENKO
<b>Model Number:</b>	17815
<b>Material:</b>	Acrylonitrile Butadiene Styrene (ABS), Alloy Steel, Plastic
<b>Finish Type:</b>	Chrome
<b>Color:</b>	Chrome
<b>Installation Type:</b>	Adhesive (Power-Loc System)
<b>Product Dimensions:</b>	6.69 x 10.04 x 1.81 inches (17 x 25.5 x 4.6 cm)
<b>Item Weight:</b>	11.7 ounces (333 Grams)

## WARRANTY AND SUPPORT

For warranty information, replacement parts, or further technical assistance, please contact WENKO customer support directly. Refer to the packaging or the official WENKO website for the most current contact details.

**WENKO Official Website:** [www.wenko.com](http://www.wenko.com)

© 2024 WENKO. All rights reserved.