

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Jet](#) /
- › [JET GH-2280ZX 22" x 80" Geared Head Metal Lathe Instruction Manual](#)

Jet GH-2280ZX

JET GH-2280ZX 22" x 80" Geared Head Metal Lathe Instruction Manual

Model: GH-2280ZX | Brand: JET

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and setup of your JET GH-2280ZX 22" x 80" Geared Head Metal Lathe. Please read this manual thoroughly before operating the machine to ensure proper usage and to prevent injury or damage.

The JET ZX Series Large Spindle Bore Lathe is designed to deliver power, precision, efficiency, and reliability for metalworking applications. Key features include a one-piece cast iron base for vibration absorption, a universal gearbox, and safety enhancements like an e-stop on the carriage.



Figure 1: Full view of the JET GH-2280ZX Geared Head Metal Lathe.

2. SAFETY INSTRUCTIONS

Always prioritize safety when operating machinery. Failure to follow safety guidelines can result in serious injury or death. This section outlines general safety practices. Refer to the full safety manual (if provided separately) for comprehensive details.

- **Read the Manual:** Understand all instructions and warnings before operation.
- **Wear Personal Protective Equipment (PPE):** Always wear safety glasses, hearing protection, and appropriate clothing. Avoid loose clothing, jewelry, and long hair.
- **Work Area:** Keep the work area clean, well-lit, and free from obstructions.
- **Machine Condition:** Inspect the lathe for damage or loose parts before each use. Ensure all guards are in place.
- **Emergency Stop:** Familiarize yourself with the location and operation of the emergency stop button. The GH-2280ZX features an e-stop on the carriage for increased operator safety.
- **Power Disconnection:** Disconnect power before performing any maintenance, adjustments, or when changing accessories.
- **Secure Workpiece:** Always ensure the workpiece is securely clamped in the chuck or between centers.
- **Proper Tooling:** Use only sharp, correctly ground cutting tools suitable for the material being machined.

3. SETUP AND INSTALLATION

Proper setup is crucial for the performance and safety of your lathe. Due to the weight and complexity of this machine, professional installation is recommended.

3.1 Unpacking and Placement

The JET GH-2280ZX weighs approximately 6933 pounds. Ensure the installation location has a solid, level foundation capable of supporting this weight. Use appropriate lifting equipment for unpacking and positioning.

- Carefully remove all packaging materials.
- Inspect the machine for any shipping damage. Report any damage immediately to the carrier and supplier.
- Position the lathe in an area with sufficient space for operation and maintenance, ensuring adequate clearance around all moving parts.
- Level the machine using shims under the base as necessary.

3.2 Electrical Connection

This machine requires a 3-phase, 230/460V power supply. Electrical connections must be performed by a qualified electrician in accordance with all local and national electrical codes.

- Verify the voltage and phase of your power supply match the machine's requirements.
- Ensure proper grounding.
- Install appropriate circuit protection.

3.3 Component Installation

Install included accessories such as the 10" 3-Jaw Chuck, 12" 4-Jaw Chuck, Steady Rest, and Follow Rest as needed for your specific operations. Refer to the detailed diagrams in the full product manual for precise installation steps.



Figure 2: The JET GH-2280ZX lathe with various components and accessories installed.

4. OPERATING INSTRUCTIONS

Understanding the controls and functions of your lathe is essential for safe and effective operation.

4.1 Control Panel Overview

The lathe features centrally-located controls for ease of use. Familiarize yourself with the main power switch, emergency stop button, spindle speed selectors, and feed controls.



Figure 3: Close-up view of the main control panel with various dials and buttons.

4.2 Spindle Operation

The 3-1/8" bore spindle is supported by two tapered and one ball bearing. Use the spindle speed selectors to choose the appropriate RPM for your material and cutting tool. Always ensure the chuck or faceplate is securely mounted before starting the spindle.




Figure 4: View of the chuck and headstock area, showing the spindle and chuck guard.

4.3 Carriage and Tool Post

The carriage allows for longitudinal and cross-feeding operations. The GH-2280ZX features a five-position automatic carriage stop for increased productivity and precision. The tool post holds the cutting tools securely.




Figure 5: Detailed view of the carriage, tool post, and lead screw.

4.4 Threading Operations

The universal gearbox eliminates the need for manual gear changes, allowing for easy selection of inch, metric, diametral, and module pitch threads. Consult the threading chart on the machine for correct settings.

4.5 Coolant System

The fully-integrated coolant system includes a full-length splash guard and coolant return, contributing to a cleaner work environment and improved tool life. Ensure the coolant reservoir is filled with appropriate cutting fluid.



4.6 Tailstock

The tailstock is used to support long workpieces or to hold drilling and reaming tools. Ensure it is properly aligned and locked in position before use.




Figure 7: Detailed view of the tailstock assembly.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your JET GH-2280ZX lathe. Always disconnect power before performing any maintenance.

- **Cleaning:** After each use, clean chips and debris from the bed, carriage, and other surfaces. Use a brush or shop vacuum; never use compressed air to blow chips towards yourself or others.
- **Lubrication:** Regularly lubricate all moving parts, including the lead screw, feed rod, and gearbox components, according to the lubrication schedule provided in the comprehensive manual.
- **Inspection:** Periodically inspect belts, gears, and electrical connections for wear or damage. Replace worn components as necessary.
- **Coolant System:** Clean the coolant tank and filter regularly to prevent buildup and maintain coolant effectiveness.

6. TROUBLESHOOTING

This section provides general guidance for common issues. For complex problems, contact qualified service personnel.

Problem	Possible Cause	Solution
Machine does not start	No power, emergency stop engaged, circuit breaker tripped.	Check power supply, disengage e-stop, reset circuit breaker.
Excessive vibration	Unbalanced workpiece, loose mounting, worn bearings, improper cutting conditions.	Balance workpiece, tighten mounting bolts, inspect bearings, adjust cutting speed/feed.
Poor surface finish	Dull cutting tool, incorrect speed/feed, excessive tool overhang, machine chatter.	Sharpen/replace tool, adjust speed/feed, reduce tool overhang, check machine rigidity.

7. SPECIFICATIONS

Key technical specifications for the JET GH-2280ZX Geared Head Metal Lathe:

Specification	Value
Model Number	GH-2280ZX
Manufacturer	Jet
Spindle Bore	3-1/8 inches
Power Source	Corded Electric
Voltage	230 Volts (3-Phase)
Horsepower	10 HP
Item Weight	6933 pounds
Product Dimensions	136 x 45 x 69 inches
Material	Cast Iron
Included Components	Lathe, Steady Rest, Follow Rest, 10" 3-Jaw Chuck, 12" 4-Jaw Chuck, Tool Box (with tools)

8. WARRANTY INFORMATION

The JET GH-2280ZX Geared Head Metal Lathe is backed by a **2-Year Warranty**. This warranty covers defects in materials and workmanship under normal use. For specific terms, conditions, and claim procedures, please refer to the official JET warranty documentation or contact JET customer support.



Figure 8: JET Red Assurance 2-Year Warranty.

JET also performs a **30-Point Inspection** on its products to ensure quality and reliability.




Figure 9: JET Red Assurance 30 Point Inspection.


9. CUSTOMER SUPPORT


For technical assistance, parts, or service inquiries regarding your JET GH-2280ZX lathe, please contact JET customer support. You can typically find contact information on the official JET website or in the packaging materials.

Visit the official [JET Store](#) for more information and product resources.

Related Documents - GH-2280ZX


 J-CK350-4K, 350mm Non-Ferrous High Speed Manual Cold Saw Product Images Short Description	JET J-CK350-4K 350mm Non-Ferrous High Speed Manual Cold Saw - Technical Specifications Detailed technical specifications for the JET J-CK350-4K 350mm Non-Ferrous High Speed Manual Cold Saw, including model number, motor details, cutting capacities, warranty, and weight.
--	--

 JET Operating Instructions and Parts Manual Shear, Brake and Roll Series SBR-30N and SBR-40N	JET SBR-30N & SBR-40N Shear, Brake, and Roll Operating Instructions and Parts Manual Comprehensive operating instructions and parts manual for JET SBR-30N and SBR-40N Shear, Brake, and Roll machines. Covers safety, setup, operation, maintenance, and parts lists.
 JET Operating Instructions and Parts Manual Benchtop Oscillating Spindle Sander Model JBOS-5	JET JBOS-5 Benchtop Oscillating Spindle Sander: Operating Instructions and Parts Manual This manual provides operating instructions, safety precautions, specifications, and a parts list for the JET JBOS-5 Benchtop Oscillating Spindle Sander. It covers setup, maintenance, warranty, and troubleshooting for woodworking professionals.
 JET JTM4VSE METALWORKING MILL 50000110T 400/50/3 PARTS LIST ERSATZTEILLISTE LISTE DE PIÉCES	JET JTM4VSE Metalworking Mill Parts List This document provides a comprehensive parts list and breakdown for the JET JTM4VSE Metalworking Mill, model 50000110T, operating at 400V, 50Hz. It details components for various assemblies including the Head Assembly, Base Assembly, Lead Screw Assembly, Lubrication System, Coolant Pump, Electrical Box, Operation Panel, Safety Shield, and Digital Read Out. Includes part numbers, descriptions, sizes, and quantities for each component.
 JET JML-1014 WOODWORKING LATHE 708351M 230/50/1 PARTS LIST ERSATZTEILLISTE LISTE DE PIÉCES	JET JML-1014 Woodworking Lathe Parts List and Diagram Comprehensive parts list and assembly diagram for the JET JML-1014 Woodworking Lathe (Model 708351M, 230/50/1). Includes part numbers, descriptions, sizes, and quantities for all components.
 JET Operating Instructions and Parts Manual E-1340VS & E-1440VS Lathe Series E-1340VS & E-1440VS	JET E-1340VS & E-1440VS Lathe: Operating Instructions and Parts Manual This document provides comprehensive operating instructions, safety precautions, maintenance procedures, and parts lists for the JET E-1340VS and E-1440VS metalworking lathes. It covers installation, operation, servicing, and replacement parts.




[\[pdf\]](#) User Manual Instructions Parts List Warranty Accessories Diagram

Microsoft Word M 321910 ZX Lathes Instruction Manual Rev I tgauger Jet 321568 GH 2280ZX Large Spindle Bore Lathe W Acu Rite 200S Taper Attachment Collet Closer B0230715 GLOBALindustrial Operation and Maintenance Instructions globalindustrial site images JET Manuals Operating ||| This .pdf document is bookmarked Operation and Maintenance Instructions ZX-Series Large Bore Lathes Models GH-1440ZX GH-1640ZX/1660ZX GH-1860ZX/1880ZX **GH-2280ZX** Model GH-1440ZX shown * For ZX-Series Lathes Parts List Electrical Diagrams, see document M-321910-1 JET 427 New Sanford Road LaVergne... lang:en **score:46** filesize: 4.75 M page_count: 92 document date: 2015-01-14




[\[pdf\]](#) Specifications Warranty

JET Tools 321881 GH 2280ZX With Newall DP700 DRO Taper Attachment JET® Lathe w Features and Specifications globalindustrial site images Manuals ||| **GH-2280ZX WITH NEWALL DP700 DRO WITH TAPER ATTACHMENT 321881** The ZX-Series Large Spindle Bore Lathe provides power, precision, efficiency and reliability to your metal shop. A one piece cast iron base absorbs vibrations during operation to allow heavier cuts and ensure accuracy, while the Universal ... lang:en **score:43** filesize: 147.47 K page_count: 6 document date: 0000-00-00



[\[pdf\]](#) Specifications Warranty

JET Tools 321880 GH 2280ZX With Newall DP700 DRO Lathe 2 Axis with B231096 GLOBALindustrial Features and Specifications globalindustrial site images Manuals ||| **GH-2280ZX WITH NEWALL DP700 DRO 321880** The ZX-Series Large Spindle Bore Lathe provides power, precision, efficiency and reliability to your metal shop. A one piece cast iron base absorbs vibrations during operation to allow heavier cuts and ensure accuracy, while the Universal Gearbox eliminates the... lang:en **score:42** filesize: 147.29 K page_count: 6 document date: 0000-00-00



[pdf] Specifications Warranty

JET Tools 321496 GH 2280ZX With Collet Closer Jet Large Spindle Bore Lathe W 10 HP B0230684
GLOBALindustrial Features and Specifications globalindustrial site images Manuals |||

GH-2280ZX WITH COLLET CLOSER 321496 The ZX-Series Large Spindle Bore Lathe provides power, precision, efficiency and reliability to your metal shop. A one piece cast iron base absorbs vibrations during operation to allow heavier cuts and ensure accuracy, while the Universal Gearbox eliminates the ne...

lang:en score:42 filesize: 147.25 K page_count: 6 document date: 0000-00-00




[pdf] User Manual Instructions Parts List Diagram

GH2280ZX T MANUAL Instructions EN cgental ZX Series Large Bore Lathes eclated view gh 2280zx t en
2 promac fr 2019 05 |||

This .pdf document is bookmarked Parts List and Electrical Diagrams ZX-Series Large Bore Lathes Models GH-1440ZX GH-1640ZX/1660ZX GH-1860ZX/1880ZX **GH-2280ZX** * For ZX-Series Lathes Operating Instructions, see document M-321910 JET 427 New Sanford Road LaVergne, Tennessee 37086 Ph.: 800-274-6848 www....

lang:i-klngon score:42 filesize: 4.49 M page_count: 65 document date: 2018-05-09




[pdf] Specifications Warranty

JET Tools 321980 GH 2280ZX 3 1 8 Spindle Bore Geared Head Lathe Jet Large 10 HP B0230959
GLOBALindustrial Features and Specifications globalindustrial site images Manuals |||

GH-2280ZX, 3-1/8 SPINDLE BORE GEARED HEAD LATHE 321980 The ZX-Series Large Spindle Bore Lathe provides power, precision, efficiency and reliability to your metal shop. A one piece cast iron base absorbs vibrations during operation to allow heavier cuts and ensure accuracy, while the Universal Gearb...


lang:en score:41 filesize: 156.51 K page_count: 6 document date: 2015-12-07



[\[pdf\]](#) Specifications Warranty

JET Tools 321579 GH 2280ZX With Newall DP700 DRO Taper Attachment and Collet Closer Jet W TAK COLLET CLSR B503405 GLOBALindustrial Features Specifications globalindustrial site images Manuals |||


GH-2280ZX WITH NEWALL DP700 DRO WITH TAPER ATTACHMENT AND COLLET CLOSER 321579 The ZX-Series Large Spindle Bore Lathe provides power, precision, efficiency and reliability to your metal shop. A one piece cast iron base absorbs vibrations during operation to allow heavier cuts and ensure accuracy, wh...
lang:en score:41 filesize: 147.66 K page_count: 6 document date: 0000-00-00



[\[pdf\]](#) Specifications Warranty

JET Tools 321575 GH 2280ZX With Taper Attachment and Collet Closer Jet Large Spindle Bore Lathe W 10 HP B0230765 GLOBALindustrial Features Specifications globalindustrial site images Manuals |||

GH-2280ZX WITH TAPER ATTACHMENT AND COLLET CLOSER 321575 The ZX-Series Large Spindle Bore Lathe provides power, precision, efficiency and reliability to your metal shop. A one piece cast iron base absorbs vibrations during operation to allow heavier cuts and ensure accuracy, while the Universal Gear...
lang:en score:41 filesize: 148.19 K page_count: 6 document date: 2015-12-04




[\[pdf\]](#) Specifications Warranty

JET Tools 321565 GH 2280ZX With Taper Attachment Jet Large Spindle Bore Lathe W 7 1 2 HP B0230682 GLOBALindustrial Features and Specifications globalindustrial site images Manuals |||


GH-2280ZX WITH TAPER ATTACHMENT 321565 The ZX-Series Large Spindle Bore Lathe provides power, precision, efficiency and reliability to your metal shop. A one piece cast iron base absorbs vibrations during operation to allow heavier cuts and ensure accuracy, while the Universal Gearbox eliminates the...
lang:en score:41 filesize: 148.02 K page_count: 6 document date: 2015-12-03




[pdf] User Manual Instructions Parts List Warranty Accessories Diagram Catalog
Microsoft Word M 321910 ZX Lathes Instruction Manual Rev I tgauger 321557 Operation and
Maintenance Instructions jetn321961 manual jetn322486 globalindustrial site images JET Manuals
Operating tylertool on demandware static Sites cpo master catalog default dw85a38f80 product media jet
documents dwa6a17e52
This .pdf document is bookmarked Operation and Maintenance Instructions ZX-Series
Large Bore Lathes Models GH-1440ZX GH-1640ZX/1660ZX GH-1860ZX/1880ZX
GH-2280ZX Model GH-1440ZX shown * For ZX-Series Lathes Parts List Electrical
Diagrams, see document M-321910-1 JET 427 New Sanford Road LaVergne...
lang:en score:40 filesize: 4.75 M page_count: 92 document date: 2015-01-14



[pdf] Specifications Warranty
JET Tools 321879 GH 2280ZX With ACU RITE 200S DRO Jet Large Spindle Bore Lathe W Acu Rite 7 1
2 HP Features and Specifications globalindustrial site images Manuals |||
GH-2280ZX WITH ACU-RITE 200S DRO 321879 The ZX-Series Large Spindle Bore
Lathe provides power, precision, efficiency and reliability to your metal shop. A one
piece cast iron base absorbs vibrations during operation to allow heavier cuts and
ensure accuracy, while the Universal Gearbox eliminates th...
lang:en score:40 filesize: 147.3 K page_count: 6 document date: 0000-00-00



[pdf] Specifications Warranty
JET Tools 321615 GH 2280ZX With ACU RITE 300S DRO Taper Attachment and Collet Closer Jet Large
Spindle Bore Lathe W Acu Rite B0230639 GLOBALindustrial Features Specifications globalindustrial site
images Manuals |||
**GH-2280ZX WITH ACU-RITE 300S DRO WITH TAPER ATTACHMENT AND
COLLET CLOSER 321615** The ZX-Series Large Spindle Bore Lathe provides power,
precision, efficiency and reliability to your metal shop. A one piece cast iron base
absorbs vibrations during operation to allow heavier cuts and ensure accuracy, w...
lang:en score:40 filesize: 148.41 K page_count: 6 document date: 2015-12-03




[\[pdf\]](#) Specifications Warranty

JET Tools 321613 GH 2280ZX With ACU RITE 300S DRO Collet Closer Jet Large Spindle Bore Lathe W Acu Rite 10 HP B0230787 GLOBALindustrial Features and Specifications globalindustrial site images Manuals |||

GH-2280ZX WITH ACU-RITE 300S DRO WITH COLLET CLOSER 321613 The ZX-Series Large Spindle Bore Lathe provides power, precision, efficiency and reliability to your metal shop. A one piece cast iron base absorbs vibrations during operation to allow heavier cuts and ensure accuracy, while the Universal Ge...

lang:en **score:40** filesize: 148.2 K page_count: 6 document date: 2015-12-04




[\[pdf\]](#) Specifications Warranty

JET Tools 321612 GH 2280ZX With ACU RITE 300S DRO Taper Attachment Jet Large Spindle Bore Lathe W Acu Rite 10 HP B0230786 GLOBALindustrial Features and Specifications globalindustrial site images Manuals |||

GH-2280ZX WITH ACU-RITE 300S DRO WITH TAPER ATTACHMENT 321612 The ZX-Series Large Spindle Bore Lathe provides power, precision, efficiency and reliability to your metal shop. A one piece cast iron base absorbs vibrations during operation to allow heavier cuts and ensure accuracy, while the Universal...


lang:en **score:40** filesize: 148.21 K page_count: 6 document date: 2015-12-04



[pdf] Specifications Warranty

JET Tools 321567 GH 2280ZX With ACU RITE 200S DRO Taper Attachment Jet Large Spindle Bore Lathe W Acu Rite 10 HP B0230714 GLOBALIndustrial Features and Specifications globalindustrial site images Manuals |||

GH-2280ZX WITH ACU-RITE 200S DRO WITH TAPER ATTACHMENT 321567 The ZX-Series Large Spindle Bore Lathe provides power, precision, efficiency and reliability to your metal shop. A one piece cast iron base absorbs vibrations during operation to allow heavier cuts and ensure accuracy, while the Universal...
lang:en score:40 filesize: 162.95 K page_count: 6 document date: 2015-12-03



[pdf] Specifications Warranty

JET Tools 321568 GH 2280ZX With ACU RITE 200S DRO Taper Attachment and Collet Closer Jet Large Spindle Bore Lathe W Acu Rite B0230715 GLOBALIndustrial Features Specifications globalindustrial site images Manuals |||


GH-2280ZX WITH ACU-RITE 200S DRO WITH TAPER ATTACHMENT AND COLLET CLOSER 321568 The ZX-Series Large Spindle Bore Lathe provides power, precision, efficiency and reliability to your metal shop. A one piece cast iron base absorbs vibrations during operation to allow heavier cuts and ensure accuracy, w...
lang:en score:40 filesize: 163.14 K page_count: 6 document date: 2015-12-03



[pdf] User Manual Instructions Declaration of Conformity

Manual E D F PROMAC GH 2280ZX 202003 Update cgental manual e d f promac gh 2280zx updatepromac fr 2019 05 update |||

GH-2260ZX GH-2280ZX Original: GB Operating Instructions Translations: D Betriebsanleitung F Manuel Utilisateur METAL LATHES Schweiz / Suisse JPW Tool AG Ackerstrasse 45, CH-8610 Uster, Switzerland www.promac.ch France TOOL FRANCE SARL 9 Rue des Pyrénées, 91090 LISSES, France www.promac.fr M ...
lang:en score:39 filesize: 4.57 M page_count: 8 document date: 2020-06-23




[\[pdf\]](#) Specifications Warranty

JET Tools 321566 GH 2280ZX With ACU RITE 200S DRO Collet Closer Jet Large Spindle Bore Lathe W Acu Rite 7 1 2 HP B0230688 GLOBALIndustrial Features and Specifications globalindustrial site images Manuals |||

GH-2280ZX WITH ACU-RITE 200S DRO WITH COLLET CLOSER 321566 The ZX-Series Large Spindle Bore Lathe provides power, precision, efficiency and reliability to your metal shop. A one piece cast iron base absorbs vibrations during operation to allow heavier cuts and ensure accuracy, while the Universal Ge...

lang:en score:39 filesize: 147.44 K page_count: 6 document date: 0000-00-00



[\[pdf\]](#) User Manual Instructions Parts List Warranty Accessories Diagram

Microsoft Word M 321910 ZX Lathes Instruction Manual Rev I tgauger Jet 321495 GH 1640ZX Large Spindle Bore Lathe W Acu Rite 200S DRO Collet Closer 7 1 2 HP Operation and Maintenance Instructions globalindustrial site images JET Manuals Operating |||

This .pdf document is bookmarked Operation and Maintenance Instructions ZX-Series Large Bore Lathes Models GH-1440ZX GH-1640ZX/1660ZX GH-1860ZX/1880ZX **GH-2280ZX** Model GH-1440ZX shown * For ZX-Series Lathes Parts List Electrical Diagrams, see document M-321910-1 JET 427 New Sanford Road LaVergne...

lang:en score:39 filesize: 4.75 M page_count: 92 document date: 2015-01-14



[\[pdf\]](#) User Manual Instructions Parts List Warranty Accessories Diagram

Microsoft Word M 321910 ZX Lathes Instruction Manual Rev I tgauger Jet 321455 GH 1660ZX Large Spindle Bore Lathe W Acu Rite 200S DRO 7 1 2 HP B0230977 GLOBALIndustrial Operation and Maintenance Instructions globalindustrial site images JET Manuals Operating |||

This .pdf document is bookmarked Operation and Maintenance Instructions ZX-Series Large Bore Lathes Models GH-1440ZX GH-1640ZX/1660ZX GH-1860ZX/1880ZX **GH-2280ZX** Model GH-1440ZX shown * For ZX-Series Lathes Parts List Electrical Diagrams, see document M-321910-1 JET 427 New Sanford Road LaVergne...

lang:en score:38 filesize: 4.75 M page_count: 92 document date: 2015-01-14



[\[pdf\]](#) User Manual Owner's Manual Instructions Parts List Declaration of Conformity Warranty Diagram Label

Microsoft Word M 321910 ZX Lathes Instruction Manual Rev J2 doc tgauger man EN content jettools assets manuals

This .pdf document is bookmarked Operation and Maintenance Instructions ZX-Series Large Bore Lathes Models GH-1440ZX GH-1640ZX/1660ZX GH-1860ZX/1880ZX **GH-2280ZX** Model GH-1440ZX shown * For ZX-Series Lathes Parts List Electrical Diagrams, see document M-321910-1 JET 427 New Sanford Road LaVergne,...

lang:en score:37 filesize: 2.81 M page_count: 94 document date: 2018-08-17



[\[pdf\]](#) User Manual Instructions Declaration of Conformity Warranty Catalog


Microsoft Word M 321910 ZX Lathes Instruction Manual Rev G doc tgauger jetn321544 manual

jetn321504 m 321980 tylertool on demandware static Sites cpo master catalog default dw34af0167

product media jet documents dw9301ee85 content jettools manuals

This Manual is Bookmarked Operating Instructions ZX Series Lathes Models GH-1440ZX/1460ZX GH-1640ZX/1660ZX GH-1840ZX/1860ZX/1880ZX **GH-2280ZX** WMH TOOL GROUP 2420 Vantage Drive Elgin, Illinois 60123 Ph.: 800-274-6848 www.wmhtoolgroup.com Part No. M-321910 Revision G 11/05 Copyright WMH Tool Group ...

lang:en score:36 filesize: 2.13 M page_count: 20 document date: 2006-04-27



[\[pdf\]](#) User Manual Owner's Manual Instructions Parts List Declaration of Conformity Warranty Diagram Label

Microsoft Word M 321910 ZX Lathes Instruction Manual Rev J2 doc tgauger Operation and Maintenance Instructions Series Elite Metal Tools 4 3 0 Warranty service JET warrants every product it sells against manufacturers defects If one of our tools needs or repair please

256f1b0c9c7ddb06bd0bad9f026818f3f9510322 elitemetaltools sites default files data manuals jpw |||

This .pdf document is bookmarked Operation and Maintenance Instructions ZX-Series Large Bore Lathes Models GH-1440ZX GH-1640ZX/1660ZX GH-1860ZX/1880ZX **GH-2280ZX** Model GH-1440ZX shown * For ZX-Series Lathes Parts List Electrical Diagrams, see document M-321910-1 JET 427 New Sanford Road LaVergne,...

lang:en score:36 filesize: 1.4 M page_count: 28 document date: 2018-08-13




[\[pdf\]](#) User Manual Instructions Warranty

Microsoft Word M 321910 ZX Lathes Instruction Manual Rev H tgauger 123490 123492 northerntool images manuals

Operating Instructions ZX Series Lathes Models GH-1440ZX/1440ZX-EVS/1460ZX GH-1640ZX/1660ZX GH-1840ZX/1860ZX/1880ZX **GH-2280ZX** WMH TOOL GROUP, Inc. 427 New Sanford Road LaVergne, TN 37086 Ph.: 800-274-6848 www.jettools.com Part No. M-321910 Revision H 05/09 Copyright 2009 WMH Tool Group, Inc. Wa...


lang:en score:36 filesize: 2.53 M page_count: 84 document date: 2013-10-07



[\[pdf\]](#) User Manual Instructions Parts List Declaration of Conformity Warranty Accessories Diagram

Microsoft Word M 321910 ZX Lathes Instruction Manual Rev J1 doc tgauger Series Large Bore man EN
elitemetaltools sites default files product data manuals |||

This .pdf document is bookmarked Operation and Maintenance Instructions ZX-Series Large Bore Lathes Models GH-1440ZX GH-1640ZX/1660ZX GH-1860ZX/1880ZX **GH-2280ZX** Model GH-1440ZX shown * For ZX-Series Lathes Parts List Electrical Diagrams, see document M-321910-1 JET 427 New Sanford Road LaVerne...
lang:en score:35 filesize: 2.79 M page_count: 94 document date: 2017-11-09




[\[pdf\]](#) Specifications Warranty

JET Tools 321573 GH 1660ZX With Collet Closer JET® Lathe w Features and Specifications
globalindustrial site images Manuals |||

GH-1660ZX WITH COLLET CLOSER 321573 The ZX-Series Large Spindle Bore Lathe provides power, precision ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en score:33 filesize: 147.53 K page_count: 6 document date: 0000-00-00




[\[pdf\]](#) Specifications Warranty

JET Tools 321439 GH 1640ZX With Collet Closer Jet Lathe with B230832 GLOBALindustrial Features and Specifications globalindustrial site images Manuals |||

GH-1640ZX WITH COLLET CLOSER 321439 The ZX-Series Large Spindle Bore Lathe provides power, precision ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en score:33 filesize: 162.95 K page_count: 6 document date: 2015-12-04




[\[pdf\]](#) Specifications Warranty

JET Tools 321467 GH 1440ZX With Taper Attachment Jet Large Spindle Bore Lathe W 7 1 2 HP

Features and Specifications globalindustrial site images Manuals |||

GH-1440ZX WITH TAPER ATTACHMENT 321467 The ZX-Series Large Spindle Bore Lathe provides power, precis ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en score:32 filesize: 161.5 K page_count: 6 document date: 2015-12-04




[\[pdf\]](#) Specifications Warranty

JET Tools 321569 GH 1440ZX With ACU RITE 200S DRO Taper Attachment and Collet Closer JET®

Lathe w Features Specifications globalindustrial site images Manuals |||

GH-1440ZX WITH ACU-RITE 200S DRO WITH TAPER ATTACHMENT AND COLLET CLOSER 321569 The ZX-Series Large ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX**GH-2280ZX GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en score:32 filesize: 130.13 K page_count: 6 document date: 0000-00-00




[\[pdf\]](#) Specifications Warranty

JET Tools 321147 GH 1640ZX With Newall DP700 DRO Taper Attachment and Collet Closer JET® Lathe

w DP700L Features Specifications globalindustrial site images Manuals |||

GH-1640ZX WITH NEWALL DP700 DRO WITH TAPER ATTACHMENT AND COLLET CLOSER 321147 The ZX-Series Large S ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX**GH-2280ZX GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en score:32 filesize: 147.95 K page_count: 6 document date: 0000-00-00




[\[pdf\]](#) Specifications Warranty

JET Tools 321557 GH 1860ZX With Newall DP700 DRO Taper Attachment and Collet Closer Features

Specifications globalindustrial site images Manuals

GH-1860ZX WITH NEWALL DP700 DRO WITH TAPER ATTACHMENT AND COLLET CLOSER 321557 The ZX-Series Large S ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX**GH-2280ZX GH-2280ZX GH-2280ZX GH-2280ZX ...**

lang:en score:32 filesize: 153.43 K page_count: 6 document date: 0000-00-00




[\[pdf\]](#) Specifications Warranty

JET Tools 321961 GH 1860ZX With Taper Attachment and Collet Closer Lathe w TAK Features

Specifications globalindustrial site images Manuals |||

GH-1860ZX WITH TAPER ATTACHMENT AND COLLET CLOSER 321961 The ZX-Series Large Spindle Bore Lathe prov ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX**GH-2280ZX GH-2280ZX GH-2280ZX GH-2280ZX ...**

lang:en score:32 filesize: 162.92 K page_count: 6 document date: 2015-12-07




[\[pdf\]](#) Specifications Warranty

JET Tools 321910 GH 1440ZX 3 1 8 Spindle Bore Geared Head Lathe Jet Large 7 2 HP Features and

Specifications globalindustrial site images Manuals |||

GH-1440ZX, 3-1/8 SPINDLE BORE GEARED HEAD LATHE 321910 The ZX-Series Large Spindle Bore Lathe provi ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX GH-2280ZX ...**

lang:en score:32 filesize: 160.91 K page_count: 6 document date: 0000-00-00




[\[pdf\]](#) Specifications Warranty

JET Tools 321138 GH 1640ZX With Newall DP700 DRO Jet Large Spindle Bore Lathe W 7 1 2 HP

Features and Specifications globalindustrial site images Manuals |||

GH-1640ZX WITH NEWALL DP700 DRO 321138 The ZX-Series Large Spindle Bore Lathe provides power, precis ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en score:32 filesize: 163 K page_count: 6 document date: 2015-12-07




[\[pdf\]](#) Specifications Warranty

JET Tools 321930 GH 1640ZX 3 1 8 Spindle Bore Geared Head Lathe Jet Large 7 2 HP Features and

Specifications globalindustrial site images Manuals |||

GH-1640ZX, 3-1/8 SPINDLE BORE GEARED HEAD LATHE 321930 The ZX-Series Large Spindle Bore Lathe provi ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en score:32 filesize: 163.08 K page_count: 6 document date: 2015-12-07




[\[pdf\]](#) Specifications Warranty

JET Tools 321486 GH 1880ZX With Taper Attachment Jet Large Spindle Bore Lathe W 7 1 2 HP

B0230708 GLOBALindustrial Features and Specifications globalindustrial site images Manuals |||

GH-1880ZX WITH TAPER ATTACHMENT 321486 The ZX-Series Large Spindle Bore Lathe provides power, precis ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX** ...


lang:en score:31 filesize: 162.76 K page_count: 6 document date: 2015-12-03



[\[pdf\]](#) Specifications Warranty

JET Tools 321463 GH 1860ZX With Taper Attachment Jet Large Spindle Bore Lathe W 7 1 2 HP B0230751 GLOBALindustrial Features and Specifications globalindustrial site images Manuals ||| GH-1860ZX WITH TAPER ATTACHMENT 321463 The ZX-Series Large Spindle Bore Lathe provides power, precis ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX** ...


lang:en score:31 filesize: 151.41 K page_count: 6 document date: 2015-12-04



[\[pdf\]](#) Specifications Warranty

JET Tools 322486 GH 1880ZX With Taper Attachment and Collet Closer Jet Large Spindle Bore Lathe W TAK ZX B0503407 GLOBALindustrial Features Specifications globalindustrial site images Manuals ||| GH-1880ZX WITH TAPER ATTACHMENT AND COLLET CLOSER 322486 The ZX-Series Large Spindle Bore Lathe prov ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX**GH-2280ZX GH-2280ZX GH-2280ZX GH-2280ZX** ...


lang:en score:31 filesize: 162.19 K page_count: 6 document date: 0000-00-00



[\[pdf\]](#) Specifications Warranty

JET Tools 321531 GH 1440ZX With Collet Closer Jet Large Spindle Bore Lathe W 7 1 2 HP B0230854 GLOBALindustrial Features and Specifications globalindustrial site images Manuals ||| GH-1440ZX WITH COLLET CLOSER 321531 The ZX-Series Large Spindle Bore Lathe provides power, precision ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX GH-2280ZX** ...


lang:en score:31 filesize: 148.25 K page_count: 6 document date: 2015-12-04



[\[pdf\]](#) Specifications Warranty

JET Tools 321477 GH 1660ZX With Taper Attachment Jet Large Spindle Bore Lathe W 7 1 2 HP
B0230632 GLOBALindustrial Features and Specifications globalindustrial site images Manuals |||
GH-1660ZX WITH TAPER ATTACHMENT 321477 The ZX-Series Large Spindle Bore Lathe provides power, precis ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX** ...


lang:en score:31 filesize: 162.98 K page_count: 6 document date: 2015-12-03



[\[pdf\]](#) Specifications Warranty

JET Tools 321474 GH 1640ZX With Taper Attachment Jet Large Spindle Bore Lathe W 7 1 2 HP
B0230806 GLOBALindustrial Features and Specifications globalindustrial site images Manuals |||
GH-1640ZX WITH TAPER ATTACHMENT 321474 The ZX-Series Large Spindle Bore Lathe provides power, precis ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX** ...


lang:en score:31 filesize: 162.99 K page_count: 6 document date: 2015-12-04



[\[pdf\]](#) Specifications Warranty

JET Tools 321139 GH 1660ZX With Newall DP700 DRO Jet Large Spindle Bore Lathe W 2 Axis DP 700
B0230999 GLOBALindustrial Features and Specifications globalindustrial site images Manuals |||
GH-1660ZX WITH NEWALL DP700 DRO 321139 The ZX-Series Large Spindle Bore Lathe provides power, precis ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en score:31 filesize: 163 K page_count: 6 document date: 2015-12-07




[\[pdf\]](#) Specifications Warranty

JET Tools 321571 GH 1880ZX With Newall DP700 DRO Taper Attachment Jet Large Spindle Bore Lathe W 7 1 2 HP Features and Specifications globalindustrial site images Manuals |||

GH-1880ZX WITH NEWALL DP700 DRO WITH TAPER ATTACHMENT 321571 The ZX-Series Large Spindle Bore Lathe ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX**GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en score:31 filesize: 162.21 K page_count: 6 document date: 0000-00-00




[\[pdf\]](#) Specifications Warranty

JET Tools 321970 GH 1880ZX 3 1 8 Spindle Bore Geared Head Lathe Jet Large 7 2 HP B0230958

GLOBALindustrial Features and Specifications globalindustrial site images Manuals |||

GH-1880ZX, 3-1/8 SPINDLE BORE GEARED HEAD LATHE 321970 The ZX-Series Large Spindle Bore Lathe provi ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en score:31 filesize: 161.2 K page_count: 6 document date: 2015-12-07




[\[pdf\]](#) Specifications Warranty

JET Tools 321529 GH 1660ZX With Newall DP700 DRO Taper Attachment Jet Large Spindle Bore Lathe W 7 1 2 HP Features and Specifications globalindustrial site images Manuals |||

GH-1660ZX WITH NEWALL DP700 DRO WITH TAPER ATTACHMENT 321529 The ZX-Series Large Spindle Bore Lathe ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX**GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en score:31 filesize: 162.48 K page_count: 6 document date: 0000-00-00




[\[pdf\]](#) Specifications Warranty

JET Tools 321148 GH 1640ZX With Newall DP700 DRO Taper Attachment Jet Large Spindle Bore Lathe W 7 1 2 HP Features and Specifications globalindustrial site images Manuals |||

GH-1640ZX WITH NEWALL DP700 DRO WITH TAPER ATTACHMENT 321148 The ZX-Series Large Spindle Bore Lathe ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX**GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en **score:31** filesize: 161.74 K page_count: 6 document date: 2015-12-04




[\[pdf\]](#) Specifications Warranty

JET Tools 321530 GH 1660ZX With 3 Axis ACU RITE 200S DRO Compound Jet Large Spindle Bore Lathe W Acu Rite Features and Specifications globalindustrial site images Manuals |||

GH-1660ZX WITH 3-AXIS ACURITE 200S DRO COMPOUND 321530 The ZX-Series Large Spindle Bore Lathe prov ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en **score:31** filesize: 162.42 K page_count: 6 document date: 0000-00-00




[\[pdf\]](#) Specifications Warranty

JET Tools 321470 GH 1440ZX With Newall DP700 DRO Jet Large Spindle Bore Lathe W 7 1 2 HP B0230893 GLOBALindustrial Features and Specifications globalindustrial site images Manuals |||

GH-1440ZX WITH NEWALL DP700 DRO 321470 The ZX-Series Large Spindle Bore Lathe provides power, precis ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX GH-2280ZX** ...


lang:en **score:31** filesize: 146.71 K page_count: 6 document date: 2015-12-07



[\[pdf\]](#) Specifications Warranty

JET Tools 321488 GH 1880ZX With Newall DP700 DRO Jet Large Spindle Bore Lathe W 7 1 2 HP B0230755 GLOBALindustrial Features and Specifications globalindustrial site images Manuals ||| GH-1880ZX WITH NEWALL DP700 DRO 321488 The ZX-Series Large Spindle Bore Lathe provides power, precis ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX **GH-2280ZX GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en score:31 filesize: 153.79 K page_count: 6 document date: 2015-12-04



[\[pdf\]](#) Specifications Warranty

JET Tools 321493 GH 1880ZX With ACU RITE200S DRO Taper Attachment and Collet Closer Jet Large Spindle Bore Lathe W Acu Rite200S Features Specifications globalindustrial site images Manuals ||| GH-1880ZX WITH ACURITE200S DRO WITH TAPER ATTACHMENT AND COLLET CLOSER 321493 The ZX-Series Large Sp ... 21879 321567 321566 321568 321610 321612 321613 321615 321880 321881 321579 321486 322486 MODEL NO **GH-2280ZX** GH-1880ZX GH-1860ZX GH-1660ZX GH-1640ZX GH-1440ZX**GH-2280ZX GH-2280ZX GH-2280ZX GH-2280ZX** ...

lang:en score:31 filesize: 163.16 K page_count: 6 document date: 2015-12-03