

[Manuals.plus](#) /

› [CONAIR](#) /

› Conair Double Ceramic Hot Rollers HS38N User Manual

CONAIR HS38N

Conair Double Ceramic Hot Rollers HS38N User Manual

Model: HS38N | Brand: CONAIR

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your Conair Double Ceramic Hot Rollers, Model HS38N. Please read all instructions carefully before use and retain this manual for future reference.

The Conair Double Ceramic Hot Rollers set includes 20 multi-sized rollers designed to create various curl styles. This compact and portable unit is suitable for all hair types.

2. IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of burns, electrocution, fire, or injury to persons:

- Always unplug the appliance immediately after using.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- This appliance should not be used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

- The appliance is hot when in use. Do not let eyes or bare skin touch heated surfaces.
- Do not place the appliance on any surface while it is operating.
- Do not touch the heating posts or rollers directly when hot. Use caution when handling.

California Proposition 65 Warning:

This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer, and bisphenol-A, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

3. PACKAGE CONTENTS

Your Conair Double Ceramic Hot Rollers set includes the following items:


- 1 x Hot Roller Heating Unit
- 8 x Small Rollers (1/2 inch diameter)
- 6 x Medium Rollers (3/4 inch diameter)
- 6 x Large Rollers (1 inch diameter)
- 20 x Color-Coded Stainless Steel Clips

20 ASSORTED ROLLERS

8 – ½" small rollers

6 – ¾" medium rollers

6 – 1" large rollers



20 STRONG-HOLD PINS



Figure 1: Included rollers and clips. The set contains 8 small (1/2 inch), 6 medium (3/4 inch), and 6 large (1 inch) rollers, along with 20 strong-hold pins for securing them.

4. PRODUCT FEATURES

- **Compact Design:** Portable case for convenient storage and travel.
- **Multi-Size Rollers:** Includes 1/2", 3/4", and 1" rollers for diverse styling options.
- **Tangle-Free Rollers:** Designed with an easy-roll grip to prevent hair tangling.
- **Ready Signal:** An indicator light illuminates when the rollers are heated and ready for use.
- **Dual Voltage:** Suitable for international travel (requires appropriate adapter, not included).
- **Color-Coded Clips:** Stainless steel clips are color-coded for easy matching with roller sizes and can be stored within the unit.

20 ASSORTED ROLLERS

for curls & waves of every kind

20 COLOR-CODED PINS

secure hair without dents and
can be stored inside the hairsetter

EASY-ROLL GRIP

patented design for
tangle-free, secure hold

READY SIGNAL

dot on roller turns white when
rollers are ready to use




Figure 2: Overview of key product features, including roller assortment, color-coded pins, easy-roll grip, and the ready signal.

5. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the hot roller set and all accessories from the packaging.
2. **Place Rollers:** Place the rollers onto the heating posts within the unit. Ensure each roller is seated correctly.
3. **Close Lid:** Close the transparent lid securely. This ensures the rollers heat efficiently to their optimal temperature.



Ensure lid is tightly closed so rollers can heat to ultimate temperature.

Figure 3: Ensure the lid is tightly closed for efficient heating of the rollers.

4. **Connect Power:** Plug the power cord into a suitable electrical outlet.
5. **Heat-Up:** The red indicator light on the unit will illuminate, signaling that the rollers are beginning to heat. The rollers will be ready for use in approximately 85 seconds.

HEAT-UP SIGNAL

Lights up when rollers begin to heat — in just 85 seconds, your rollers will be ready for use!



Figure 4: The red light indicates the rollers are heating and will be ready in about 85 seconds.

6. OPERATING INSTRUCTIONS

Follow these steps to achieve desired curl and wave styles:

1. **Prepare Hair:** Ensure your hair is clean, dry, and thoroughly detangled. Brush through your hair to remove any knots.
2. **Select Roller:** Choose a roller size appropriate for the desired curl. For tighter curls, use smaller rollers; for looser waves, use larger rollers.
3. **Section Hair:** Take a 1-inch section of hair. For best results, start with sections from the top of your head.
4. **Roll Hair:** Place the end of the hair section on the roller and wind the hair towards the scalp. Ensure the hair is wrapped smoothly and evenly around the roller.



EASY-GRIP ROLLERS FOR A TANGLE-FREE, SECURE HOLD



BEAUTY TIP

Use 1-inch section of hair
and secure with roller pin

Figure 5: The easy-grip rollers provide a secure hold for tangle-free styling.

5. **Secure Roller:** Use a color-coded stainless steel clip to secure the roller firmly in place against your scalp.
6. **Repeat:** Continue rolling sections of hair until all desired areas are covered.
7. **Cooling Time:**
 - For bouncy curls and volume: Leave rollers in for 20 minutes or more.
 - For looser waves: Leave rollers in for 10 minutes or less.
 - Allow rollers to cool completely in your hair for optimal curl retention.
8. **Remove Rollers:** Once the rollers are cool to the touch, gently remove them one at a time. Start from the bottom back of your head to avoid disturbing other curls. Unroll the hair carefully, making sure not to pull or tug.
9. **Style Hair:** For bouncy, voluminous curls and waves, gently comb through your hair with your fingers or a wide-tooth comb. For extra hold, finish with a light application of hairspray.

7. MAINTENANCE AND CARE

- **Cleaning:** Ensure the unit is unplugged and completely cool before cleaning. Wipe the heating unit and rollers with a

damp cloth. Do not immerse the unit in water or any other liquid.

- **Storage:** Store the hot roller set in a cool, dry place. The clips can be stored inside the heating unit for convenience. Do not wrap the power cord around the appliance.
- **Cord Care:** Periodically inspect the power cord for any damage. If the cord is damaged, discontinue use and contact customer support.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Rollers not heating.	Unit not plugged in; rollers not seated correctly; lid not closed.	Ensure the unit is securely plugged into a working outlet. Verify rollers are properly placed on heating posts and the lid is tightly closed.
Rollers feel too hot to handle.	Rollers have been heating for an extended period.	Unplug the unit once the ready signal indicates optimal temperature. Allow a few moments for rollers to cool slightly before handling with care.
Curls do not hold or are too loose.	Insufficient heating time; rollers removed too soon; hair not properly prepared.	Ensure rollers are fully heated. Leave rollers in hair for a longer duration (20+ minutes). Ensure hair is clean and dry before styling. Finish with hairspray.
Hair tangles during rolling.	Hair not detangled; sections too large.	Thoroughly brush hair before rolling. Use smaller, manageable sections (approx. 1 inch).
Unusual plastic smell during first use.	Normal for new heating appliances.	This is typically normal for the first few uses. Ensure adequate ventilation. If the smell persists or is accompanied by smoke, discontinue use immediately.

9. SPECIFICATIONS

Model Number: HS38N

Brand: CONAIR

Product Dimensions: 7.25 x 4 x 7.25 inches

Item Weight: 1.1 Pounds

Material: Plastic

Number of Rollers: 20 (8 x 1/2", 6 x 3/4", 6 x 1")

Hair Type Compatibility: All

UPC: 074108145734

10. WARRANTY AND SUPPORT

This product is manufactured by Conair. For information regarding warranty coverage, product registration, or customer support, please refer to the warranty card included with your purchase or visit the official Conair website.

Please retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where can I get replacement clips for my Conair HS38N Double Ceramic Hot Roller set?

You can obtain replacement clips and rollers for your Conair HS38N set directly from the manufacturer. According to the product documentation, there are two primary ways to find these parts: Official Website: Visit the...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B001BLRYMO>

More documents and user manuals: <https://manuals.plus/>