Kingston Brass CC10T1

Kingston Brass CC10T1 Vintage Leg Tub Filler with Hand Shower Instruction Manual

Model: CC10T1 - Polished Chrome

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Kingston Brass CC10T1 Vintage Leg Tub Filler with Hand Shower. Please read all instructions carefully before beginning installation to ensure proper function and to prevent damage.

The Kingston Brass CC10T1 is a wall-mount tub filler designed for clawfoot tubs, featuring solid brass construction, a polished chrome finish, and a convenient hand shower with backflow prevention. It incorporates 1/4 turn ceramic disc cartridges for reliable operation.

Safety Information

- Always shut off the main water supply before installing or servicing the faucet.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, during installation.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Ensure all connections are secure to prevent leaks. Do not overtighten.
- This product is intended for use with standard residential water pressure.

Package Contents

Verify that all components are present before beginning installation:

- Tub Filler Faucet Body
- Hot and Cold Porcelain Handles
- Hand Shower with Hose
- Mounting Hardware
- Washers and Gaskets



Image 1: The Kingston Brass CC10T1 Vintage Leg Tub Filler with Hand Shower in Polished Chrome, shown installed on a bathtub. This image displays the main faucet body, hot and cold handles, spout, and the attached hand shower with its hose.

Tools Required

- Adjustable Wrench
- Pipe Wrench
- Screwdriver (Phillips and Flathead)
- Plumber's Putty or Silicone Sealant
- Thread Seal Tape (Teflon Tape)
- Measuring Tape
- Level

Installation (Setup)

Pre-Installation Steps

1. Shut off the main water supply to the bathroom.
2. Clear the installation area and ensure you have adequate space to work.
3. Inspect the tub filler and all components for any visible damage.

Mounting the Faucet Body

1. The faucet is designed for a 3-3/8 inch center-to-center spread wall-mount installation. Ensure your tub or wall has the appropriate two holes for mounting.
2. Apply plumber's putty or silicone sealant around the base of the faucet body where it will meet the mounting surface to create a watertight seal.
3. Insert the threaded shanks of the faucet body through the mounting holes.
4. From the backside of the mounting surface, secure the faucet body using the provided washers and mounting nuts. Hand-tighten first, then use an adjustable wrench to gently tighten, ensuring the faucet is level and stable. Do not overtighten.

Connecting Water Lines

1. Apply thread seal tape to the threaded ends of your hot and cold water supply lines.
2. Connect the hot water supply line to the inlet marked 'H' (Hot) and the cold water supply line to the inlet marked 'C' (Cold) on the faucet body.
3. Tighten all connections securely with an adjustable wrench.

Installing the Hand Shower

1. Attach the hand shower hose to the designated outlet on the faucet body. Ensure the washer is properly seated to prevent leaks.
2. Secure the hand shower cradle to the faucet body or an adjacent wall mount point as desired.
3. Connect the hand shower head to the other end of the hose.

Final Testing

1. Slowly turn on the main water supply.
2. Check all connections for leaks. If leaks are present, gently tighten the connections until they stop.
3. Turn on both hot and cold water to flush the lines and check for proper operation of the faucet and hand shower.




Image 2: Technical drawing providing detailed dimensions and specifications for the Kingston Brass CC10T1 tub filler, including the 3-3/8 inch spread and hose length.




Image 3: Diagram illustrating key features of the Kingston Brass CC10T1, such as solid brass construction, corrosion resistance, and the wall-mount installation type. It also shows flow rates for the hand shower and tub spout.

Operating Instructions

Using the Faucet

- The faucet features two porcelain handles labeled 'Hot' and 'Cold'. Turn the respective handle a quarter turn to open or close the water flow.
- Rotate the 'Hot' handle counter-clockwise to increase hot water flow and clockwise to decrease.
- Rotate the 'Cold' handle counter-clockwise to increase cold water flow and clockwise to decrease.
- Adjust both handles to achieve the desired water temperature and flow from the tub spout.

Using the Hand Shower

- To divert water to the hand shower, locate the diverter knob or lever on the faucet body and activate it.
- The hand shower has a maximum flow rate of 2.0 GPM (7.6 LPM) at 80 PSI.
- Ensure the hand shower is properly seated in its cradle when not in use.

Care and Maintenance

Cleaning the Finish

- The polished chrome finish is durable and resistant to tarnishing and corrosion.
- Clean the faucet regularly with a soft cloth and mild soap and water.
- Avoid using abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- Rinse thoroughly after cleaning and dry with a soft cloth to prevent water spots.

General Maintenance

- Periodically check all connections for tightness. If handles become loose, gently tighten the set screws located on the underside of the handles.
- The 1/4 turn ceramic disc cartridges are designed for long-lasting, drip-free performance. If a drip occurs, the cartridge may need to be replaced. Consult a plumber or the manufacturer for replacement parts.
- Clean the hand shower nozzles regularly to remove mineral buildup and maintain optimal spray performance.

Troubleshooting

Problem	Possible Cause	Solution
Faucet leaks from spout or handles	Loose connections; Worn O-rings or cartridge	Check and tighten all connections. If leaking persists, replace O-rings or ceramic disc cartridge.
Low water flow	Clogged aerator; Partially closed shut-off valve; Debris in water lines	Remove and clean the aerator. Ensure water supply valves are fully open. Flush water lines.
Handles are loose	Set screw needs tightening	Locate the set screw on the underside of the handle and tighten it with an Allen wrench.
Hand shower not working or low pressure	Diverter not fully engaged; Clogged nozzles; Kinked hose	Ensure diverter is fully engaged. Clean hand shower nozzles. Check hose for kinks.

Specifications

Feature	Specification
Model Number	CC10T1
Brand	Kingston Brass
Color	Polished Chrome
Material	Brass (faucet body), Brass/Ceramic/Porcelain (handles)
Finish Type	Polished
Number of Handles	3
Mounting Type	Wall-mount, Spread
Center-to-Center Spread	3-3/8 inches

Feature	Specification
Flow Rate (Hand Shower)	Max 2.0 GPM / 7.6 LPM at 80 PSI
Cartridge Type	1/4 Turn Ceramic Disc
Product Dimensions	10 x 9.5 x 4.25 inches
Item Weight	8.16 pounds
UPC	796299143701, 735090389437

Warranty and Support

For specific warranty information regarding your Kingston Brass CC10T1 tub filler, please refer to the documentation provided with your purchase or visit the official Kingston Brass website. Warranty terms typically cover manufacturing defects and material flaws for a specified period.
For technical support, replacement parts, or further assistance, please contact Kingston Brass customer service directly. You can find contact information on their official website or through your retailer.

Visit the Kingston Brass Store for more information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question