

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TOTO](#) /

› [TOTO ST733-03 Dalton Toilet Tank User Manual](#)

## TOTO ST733-03

# TOTO ST733-03 Dalton Toilet Tank User Manual

Model: ST733-03

## 1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your TOTO ST733-03 Dalton Toilet Tank. Designed with clean lines and a convenient tank lid shelf, this tank incorporates the 1.6 Gallon Gravity Jet flushing system, engineered for a powerful and quiet flush. Please read this manual thoroughly before installation and use to ensure proper function and longevity of your product.

**Note:** This product includes the toilet tank only. The toilet bowl is sold separately.

## 2. SAFETY INFORMATION

Please observe the following safety precautions during installation and maintenance:

- Always shut off the main water supply before beginning any plumbing work.
- Wear appropriate personal protective equipment, such as safety glasses and gloves.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any installation steps, consult a qualified plumber.
- Do not use harsh chemicals or abrasive cleaners on the tank's finish or internal components.

## 3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- TOTO ST733-03 Dalton Toilet Tank (Bone color)
- Tank Lid
- Internal Flushing System Fittings
- Chrome Plated Trip Lever
- Tank-to-Bowl Connection Hardware (bolts, washers, nuts, rubber gasket)



Figure 1: TOTO ST733-03 Dalton Toilet Tank, showcasing its clean lines and bone finish.



Figure 2: Color swatch indicating the Bone finish (#03) of the toilet tank.

## 4. SETUP AND INSTALLATION

Follow these steps to properly install your TOTO ST733-03 Dalton Toilet Tank onto a compatible toilet bowl (sold separately).

- 1. Prepare the Toilet Bowl:** Ensure the toilet bowl is securely installed and the mounting surface for the tank is clean and level.
- 2. Install Tank-to-Bowl Gasket:** Place the large rubber gasket onto the threaded outlet at the bottom of the tank. Ensure it is seated correctly to create a watertight seal.
- 3. Position the Tank:** Carefully align the tank over the bolt holes on the back of the toilet bowl. Lower the tank onto the bowl, ensuring the gasket compresses evenly.
- 4. Secure the Tank:** Insert the tank bolts through the holes in the tank and the bowl. From underneath the bowl, place washers and then tighten the nuts onto the bolts. Tighten evenly, alternating between bolts, until the tank is snug and stable. **Do not overtighten**, as this can crack the porcelain.
- 5. Connect Water Supply:** Connect the flexible water supply line from your shut-off valve to the fill valve inlet at the bottom of the tank. Hand-tighten first, then use a wrench for a final quarter-turn.

6. **Check for Leaks:** Slowly turn on the water supply valve. Allow the tank to fill. Inspect all connections (tank-to-bowl, water supply line) for any signs of leaks. Tighten connections slightly if necessary.

7. **Install Tank Lid:** Place the tank lid securely on top of the tank.

## 5. OPERATING INSTRUCTIONS

---

The TOTO ST733-03 Dalton Toilet Tank utilizes a 1.6 Gallon Gravity Jet flushing system for efficient waste removal.

- **Flushing:** To flush the toilet, press down firmly on the chrome plated trip lever located on the front of the tank. This activates the flush valve, releasing water from the tank into the bowl.
- **Refilling:** After flushing, the tank will automatically refill to the appropriate water level, ready for the next use. The Gravity Jet system ensures a powerful and quiet flush with each activation.

## 6. MAINTENANCE

---

Regular cleaning and basic maintenance will help ensure the longevity and optimal performance of your TOTO toilet tank.

### 6.1. Cleaning the Exterior

- Use a soft cloth and a mild, non-abrasive cleaner specifically designed for bathroom fixtures.
- Avoid abrasive powders, scouring pads, or cleaners containing harsh chemicals like bleach, ammonia, or acid, as these can damage the finish.
- Wipe the exterior surfaces, including the tank lid and trip lever, regularly to prevent mineral buildup and maintain shine.

### 6.2. Internal Component Check

- Periodically remove the tank lid and inspect the internal components (fill valve, flush valve, flapper/seal) for wear or damage.
- Ensure the chain connecting the trip lever to the flapper is not tangled or too tight/loose, as this can affect flushing performance.
- If mineral deposits accumulate, gently clean them with a soft brush and a vinegar solution, then rinse thoroughly.

## 7. TROUBLESHOOTING

---

Refer to this section for solutions to common issues you might encounter.

### 7.1. Toilet Runs Continuously

- **Flapper/Seal Issue:** The flapper or flush valve seal may not be seating properly. Inspect for debris, wear, or misalignment. Clean or replace if necessary.
- **Fill Valve Adjustment:** The water level may be too high, causing water to flow into the overflow tube. Adjust the fill valve to lower the water level.
- **Trip Lever Chain:** The chain connecting the trip lever to the flapper might be too short, holding the flapper slightly open. Adjust the chain length.

### 7.2. Weak or Incomplete Flush

- **Water Level Too Low:** The water level in the tank might be too low to provide sufficient flushing power. Adjust the fill valve to raise the water level.
- **Flapper Not Opening Fully:** The chain to the flapper might be too long, preventing it from opening completely. Shorten the chain.
- **Clogged Rim Jets/Siphon Jet:** Mineral buildup in the rim jets or siphon jet of the toilet bowl (not the tank) can restrict water flow. This requires cleaning the bowl's jets.

### 7.3. Leaks Around the Tank Base

- **Tank-to-Bowl Gasket:** The gasket between the tank and bowl may be improperly seated, worn, or damaged. Ensure it is correctly positioned and replace if necessary.
- **Tank Bolts:** The tank bolts may not be tightened evenly or sufficiently. Gently tighten the nuts, alternating between them, but avoid overtightening.
- **Water Supply Connection:** Check the connection of the water supply line to the fill valve for tightness.

If these steps do not resolve the issue, please contact TOTO customer support or a qualified plumber.

## 8. SPECIFICATIONS

Feature	Detail
Manufacturer	TOTO
Model Number	ST733-03
Item Weight	40 pounds
Package Dimensions	60 x 34 x 14 inches
Size	1.6 Gallon Flush
Color	Bone
Water Consumption	1.6 Gallons per Flush
Item Package Quantity	1

## 9. WARRANTY AND SUPPORT

The TOTO ST733-03 Dalton Toilet Tank is covered by a**One Year Limited Warranty**. This warranty covers defects in materials and workmanship under normal use and service.

For warranty claims, technical assistance, or to purchase replacement parts, please contact TOTO customer support. Refer to the official TOTO website or your purchase documentation for the most current contact information.

**TOTO Customer Support:** [Visit TOTO's Official Website](#)

