Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WARNER HOME VIDEO B001CC7POE

The Flintstones: The Complete Series DVD Instruction Manual

Model: B001CC7POE | Brand: WARNER HOME VIDEO

1. Introduction

This manual provides essential instructions for the proper setup, operation, and maintenance of your**The Flintstones: The Complete Series DVD** set. Please read this guide thoroughly to ensure optimal enjoyment and longevity of your product.



Image 1.1: The Flintstones: The Complete Series DVD box set. This image displays the front cover of The Flintstones: The Complete Series DVD box set. It features the main characters, Fred Flintstone, Wilma Flintstone, Barney Rubble, Betty Rubble, Pebbles, and Dino, riding in their stone-age car. The title 'The Flintstones: The Complete Series' is prominently displayed at the top. The overall design evokes the classic animated television show.

2. Setup

2.1 Unboxing and Inspection

1. Carefully remove the DVD box set from its packaging.
2. Inspect the outer packaging for any signs of damage.
3. Open the box set to access the 24 DVD discs.
4. Examine each disc for scratches, smudges, or other imperfections. If any disc appears damaged, contact customer support.

2.2 Preparing for Playback

- Ensure you have a compatible DVD player or computer with a DVD drive.
- Connect your DVD player to a television or monitor according to its own instruction manual.
- Power on your DVD player and display device.

3. Operating Instructions

3.1 Disc Insertion and Playback

1. Gently remove the desired DVD disc from its sleeve. Handle discs by the edges to avoid fingerprints.
2. Insert the disc into your DVD player with the label side facing up.
3. The DVD player should automatically load the disc and display the main menu. If not, press the 'Play' button on your remote control or DVD player.
4. From the main menu, you can select specific episodes, adjust audio settings, or choose subtitles if available.

3.2 Language Selection

The primary audio language for this DVD set is English. Some discs may offer additional language options, such as Spanish dubbing, which can typically be selected from the DVD's main menu or audio settings.

4. Maintenance

4.1 Disc Handling and Cleaning

- Always hold discs by their outer edges or by placing a finger through the center hole. Avoid touching the shiny playback surface.
- To clean a disc, gently wipe it with a soft, lint-free cloth from the center outwards. Do not use abrasive materials or harsh cleaning chemicals.
- For stubborn smudges, a slightly dampened cloth with water can be used, followed by immediate drying with a clean, dry cloth.

4.2 Storage

- Store discs in their original sleeves within the box set to protect them from dust and scratches.
- Keep the box set in a cool, dry place away from direct sunlight and extreme temperatures.
- *Note: Some users have reported that the disc sleeves can be tight. Exercise caution when removing and inserting discs to prevent damage. If preferred, consider transferring discs to alternative, less restrictive storage cases.*

5. Troubleshooting

5.1 Common Playback Issues

- **Disc Not Playing/Freezing:**
  - Ensure the disc is clean and free of smudges or scratches. Clean the disc as described in Section 4.1.
  - Check if the disc is inserted correctly into the DVD player.
  - Try playing the disc in another DVD player or computer to determine if the issue is with the disc or the player.
  - Ensure your DVD player's firmware is up to date, if applicable.
- **No Audio/Video:**
  - Verify that your DVD player is correctly connected to your TV/monitor.
  - Check the audio and video input selections on your TV/monitor.
  - Ensure the volume on your TV/audio system is not muted or set too low.

6. Specifications

Product Title	The Flintstones: The Complete Series
Model Number (ASIN)	B001CC7POE
Brand	WARNER HOME VIDEO
Media Format	DVD, Animated, Box set, Color, Dolby, Limited Edition
Number of Discs	24
Run Time	Approximately 70 hours and 58 minutes
Language	English (with potential additional language options)
MPAA Rating	NR (Not Rated)
Genre	Kids & Family, Anime & Manga
Package Dimensions	12.9 x 8.3 x 2.9 inches
Item Weight	3.15 Pounds
Actors	Alan Reed, Bea Benaderet, Jean Vander Pyl, John Stephenson, Mel Blanc

7. Warranty Information

This product is covered by the standard manufacturer's warranty. Please refer to the packaging or the official WARNER HOME VIDEO website for detailed warranty terms and conditions. Keep your proof of purchase for warranty claims.

8. Customer Support

For further assistance, technical support, or inquiries regarding your **The Flintstones: The Complete Series DVD** set, please contact WARNER HOME VIDEO customer service. Contact information can typically be found on the product packaging or their official website.

© 2023 WARNER HOME VIDEO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B001CC7POE

More documents and user manuals: **https://manuals.plus/**