



Manuals.plus /

› Vivanco /

› Vivanco HDMI 1.3 2-Port Manual Switch User Manual

Vivanco HDX2.1 MAN 1.3

Vivanco HDMI 1.3 2-Port Manual Switch User Manual

Model: HDX2.1 MAN 1.3

INTRODUCTION

This manual provides comprehensive instructions for the Vivanco HDMI 1.3 2-Port Manual Switch, Model HDX2.1 MAN 1.3. This device allows you to connect two HDMI source devices to a single HDMI display, enabling manual switching between the inputs. Please read this manual carefully before using the product to ensure proper operation and longevity.

PRODUCT OVERVIEW

The Vivanco HDMI 1.3 2-Port Manual Switch is designed to simplify your audio-visual setup. It eliminates the need to constantly swap HDMI cables when using multiple source devices with one display. Key features include:

- **2 HDMI Inputs:** Connect up to two HDMI source devices.
- **1 HDMI Output:** Connect to a single HDMI display.
- **Manual Switching:** Easily select your desired input with dedicated buttons.
- **Plug and Play:** No software installation required.
- **Nickel-Plated Connectors:** Ensures reliable signal transmission and durability.



Image: Front view of the Vivanco HDMI 1.3 2-Port Manual Switch, showing the two input selection buttons and HDMI ports. This image illustrates the compact design and user interface for input selection.

SETUP

Follow these steps to connect your Vivanco HDMI switch:

1. **Connect Source Devices:** Take an HDMI cable from your first source device (e.g., Blu-ray player, game console) and connect it to the **INPUT 1** port on the Vivanco HDMI switch. Repeat this step for your second source device, connecting it to the **INPUT 2** port.
2. **Connect to Display:** Use another HDMI cable to connect the **OUTPUT** port of the Vivanco HDMI switch to an HDMI input port on your display (e.g., TV, monitor, projector).
3. **Power On:** Ensure all connected devices (source devices, display, and the HDMI switch itself) are powered on. This manual switch does not require an external power adapter.

Note: For optimal performance, use high-quality HDMI cables. Ensure all connections are secure to prevent signal loss.

OPERATING INSTRUCTIONS

Using the Vivanco HDMI switch is straightforward:

1. **Select Input:** On the front panel of the Vivanco HDMI switch, press the button labeled **1** to select the device connected to INPUT 1, or press the button labeled **2** to select the device connected to INPUT 2.
2. **View Content:** The video and audio from the selected source device will now be displayed on your connected screen.

Tip: If your display does not automatically switch to the correct input, manually select the HDMI input on your TV or monitor that the switch is connected to.

MAINTENANCE

To ensure the longevity and optimal performance of your Vivanco HDMI switch, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the exterior of the device. Do not use liquid cleaners, aerosols, or solvents, as these may damage the finish or internal components.
- **Environment:** Keep the switch in a cool, dry place, away from direct sunlight, heat sources, and excessive moisture. Avoid placing it in areas with high dust accumulation.
- **Connections:** Periodically check that all HDMI cables are securely connected. Avoid bending or crimping cables excessively.

TROUBLESHOOTING

If you encounter issues with your Vivanco HDMI switch, refer to the following common problems and solutions:

- **No Picture or Sound:**
 - Ensure all HDMI cables are firmly connected to both the source devices, the switch, and the display.
 - Verify that the correct input button (1 or 2) is pressed on the Vivanco switch.
 - Check that your TV or monitor is set to the correct HDMI input channel.
 - Try connecting a source device directly to the display to confirm the source device and HDMI cable are functioning correctly.
 - Restart all connected devices (source, switch, display).
- **Poor Picture Quality or Flickering:**
 - Ensure you are using high-quality HDMI cables. Lower quality or excessively long cables can degrade signal.
 - Check for any interference from other electronic devices.
- **Switch Not Responding:**
 - This manual switch does not require external power, but ensure the source devices are providing sufficient power through the HDMI connection.
 - Disconnect and reconnect all HDMI cables to reset the connections.

SPECIFICATIONS

Brand	Vivanco
Model Number	HDX2.1 MAN 1.3
HDMI Standard	1.3
Inputs	2 x HDMI
Output	1 x HDMI
Switching Method	Manual Push Button
Color	Black
Special Features	Plug and Play, HDMI and HDCP Compatible, Nickel-plated connectors
Compatible Devices	HDMI source devices (e.g., DVD/Blu-ray players, game consoles, set-top boxes), HDMI displays (e.g., TVs, monitors, projectors)

WARRANTY AND SUPPORT

For information regarding warranty coverage, technical support, or spare parts availability for your Vivanco HDMI 1.3 2-Port Manual Switch, please refer to the documentation provided at the time of purchase or visit the official Vivanco website. Specific warranty terms may vary by region and retailer.

Information regarding guaranteed software updates and spare parts availability is not provided with this product.