Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Onkyo DS-A1XP

ONKYO iPod RI Dock DS-A1XP User Manual

Model: DS-A1XP

Introduction

The ONKYO iPod RI Dock DS-A1XP allows you to integrate your iPod with your Onkyo component audio system. This dock enables remote control of your iPod's music library, including playback, pause, track skipping, and volume adjustment, directly from your Onkyo system's remote control. It also supports user-friendly system linking features, such as automatic iPod power-on and input selector switching when you press the play button on the remote during standby. Additionally, the dock charges your iPod while it is connected, transforming your Onkyo system into a high-quality music server utilizing your iPod library.

Setup

Package Contents:

- ONKYO iPod RI Dock DS-A1XP unit
- Power Adapter
- Audio Cables (RCA and 3.5mm jack)



This image displays the power adapter and audio cables required for connecting the Onkyo iPod RI Dock DS-A1XP to your audio system and power source. The cables include RCA connectors (red and white) for audio output and a blue 3.5mm jack, along with the power adapter.

Connection Steps:

1. **Connect Audio Cables:** Connect the RCA audio cables (red for right, white for left) from the DS-A1XP dock's audio output to an available audio input on your Onkyo component system. Alternatively, use the 3.5mm jack if your system supports it.
2. **Connect Power Adapter:** Plug the power adapter into the DC input on the DS-A1XP dock, then plug the adapter into a standard electrical outlet.
3. **Place iPod:** Carefully place your compatible iPod into the dock connector on the DS-A1XP. Ensure it is seated firmly to establish a proper connection for audio playback and charging.
4. **Power On:** Turn on your Onkyo component system and select the input source to which the DS-A1XP is connected.

Operating Instructions

Basic Playback:

- Once your iPod is docked and the Onkyo system is set to the correct input, you can use the Onkyo system's remote control to manage iPod playback.
- Press the **Play** button on your Onkyo remote to start music playback. If the system is in standby, this action will also power on your iPod and switch the input automatically.
- Use the **Pause** button to temporarily stop playback.
- Use the **Skip Up/Down** buttons to navigate between tracks.
- Adjust the volume using the **Volume Up/Down** buttons on your Onkyo remote.

Charging:

The iPod will automatically charge when it is correctly docked in the DS-A1XP and the dock is connected to a power source, regardless of whether the Onkyo system is powered on or in standby.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the dock. Do not use liquid cleaners or abrasive materials.
- **Dock Connector:** Periodically inspect the iPod dock connector for dust or debris. Use a soft brush or compressed air to gently clean it if necessary.
- **Storage:** When not in use for extended periods, disconnect the power adapter and store the dock in a cool, dry place away from direct sunlight.

Troubleshooting

Problem	Possible Cause / Solution
No sound from iPod	◦ Ensure the iPod is firmly seated in the dock connector. ◦ Verify the audio cables are securely connected to both the dock and the Onkyo system. ◦ Check that the correct input source is selected on your Onkyo system. ◦ Confirm the volume on both the iPod and the Onkyo system is not muted or set too low.
iPod not charging	◦ Ensure the power adapter is properly connected to the dock and a working electrical outlet. ◦ Check if the iPod is correctly seated in the dock.
Remote control not working with iPod	◦ Ensure the iPod is fully compatible with the dock (e.g., older iPod models may have full functionality, newer models like some iPod Touch or iPhone models might have limited remote control for album/playlist selection). ◦ Confirm the iPod is firmly docked. ◦ Remove any bulky protective cases from the iPod, as they may prevent proper connection to the dock. ◦ Ensure your Onkyo system's remote control is functioning correctly and has fresh batteries.
iPod not recognized with protective case	◦ Some protective cases may prevent the iPod from making full contact with the dock connector. Remove the case before docking the iPod.

Specifications

Feature	Detail
Brand	Onkyo
Model Number	DS-A1XP
Color	Black
Hardware Interface	USB (for iPod connection)
Total USB Ports	1
Audio Output Ports	2 (RCA L/R, 3.5mm jack)
Item Weight	1.37 pounds (approx. 0.62 kg)
Power Consumption	7.5 W

Warranty and Support

For warranty information and technical support, please refer to the documentation provided with your original purchase or visit the official Onkyo website. Keep your proof of purchase for any warranty claims.

For further assistance, you may contact Onkyo customer support through their official channels. Please have your model number (DS-A1XP) and any relevant purchase details ready.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B001CMU4TC

More documents and user manuals: **https://manuals.plus/**