

Household Essentials 131210

Household Essentials Tabletop Ironing Board

Model: 131210

INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your Household Essentials Tabletop Ironing Board, Model 131210. Designed for efficiency in compact spaces, this ironing board offers a convenient solution for garment care.

PRODUCT OVERVIEW

The Household Essentials Tabletop Ironing Board is a compact and versatile ironing surface. Key features include:

- **Compact Design:** Ideal for small living spaces, dorms, or apartments.
- **Integrated Iron Rest:** A retractable metal rack provides a safe place to rest your iron, preventing scorching and damage.
- **Door Hanging Feature:** Includes a door hanger for convenient storage when not in use.
- **Quality Surface:** Features a perforated steel mesh top and a 100% cotton cover with 5mm fiber padding for optimal steam circulation and smooth ironing.
- **Versatile Use:** Can be used on various flat surfaces such as tabletops, counters, or floors.



Figure 1: Household Essentials Tabletop Ironing Board with its retractable iron rest extended.



Figure 2: Detail of the retractable iron rest, designed to securely hold an iron during use.

## SETUP INSTRUCTIONS

1. **Unfold the Board:** Place the ironing board face down on a flat, stable surface.
2. **Extend Support Bars:** Locate the center support bar and pull it upwards. Then, pull up one of the two cross support bars.
3. **Secure the Supports:** Snap the center support bar into the designated slot on the cross support bar. Ensure all legs are securely locked into place for stability.
4. **Position for Use:** Flip the board over to its upright position. It is now ready for ironing.
5. **Retract Iron Rest (Optional):** If needed, slide out the retractable iron rest from the end of the board.



Figure 3: The ironing board fully set up on a kitchen countertop, demonstrating its tabletop use.

## Storage

When collapsed, the ironing board has a slim profile of approximately 1.5 inches. It can be easily stored by sliding it into tight spaces or by hanging it on the back of a door using the included door hanging bar.



Figure 4: The included door hanger accessory for convenient storage.



Figure 5: The ironing board stored by hanging it on a door, showcasing its space-saving design.

## OPERATING INSTRUCTIONS

Once the ironing board is set up on a stable surface:

- 1. Prepare Garment:** Lay the garment flat on the ironing surface, ensuring it is smooth and free of wrinkles.
- 2. Iron Placement:** Place your iron on the retractable iron rest when not actively ironing to prevent accidental burns or damage to the garment or surface.
- 3. Ironing Technique:** Follow the garment's care label instructions for appropriate iron temperature. Iron in smooth, even strokes. The perforated steel mesh top and padded cover facilitate steam penetration for effective wrinkle removal.
- 4. Safety:** Always unplug your iron when not in use and allow it to cool completely before storing.

## MAINTENANCE

- Cleaning the Cover:** The 100% cotton cover can be removed and spot cleaned as needed. Allow it to air dry completely before reattaching.
- Replacing the Cover:** Over time, the ironing board cover and padding may wear out. Replacement covers (Model #1209) are available separately.
- Frame Care:** Wipe the metal frame with a damp cloth to remove dust or debris. Do not use abrasive cleaners.

## TROUBLESHOOTING

- Problem: Board feels unstable or wobbly.**  
**Solution:** Ensure all support bars are fully extended and securely locked into place. Verify the board is placed on a flat, even surface. Uneven surfaces can affect stability.
- Problem: Difficulty in folding or unfolding the board.**  
**Solution:** Apply gentle, firm pressure when engaging or disengaging the support bar mechanisms. Avoid forcing components. Refer to the "Setup Instructions" for the correct procedure.
- Problem: Iron rest does not slide smoothly.**  
**Solution:** Check for any obstructions or debris in the sliding mechanism. Clean the area if necessary. Ensure the iron rest is aligned correctly within its tracks.

## SPECIFICATIONS

|                             |                                                         |
|-----------------------------|---------------------------------------------------------|
| Brand                       | Household Essentials                                    |
| Model Number                | 131210                                                  |
| Material                    | Alloy Steel (Frame), 100% Cotton (Cover)                |
| Color                       | Natural                                                 |
| Product Dimensions (Open)   | 30" L x 12" W x 5" H (approx. with iron rest retracted) |
| Ironing Surface Dimensions  | 12" x 30"                                               |
| Product Dimensions (Closed) | 1.5" H x 12" W x 35.5" L (approx.)                      |
| Item Weight                 | 5.3 Pounds                                              |
| Mounting Type               | Tabletop Mount (with door hang option)                  |
| Collapsible Legs            | Yes, for compact storage                                |

|     |              |
|-----|--------------|
| UPC | 026663450228 |
|-----|--------------|




Figure 6: Dimensional overview of the Household Essentials Tabletop Ironing Board.

## WARRANTY AND SUPPORT

For warranty information or product support, please contact Household Essentials customer service. Details can typically be found on the product packaging or the official Household Essentials website.

**Online Support:** [Visit the Household Essentials Store on Amazon](#)

© 2023 Household Essentials. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

Anonymous

#### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B001D4AJL2>

More documents and user manuals: <https://manuals.plus/>