

[Manuals.plus](#) /

› [Standard Motor Products](#) /

› Standard Motor Products PR334 Fuel Pressure Regulator Instruction Manual

Standard Motor Products PR334

Standard Motor Products PR334 Fuel Pressure Regulator Instruction Manual

Model: PR334

INTRODUCTION

This instruction manual provides essential information for the proper installation, operation, and maintenance of your Standard Motor Products PR334 Fuel Pressure Regulator. Please read this manual thoroughly before attempting any installation or service to ensure safety and optimal performance of the product.

IMPORTANT SAFETY INFORMATION

WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov. Always wear appropriate personal protective equipment when handling automotive components and working on vehicle systems. Fuel systems are under pressure and contain flammable liquids; exercise extreme caution.

PRODUCT OVERVIEW

The Standard Motor Products PR334 is a fuel pressure regulator designed to maintain consistent fuel pressure within your vehicle's fuel injection system. Proper fuel pressure is crucial for efficient engine operation and fuel delivery.



Image: Standard Motor Products PR334 Fuel Pressure Regulator. This image displays the metallic body of the regulator, featuring a threaded connection at the top, a black hexagonal nut, and two hose barb fittings extending from the side and bottom for fuel line connections.

SETUP AND INSTALLATION

Installation of a fuel pressure regulator requires specific automotive knowledge and tools. It is highly recommended that installation be performed by a qualified automotive technician. Incorrect installation can lead to fuel leaks, engine damage, or fire hazards.

General Installation Steps (Consult Vehicle Service Manual for Specifics):

1. **Depressurize Fuel System:** Before beginning, ensure the vehicle's fuel system is depressurized according to the manufacturer's service manual.
2. **Disconnect Battery:** Disconnect the negative terminal of the vehicle's battery.
3. **Locate Old Regulator:** Identify the existing fuel pressure regulator on your vehicle.
4. **Remove Fuel Lines:** Carefully disconnect fuel lines from the old regulator, being prepared for residual fuel spillage. Use appropriate catch containers.
5. **Remove Old Regulator:** Unmount the old regulator from its position.
6. **Install New Regulator:** Install the new Standard Motor Products PR334 regulator, ensuring all seals and O-rings are correctly seated.
7. **Reconnect Fuel Lines:** Securely reattach all fuel lines to the new regulator.
8. **Reconnect Battery:** Reconnect the negative battery terminal.
9. **Check for Leaks:** Turn the ignition to the "ON" position (without starting the engine) to prime the fuel pump and pressurize the system. Inspect all connections for any fuel leaks.
10. **Start Engine:** Start the engine and re-check for leaks while the engine is running.

Always refer to your specific vehicle's service manual for detailed, model-specific installation procedures and torque specifications.

OPERATING PRINCIPLES

The PR334 Fuel Pressure Regulator operates automatically to maintain a consistent fuel pressure differential across the fuel injectors. This ensures that the correct amount of fuel is delivered to the engine under various operating conditions. Once installed, the regulator requires no manual adjustment or intervention during normal vehicle operation.

MAINTENANCE

The Standard Motor Products PR334 Fuel Pressure Regulator is designed for long-term, maintenance-free operation. Regular maintenance typically involves inspecting the fuel system for leaks and ensuring all connections remain secure. If any signs of malfunction or fuel leaks are observed, the unit should be inspected by a qualified technician.

TROUBLESHOOTING

If you suspect a problem with your fuel pressure regulator, common symptoms may include:

- Engine misfires or rough idling
- Difficulty starting the engine
- Reduced fuel economy
- Black smoke from the exhaust (rich fuel mixture)
- Fuel smell from the engine compartment
- Check Engine Light illumination

If you experience any of these symptoms, it is recommended to have your vehicle's fuel system diagnosed

by a professional technician. Do not attempt to repair the regulator; replacement is typically the only solution for a faulty unit.

SPECIFICATIONS

Model Number	PR334
Brand	Standard Motor Products
Item Weight	3.52 ounces
Product Dimensions	2 x 1.44 x 3.38 inches
Exterior Finish	Machined
Manufacturer Part Number	PR334

WHAT'S IN THE BOX

- One (1) Standard Motor Products PR334 Fuel Pressure Regulator

WARRANTY AND SUPPORT

For warranty information or technical support regarding your Standard Motor Products PR334 Fuel Pressure Regulator, please contact Standard Motor Products directly through their official website or customer service channels. Keep your purchase receipt for warranty claims.