

[Manuals.plus](#) /

- › [Johnny Apple Peeler](#) /
- › Johnny Apple Peeler VKP1010: Corer, Slicer, and Peeler Instruction Manual

Johnny Apple Peeler VKP1010

Johnny Apple Peeler VKP1010 Instruction Manual

Model: VKP1010 | Brand: Johnny Apple Peeler

PRODUCT OVERVIEW

The Johnny Apple Peeler VKP1010 is a versatile kitchen tool designed to efficiently peel, core, and slice apples and other produce. Constructed with a heavy-duty cast iron body and stainless steel blades, it offers durability and ease of use for various culinary tasks.

- **Quick and Easy:** Designed to peel, core, and slice any apple variety with minimal effort.
- **Easy to Adjust:** The coring/slicing blade can be removed, and the peeling blade is adjustable for thick or thin peels.
- **Built to Last:** Features stainless steel blades and a robust cast iron body.
- **Strong Suction Base:** Ensures stable operation by firmly gripping smooth, nonporous surfaces.



Figure 1: Johnny Apple Peeler VKP1010 with its primary components.

SETUP

1. **Secure the Base:** Place the peeler on a clean, smooth, nonporous surface. Press down on the suction lever located at the base to firmly attach the unit to the countertop.
2. **Prepare the Drive Shaft:** Pull back the drive shaft using the quick-release lever to create space for mounting the apple.
3. **Adjust Blades (if necessary):**
 - **Peeling Blade:** The adjustable stainless steel peeling blade can be moved to remove a thicker or thinner peel.
 - **Coring/Slicing Blade:** This blade can be removed if only peeling is desired. To remove, loosen the wing nut and slide the blade off.




Figure 2: Labeled components of the Johnny Apple Peeler VKP1010.

Video 1: Demonstrates the easy installation and time-saving features of the Johnny Apple Peeler.

OPERATING INSTRUCTIONS

Peeling, Coring, and Slicing Apples

1. Ensure the peeling blade and coring/slicing blade are in place and properly adjusted.
2. Center an apple onto the three prongs of the drive shaft.
3. Turn the crank handle clockwise. The apple will rotate, moving towards the blades. The peeling blade will remove the skin, and the coring/slicing blade will simultaneously core and slice the apple into a continuous spiral.
4. Once the apple is fully processed, pull the drive shaft back using the quick-release lever to remove the peeled, cored, and sliced apple.



Peel, Core & Slice Apples



Core & Slice Apples



Baked Goods



Dehydrated Apples

Figure 3: Apple being peeled, cored, and sliced by the peeler.

Video 2: Demonstrates the process of peeling, coring, and slicing an apple.

Peeling Only (without Coring/Slicing)

1. Before starting, remove the coring/slicing blade by loosening its wing nut and sliding it off.
2. Mount the apple onto the drive shaft prongs.
3. Turn the crank handle. The peeling blade will remove the skin, leaving the apple whole and cored.

Peeling Potatoes

1. For potatoes, it is recommended to remove the coring/slicing blade.
2. Mount the potato onto the drive shaft prongs.
3. Turn the crank handle. The peeling blade will remove the potato skin.



Figure 4: Peeling a potato with the Johnny Apple Peeler VKP1010.

MAINTENANCE AND CLEANING

To ensure the longevity and optimal performance of your Johnny Apple Peeler VKP1010, follow these cleaning guidelines:

- After each use, rinse the unit under running water to remove any fruit or vegetable residue.
- For thorough cleaning, carefully remove the coring and slicing blade. Gently wash it in a soapy bowl of hot water, rinse, and dab dry.
- The unit is not recommended for dishwasher cleaning, especially due to the wooden handle.
- For long-term storage, apply a thin coat of petroleum jelly to any unpainted metal parts to prevent rust.

TROUBLESHOOTING

Apple not coring or slicing properly

Ensure the coring and slicing blade is correctly aligned with the steel shaft. A slight adjustment may be needed to ensure proper function and prevent premature wear.

Peeling blade not removing skin effectively

Check the adjustment of the peeling blade. It can be moved to remove a thicker or thinner peel. Also, ensure the apple is firmly secured on the prongs.

Unit not stable on countertop

Verify that the suction base is properly engaged on a clean, smooth, nonporous surface. Press down firmly on the suction lever.

SPECIFICATIONS

Feature	Detail
Brand	Johnny Apple Peeler
Model Name	VKP1010
Color	Red
Material	Cast Iron
Blade Material	Stainless Steel
Handle Material	Wood
Operation Mode	Automatic
Product Dimensions	12"L x 4.25"W
Item Weight	2 Pounds
Number of Blades	2
UPC	811957010109




Figure 5: Product dimensions of the Johnny Apple Peeler VKP1010.

WARRANTY AND SUPPORT

The Johnny Apple Peeler VKP1010 is backed by a full 5-year warranty, ensuring quality and durability.

For customer service, support, or additional product information, please visit the [Johnny Apple Peeler Store](#).