

Lasko 4440

Lasko 4440 40-Inch Hybrid 3-Speed Fan with Remote Control User Manual

Model: 4440

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using this fan. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- This fan is for household use only. Do not use for commercial or industrial purposes.
- Always unplug the fan before cleaning, servicing, or relocating.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Do not insert or allow fingers or foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fan.
- Do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- Always place the fan on a stable, flat, level surface during operation to prevent the fan from tipping over.
- This fan is not intended for use in wet or damp locations. Never locate a fan where it may fall into a bathtub or other water container.
- Do not use this fan near windows. Rain and moisture may create an electrical hazard.
- This fan employs a safety fuse. If the fuse blows, unplug the fan and replace the fuse according to the instructions provided.

2. PRODUCT OVERVIEW

The Lasko 4440 Hybrid Fan is designed to provide powerful and efficient cooling for your home. Its sleek tower design incorporates advanced airflow technology and convenient features.

Key Features:

- Hybrid fan technology delivers approximately 30% more air than standard tower fans.
- Easy-to-use control panel with intuitive buttons.
- Three distinct speed settings for customized airflow.
- Widespread oscillation feature for broad room coverage.
- Integrated night light function for a soft, ambient glow.
- Includes a remote control for convenient operation from a distance.
- Equipped with a patented safety fuse for enhanced protection.

Package Contents:

- Lasko 4440 Hybrid Fan Unit
- Remote Control (with batteries included)
- User Manual (this document)





Figure 1: The Lasko 4440 40-Inch Hybrid Fan. This image shows the fan's tall, slender tower design in a gray and black finish, with the control panel visible at the top and the Lasko logo on the front grille. The wide, stable base is also depicted.

3. SETUP

The Lasko 4440 Hybrid Fan typically requires minimal assembly. Follow these steps to prepare your fan for use:

- 1. Unpack the Fan:** Carefully remove the fan and all packaging materials from the box. Retain packaging for future storage if desired.
- 2. Base Assembly (if required):** Some models may require attaching the base. If your fan's base is separate, align the base sections and secure them to the bottom of the fan unit using the provided screws. Ensure the power cord passes through the designated channel in the base.
- 3. Placement:** Place the fan on a firm, level surface where it will not be easily knocked over. Ensure there is adequate space around the fan for proper airflow and oscillation. Avoid placing the fan directly against walls or furniture that could obstruct its air intake or output.
- 4. Power Connection:** Plug the fan's power cord into a standard 120-volt AC wall outlet. Ensure the outlet is in good condition and not overloaded.

4. OPERATING INSTRUCTIONS

Your Lasko 4440 Hybrid Fan can be operated using the control panel on the top of the unit or the included remote control.

Control Panel Functions:

- **Power Button (O/I):** Press to turn the fan ON or OFF.
- **Speed Button (I, II, III):** Press repeatedly to cycle through the three fan speeds: Low (I), Medium (II), and High (III).
- **Oscillation Button (↔):** Press to activate or deactivate the widespread oscillation feature. When active, the fan head will sweep from side to side.
- **Night Light Button ():** Press to turn the soft night light ON or OFF.

Remote Control:

The remote control duplicates all functions of the control panel, allowing for convenient operation from a distance. Ensure the batteries are correctly installed (batteries are typically included).

- Point the remote control directly at the fan's receiver window (usually located on the control panel).
- Press the corresponding buttons for Power, Speed, Oscillation, or Night Light.

5. MAINTENANCE

Regular maintenance helps ensure the longevity and efficient operation of your fan.

Cleaning:

- **Always unplug the fan before cleaning.**
- Use a soft cloth or a vacuum cleaner with a brush attachment to remove dust from the fan's grilles and exterior surfaces.
- Do not immerse the fan in water or allow water to drip into the motor housing.
- For stubborn dirt, wipe surfaces with a soft cloth dampened with a mild soap solution, then dry thoroughly.
- Do not use gasoline, benzene, paint thinner, or other harsh cleaners, as they may damage the fan's finish.

Storage:

When not in use for extended periods, store the fan in its original box or cover it to protect it from dust. Store in a cool, dry place.

Fuse Replacement:

This fan is equipped with a safety fuse located in the plug. If the fan fails to operate, the fuse may need replacement.

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
2. Open fuse cover. Slide open fuse access cover on top of attachment plug towards blades.
3. Remove fuse carefully.
4. Replace fuse only with 2.5 Amp, 125 Volt fuse.
5. Close fuse cover. Slide closed the fuse access cover on top of attachment plug.
6. If the new fuse blows, the fan may have an electrical fault and should be inspected by a qualified service

technician.

6. TROUBLESHOOTING

If your Lasko 4440 Hybrid Fan is not operating as expected, consult the following common issues and solutions:

- **Fan does not turn on:**

- Ensure the power cord is securely plugged into a working 120V outlet.
- Check the safety fuse in the plug (refer to Maintenance section for replacement).
- Verify that the power button on the control panel or remote is pressed.

- **Weak airflow:**

- Increase the fan speed setting.
- Ensure the fan grilles are not obstructed by dust or debris. Clean as per Maintenance instructions.
- Check that the fan is placed in an open area, not against a wall or furniture.

- **Fan is making unusual noise:**

- Ensure the fan is on a stable, level surface.
- Check for any foreign objects that may have entered the fan grilles. Unplug the fan before inspecting.
- If the noise persists, discontinue use and contact customer support.

- **Remote control is not working:**

- Ensure the remote control batteries are correctly installed and not depleted. Replace if necessary.
- Point the remote directly at the fan's receiver.
- Ensure there are no obstructions between the remote and the fan.

If the problem persists after attempting these troubleshooting steps, please contact Lasko customer support.

7. SPECIFICATIONS

Specification	Detail
Model Number	4440
Dimensions (L x W x H)	Approx. 12.25 x 12 x 8 inches (31.1 x 30.5 x 20.3 cm)
Weight	Approx. 13 lbs (5.9 kg)
Voltage	120 Volts
Number of Speeds	3
Controller Type	Remote Control, On-unit Buttons
Special Features	Oscillating, Portable, Night Light
Power Source	AC Power (Battery for Remote)
Color	Gray / Black

8. WARRANTY AND SUPPORT

Limited Warranty:

This Lasko 4440 Hybrid Fan comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal household use. It does not cover damage resulting from misuse, accident, neglect, unauthorized repair, or commercial use.

For warranty service, please retain your original purchase receipt as proof of purchase.

Customer Support:

If you have any questions, require assistance, or need to report a problem with your fan, please contact Lasko customer support. Contact information can typically be found on the Lasko official website or on the product packaging.

When contacting support, please have your model number (4440) and purchase information readily available.

© 2023 Lasko Products, LLC. All rights reserved.

Related Documents - 4440

	<p><u>Lasko 2511 Tower Fan with Remote Control - Operating Manual</u></p> <p>This document provides operating instructions, safety information, and warranty details for the Lasko 2511 36" Tower Fan with Remote Control. Learn how to assemble, operate, and maintain your fan for safe and efficient use.</p>
	<p><u>Lasko 5307 Oscillating Ceramic Tower Heater: User Manual, Safety Guide, and Warranty</u></p> <p>Comprehensive operating instructions, essential safety warnings, maintenance tips, and warranty information for the Lasko 5307 Oscillating Ceramic Tower Heater. Ensure safe and efficient use of your home comfort appliance.</p>
	<p><u>Lasko T36211 36" Tower Fan with Remote Control - User Manual and Safety Instructions</u></p> <p>Official user manual and safety guide for the Lasko T36211 36-inch Tower Fan with remote control. Covers assembly, operation, maintenance, troubleshooting, warranty, and customer support.</p>
	<p><u>Lasko 16" Oscillating Stand Fan Model 2521C User Manual and Safety Instructions</u></p> <p>Comprehensive user manual and safety instructions for the Lasko 16-inch Oscillating Stand Fan, Model 2521C. Includes assembly, operation, maintenance, and warranty information.</p>
	<p><u>Lasko CT16450 Oscillating Ceramic Tower Heater - Operating Manual and Safety Instructions</u></p> <p>Comprehensive operating manual and safety instructions for the Lasko CT16450 Oscillating Ceramic Tower Heater. Learn about safe operation, maintenance, troubleshooting, and warranty information.</p>



[Lasko U35105 Oscillating High Velocity Fan - Operating Manual and Safety Instructions](#)

Comprehensive operating manual and safety instructions for the Lasko U35105 Oscillating High Velocity Fan. Includes maintenance, troubleshooting, warranty information, and usage guidelines for residential use.