

Faithfull FAIFLICK

Faithfull Tyrolean Flicker Machine (FAIFLICK) Instruction Manual

Model: FAIFLICK

1. INTRODUCTION

The Faithfull Tyrolean Flicker Machine (Model FAIFLICK) is a hand-operated tool designed for applying Tyrolean and roughcast plaster materials to both interior and exterior walls. This machine offers an efficient and effective method for achieving textured wall finishes. Its robust stainless steel construction ensures durability and resistance to rust, providing a long service life.

This manual provides essential information for the safe and effective use of your Faithfull Tyrolean Flicker Machine, covering setup, operation, maintenance, and troubleshooting.

2. SAFETY INFORMATION

WARNING:

Always use appropriate personal protective equipment (PPE) when operating this machine, including eye protection, gloves, and respiratory protection. Handle the sprayer carefully to prevent injury. Follow all manufacturer's instructions for maintenance and disposal of materials. Ensure the work area is well-ventilated.

3. PRODUCT OVERVIEW AND KEY FEATURES

The Faithfull Tyrolean Flicker Machine is engineered for versatility and ease of use. Key features include:


- **Durable Stainless Steel Construction:** The casing and reducer plate are made from high-grade stainless steel, offering excellent rust prevention and a long operational life.
- **Adjustable Pressure Bar:** Allows for precise control over the texture of the applied coating, providing flexibility for various wall coating projects.
- **Easily Removable Reducer Plate:** Supplied with a convenient reducer plate for enhanced precision and efficiency when working on smaller areas or performing touch-up work.
- **Easy to Clean:** The comb roller can be easily removed from the machine for quick and hassle-free maintenance.
- **Versatile Application:** Ideal for applying Tyrolean and roughcast wall coatings on homes, garages, sheds, or other large surfaces, both indoors and outdoors.

KEY FEATURES



Adjustable Pressure Bar
Control over texture offering versatility on a variety of wall coating projects

Removable Comb Roller
Easy to withdraw for quick, hassle-free cleaning



Durable Stainless Steel Casing & Reducer Plate
Rust resistant and strong for long-lasting performance

Image: Key features of the Faithfull Tyrolean Flicker Machine, highlighting the removable comb roller, adjustable pressure bar, and durable stainless steel casing and reducer plate.

TEXTURE CONTROL



Fine



Medium



Heavy



Image: Visual representation of texture control options (Fine, Medium, Heavy) achievable with the Tyrolean Flicker Machine.

4. SETUP

1. **Unpack the Machine:** Carefully remove the Tyrolean Flicker Machine from its packaging. Inspect for any damage.
2. **Familiarize with Components:** Identify the main body, comb roller, adjustable pressure bar, and reducer plate.
3. **Install Reducer Plate (Optional):** For smaller areas or detailed work, attach the easy-fit reducer plate. This plate slides into position to narrow the application area.
4. **Adjust Pressure Bar:** The pressure bar controls the texture. Rotate the adjustment knob to set the desired texture. A tighter setting typically results in a finer texture, while a looser setting allows for a heavier, rougher finish.
5. **Prepare Material:** Ensure your Tyrolean or roughcast material is mixed according to its manufacturer's instructions to the correct consistency for spraying.



Supplied with an Easy-Fit Reducer Plate for Precision & Control on Small Area or Re-Touch Work

Image: The Tyrolean Flicker Machine shown with the easy-fit reducer plate installed, demonstrating its use for precision work.

5. OPERATING INSTRUCTIONS

1. **Fill the Hopper:** Pour the prepared Tyrolean or roughcast material into the machine's hopper. Do not overfill.
2. **Position the Machine:** Hold the machine firmly against the wall surface, ensuring it is level and at a consistent distance for even application.
3. **Operate the Handle:** Turn the handle steadily and continuously. The comb roller inside will pick up the material and flick it onto the wall, creating the desired textured finish.
4. **Maintain Consistency:** Move the machine across the wall in a controlled manner, overlapping slightly with previous passes to ensure uniform coverage.
5. **Adjust Texture During Application:** If needed, you can fine-tune the texture by adjusting the pressure bar during operation.
6. **Work in Sections:** For large areas, work in manageable sections to maintain a wet edge and avoid visible seams.



Effortlessly Apply Tyrolean & Roughcast on Inside & Outside Walls, Ensuring a Durable & Even Finish

Image: A person demonstrating the use of the Faithfull Tyrolean Flicker Machine to apply wall coating, ensuring a durable and even finish.

6. MAINTENANCE

Proper cleaning and maintenance will extend the life of your Faithfull Tyrolean Flicker Machine.

1. **Immediate Cleaning:** After each use, immediately empty any remaining material from the hopper.
2. **Disassemble for Cleaning:** The comb roller can be easily removed. Disassemble the machine as needed to access all parts that came into contact with the material.
3. **Wash Components:** Thoroughly wash all components with water, or a suitable cleaning agent recommended by your material manufacturer, until all residue is removed. Pay special attention to the comb roller and the inside of the hopper.
4. **Dry Thoroughly:** Allow all parts to dry completely before reassembling or storing to prevent rust and material buildup.
5. **Lubrication:** Periodically apply a light oil to moving parts, such as the handle mechanism, to ensure smooth

operation.

6. **Storage:** Store the machine in a clean, dry place away from extreme temperatures.



Image: A collage highlighting the material properties and ease of cleaning for the Faithfull Tyrolean Flicker Machine.

7. TROUBLESHOOTING

If you encounter issues with your Faithfull Tyrolean Flicker Machine, refer to the following common problems and solutions:

- **Uneven Application:**
 - **Cause:** Inconsistent speed of handle rotation or uneven distance from the wall.
 - **Solution:** Practice maintaining a steady rotation speed and a consistent distance from the surface. Ensure material consistency is correct.
- **Material Not Flicking Properly:**

- **Cause:** Material too thick or too thin; comb roller clogged; pressure bar setting incorrect.
 - **Solution:** Adjust material consistency. Clean the comb roller thoroughly. Adjust the pressure bar to a suitable setting for your material.
- **Machine Jamming:**
- **Cause:** Dried material buildup; foreign object in the mechanism.
 - **Solution:** Disassemble and thoroughly clean all parts. Ensure no foreign objects are present. Lubricate moving parts if necessary.

8. SPECIFICATIONS

Specification	Detail
Model Number	FAIFLICK
Brand	Faithfull
Material	Stainless Steel
Power Source	Hand-powered
Product Dimensions	26 x 18.5 x 27.5 cm
Item Weight	1.55 Kilograms
Recommended Use	Tyrolean and Roughcast wall covering material on both interior and exterior walls
Included Components	Reducer Plate, Pressure Bar

9. WARRANTY AND SUPPORT

The Faithfull Tyrolean Flicker Machine comes with a **5-year guarantee**, ensuring quality and reliability. For warranty claims or technical support, please refer to the retailer where the product was purchased or visit the official Faithfull Tools store online.



Image: Packaging of the Faithfull Flicker Machine, prominently displaying the 5-year guarantee.

For more information about Faithfull products, visit the [Faithfull Store](#).

© 2026 Faithfull Tools. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question