

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ideal Standard](#) /
- › [Ideal Standard A3914AA Moments Chrome Bathtub Faucet User Manual](#)

## Ideal Standard A3914AA

# Ideal Standard A3914AA Moments Chrome Bathtub Faucet

Model: A3914AA | Brand: Ideal Standard

### INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Ideal Standard A3914AA Moments chrome bathtub faucet. Please read this manual thoroughly before installation and use to ensure proper function and longevity of the product. Keep this manual for future reference.

### IMPORTANT SAFETY INFORMATION

- Always shut off the main water supply before beginning any installation or maintenance work.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any part of the installation, consult a qualified plumber.
- Do not use abrasive cleaners or harsh chemicals on the chrome finish, as this may damage the surface.
- This product is designed for bathtub use. Do not modify it for other applications.

### PACKAGE CONTENTS

Please check that all components are present before starting installation:

- Ideal Standard A3914AA Bathtub Faucet
- S-connections
- Installation hardware
- User Manual (this document)

## PRODUCT SPECIFICATIONS

<b>Brand:</b>	Ideal Standard
<b>Model Number:</b>	A3914AA
<b>Color:</b>	Chrome
<b>Finish:</b>	Chromed
<b>Material:</b>	Metal
<b>Installation Method:</b>	Wall Mount, Single Hole
<b>Number of Handles:</b>	1
<b>Spout Reach:</b>	204 mm
<b>Adjustable S-connections:</b>	137-163 mm
<b>Cartridge Type:</b>	Multiport Click cartridge with ceramic sealing rings
<b>Swivel Range:</b>	120 degrees
<b>Special Features:</b>	Foldable spout, Temperature control, Eco-function
<b>Product Dimensions:</b>	20 x 20 x 30 cm
<b>Weight:</b>	2 kg

## SETUP AND INSTALLATION


The Ideal Standard A3914AA faucet is designed for wall-mounted, single-hole installation. Follow these steps carefully:

- 1. Prepare the Installation Area:** Ensure the wall surface is clean and flat. Turn off the main water supply to prevent water damage.
- 2. Install S-connections:** The included S-connections are designed for concealed, sound-dampened installation. They are adjustable to an inter-axis distance of 137-163 mm. Securely fasten them to the wall water outlets.
- 3. Mount the Faucet:** Attach the faucet body to the S-connections using the provided installation hardware. Ensure a tight and leak-free connection.
- 4. Check for Leaks:** Once the faucet is securely mounted, slowly turn on the main water supply and check all connections for any signs of leakage. Tighten connections as necessary.

Modello: A3914

MOMENTS

Miscelatore monocomando esterno per vasca/doccia



#### Miscelatore esterno

Da completare con i componenti doccia.

Da completare con i componenti doccia.

Con deviatore automatico. Bocca d'erogazione GIREVOLE dotata di rompigitto Neoperl, raccordi a S da 1/2" regolabili per interasse da 137 a 163 mm. È dotato di cartuccia Multiport 40mm e dispositivo di limitazione della temperatura dell'acqua.

#### Finitura\*



#### Varianti

**DOPPIO COMANDO BORDO VASCA, CON EROGAZIONE DA COLONNA** **A3920**

**MISCELATORE MONOCOMANDO ESTERNO PER DOCCIA** **A3910**

**Figure 1:** A detailed view of the Ideal Standard A3914AA Moments chrome bathtub faucet, highlighting its sleek design and single lever control. This image provides a visual reference for the product's appearance.

A technical diagram (refer to the product packaging or manufacturer's website for visual reference) illustrates the precise dimensions and connection points of the A3914AA faucet. This diagram shows a total length of 294mm, a spout projection of 183mm, and an overall reach of 204mm. The S-connections are indicated as G 1/2" and are adjustable for an inter-axis distance between 137mm and 163mm. The diagram also details the 91mm drop for the shower outlet and the 120-degree swivel range of the spout, which is crucial for planning your installation.

## OPERATING INSTRUCTIONS

### Water Flow and Temperature Control

The A3914AA faucet features a single metal operating handle for controlling both water flow and temperature. Move the handle left or right to adjust the water temperature from cold to hot. Move the handle up or down to control the water flow intensity. The Multiport Click cartridge ensures smooth and precise control. An integrated warm water temperature regulation and eco-function are designed for efficient use.

### Foldable and Swivel Spout

The faucet is equipped with a foldable spout and an automatic diverter. The spout can be swiveled 120 degrees. To switch from bath filling to shower function, simply swivel the spout. When switched to the shower head, the spout can be fully integrated (folded) to provide more space in the bathtub. The spout features a Neoperl aerator for a smooth water stream.

## MAINTENANCE

### Cleaning the Chrome Finish

To maintain the lustrous chrome finish of your faucet, clean it regularly with a soft cloth and mild soap or a non-abrasive cleaner specifically designed for chrome. Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots. Avoid using abrasive sponges, scouring pads, or harsh chemical cleaners, as these can damage the finish.

### Aerator Maintenance

If water flow becomes restricted, the Neoperl aerator may need cleaning. Unscrew the aerator from the end of the spout, clean any debris or mineral deposits, and then reattach it securely.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
<b>Low Water Flow</b>	Clogged aerator; partially closed stopcock; low water pressure.	Clean the aerator. Ensure stopcocks are fully open. Check household water pressure.
<b>Leaks from Spout</b>	Worn cartridge; loose connections.	Tighten connections. If leak persists, the Multiport Click cartridge may need replacement. Contact a qualified plumber.
<b>Water Temperature Issues</b>	Incorrect cartridge setting; water heater issues.	Check the warm water temperature regulation setting on the cartridge. Ensure your water heater is functioning correctly.

If you encounter problems not listed here or if the suggested solutions do not resolve the issue, please contact Ideal Standard customer support or a qualified plumber.

## WARRANTY AND SUPPORT

Ideal Standard products are manufactured to high-quality standards and are covered by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Ideal Standard website. For technical support, spare parts, or service inquiries, please contact Ideal Standard customer service through their official channels.

**Manufacturer:** Ideal Standard

**Website:** [www.idealstandard.com](http://www.idealstandard.com) (Please check for your regional website)