

[Manuals.plus](#) /

› [TURNER](#) /

› Turner Minnesota Wild Paper Cube User Manual

TURNER 8080257

Turner Minnesota Wild Paper Cube User Manual

Model: 8080257

INTRODUCTION

Welcome to the user manual for the Turner Minnesota Wild Paper Cube. This document provides essential information for the proper use and care of your paper cube, ensuring its longevity and functionality as a desk accessory.

PRODUCT OVERVIEW

The Turner Minnesota Wild Paper Cube is a functional desk accessory designed for convenient note-taking and organization. It features the official Minnesota Wild team logo, making it a suitable item for fans.

- Contains 700 sheets of paper, providing ample supply for daily use.
- Features the Minnesota Wild team logo prominently displayed on all four sides of the cube.
- Compact dimensions: 3.5 inches x 3.5 inches x 3.5 inches (8.89 cm x 8.89 cm x 8.89 cm), suitable for any desk or workspace.



Image: The Turner Minnesota Wild Paper Cube, showcasing the team's distinctive logo on its sides. The cube is composed of numerous white paper sheets.

SETUP

The Turner Minnesota Wild Paper Cube requires no assembly or complex setup. Simply remove the paper cube from its packaging and place it on your desired flat and stable surface, such as a desk, table, or shelf.

OPERATING INSTRUCTIONS

To use the paper cube, gently pull a single sheet of paper from the top of the cube. The individual sheets are designed for easy detachment, allowing for quick access to paper for notes, reminders, or messages. No special tools or procedures are required for operation.

MAINTENANCE

The paper cube requires minimal maintenance to preserve its quality and appearance.

- Keep the paper cube in a dry environment to prevent moisture absorption, which can cause the paper to warp or stick together.
- Avoid exposing the cube to direct sunlight or harsh artificial lighting for prolonged periods, as this may lead to fading of the team logo.
- Once all sheets have been used, the cube is depleted and should be replaced.

TROUBLESHOOTING

Given the straightforward nature of this product, troubleshooting is rarely necessary. However, if you encounter minor issues, consider the following:

- **Issue:** Paper sheets are difficult to remove or tear unevenly.
 - **Solution:** *Ensure the cube is placed on a flat, stable surface. Gently pull sheets one at a time, applying even pressure. Avoid pulling at an extreme angle.*
- **Issue:** The team logo appears faded or discolored.
 - **Solution:** *This is typically due to prolonged exposure to light. Relocate the cube to an area with less direct sunlight or intense artificial light.*

SPECIFICATIONS

Feature	Detail
Brand	TURNER
Model Number	8080257
Manufacturer	Lang Holdings, Inc.
Color	White
Number of Sheets	700
Dimensions (L x W x H)	3.5 x 3.5 x 3.5 inches (8.89 x 8.89 x 8.89 cm)
Item Weight	453.59 g
Release Date	June 15, 2010

WARRANTY AND SUPPORT

For information regarding product warranty, return policies, or specific product support, please refer to the terms and conditions provided by the retailer from whom the product was purchased. Alternatively, you may contact the manufacturer directly using the contact information typically found on the product packaging or the manufacturer's official website.

Note: Specific warranty details are not provided within this user manual.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question