

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Elchim](#) /
- › [Elchim Classic 2001 High Pressure Hair Dryer Instruction Manual](#)

Elchim 220710010

Elchim Classic 2001 High Pressure Hair Dryer Instruction Manual

Model: 220710010 | Brand: Elchim

INTRODUCTION

The Elchim Classic 2001 High Pressure Hair Dryer is a professional-grade styling tool designed for efficient and quick hair drying. Featuring an Italian professional AC motor, this 1875-watt dryer offers high-pressure airflow and multiple heat and speed settings to achieve salon-quality results. This manual provides essential information for safe and effective use, maintenance, and troubleshooting.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of electrocution, fire, personal injury, or death:

- Do not use while bathing.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Always unplug this appliance immediately after using.
- Unplug this appliance before cleaning.
- Close supervision is necessary when this appliance is used by, on, or near children or invalids.
- Use this appliance only for its intended use as described in this manual.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.

- Do not direct hot air towards eyes or other heat-sensitive areas.
- Attachments may be hot during use. Allow them to cool before handling.
- Do not place appliance on any surface while it is operating.
- While using the appliance, keep your hair away from the air inlets.

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove the hair dryer and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Inspect:** Check the hair dryer for any visible damage. Ensure the power cord and plug are intact.
3. **Attach Concentrator Nozzle:** The Elchim Classic 2001 comes with an optimized precision nozzle. Align the nozzle with the front of the dryer and push it firmly into place. This nozzle helps to direct airflow for precise styling.
4. **Power Connection:** Plug the hair dryer into a standard 110-volt electrical outlet. Ensure the outlet is easily accessible.



Image: The Elchim Classic 2001 High Pressure Hair Dryer in black, shown with its concentrator nozzle attached. This image illustrates the main product and its primary accessory.

Your browser does not support the video tag.

Video: An official Elchim video demonstrating the unboxing and features of the Elchim Classic 2001 Hair Dryer, including the attachment of the concentrator nozzle and a brief overview of its use.

OPERATING INSTRUCTIONS

The Elchim Classic 2001 features intuitive controls for customized styling.

Power and Speed Settings

The hair dryer has two speed settings:

- **Low Speed:** For gentle drying or styling.
- **High Speed:** For rapid drying and powerful airflow.

To adjust the speed, use the lower switch on the handle.

Heat Settings

The hair dryer offers three temperature settings:

- **Cool:** For setting styles and adding shine.
- **Warm:** For general drying.
- **Hot:** For quick drying and intense styling.

To adjust the temperature, use the upper switch on the handle.



Image: A close-up view of the Elchim Classic 2001 Hair Dryer's handle, showing the two rocker switches for controlling speed and temperature settings.

Using the Concentrator Nozzle

The included concentrator nozzle is designed to focus the airflow, making it ideal for precision styling, straightening, or working with a round brush. Direct the concentrated airflow along the hair shaft from roots to ends.

Your browser does not support the video tag.

Video: An official Elchim video demonstrating the powerful airflow and quick drying capabilities of the Elchim Classic 2001 Hair Dryer.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your Elchim hair dryer.

Cleaning the Air Filter

The rear air filter should be cleaned regularly to prevent lint and hair buildup, which can reduce airflow and efficiency.

1. **Unplug:** Always unplug the hair dryer from the electrical outlet before cleaning.
2. **Remove Filter:** Gently twist or pull off the rear filter cover.
3. **Clean:** Remove any accumulated lint or hair from the filter using a soft brush or cloth.

4. **Reattach Filter:** Place the clean filter cover back onto the dryer and secure it.



Image: A rear view of the Elchim Classic 2001 Hair Dryer, highlighting the air intake grille and filter area, which requires regular cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dryer does not turn on.	No power supply.	Check if the plug is securely inserted into the outlet. Check the circuit breaker.
Reduced airflow.	Clogged air filter.	Clean the rear air filter as described in the Maintenance section.
Dryer overheats and shuts off.	Overheating protection activated due to blocked airflow or prolonged use.	Unplug the dryer and allow it to cool down for several minutes. Clean the air filter. Ensure proper ventilation during use.

SPECIFICATIONS

- **Model Number:** 220710010
- **Wattage:** 1875 watts (1700-2000 watt range)
- **Voltage:** 110 Volts
- **Power Source:** Corded Electric
- **Product Dimensions:** 9 x 3.75 x 8.75 inches
- **Item Weight:** 1.1 Pounds
- **Motor Type:** Italian professional AC motor (duration over 2,000 hours)
- **Speed Settings:** 2
- **Temperature Settings:** 3
- **Included Components:** Concentrator, Diffuser
- **Material Type:** Ceramic

- **Manufacturer:** Elchim
- **GTIN/UPC:** 836793002118



Image: A close-up of the Elchim Classic 2001 Hair Dryer's body, showing a label with technical specifications and model information.

WARRANTY AND SUPPORT

The Elchim Classic 2001 Hair Dryer comes with a **Limited One Year Manufacturer Warranty**. Additionally, Elchim offers a **Lifetime Warranty** with repair and replacement services, ensuring long-term reliability for your professional styling tool. For warranty claims or support, please contact Elchim customer service. For further assistance or inquiries, please visit the official Elchim website or contact their customer support.