

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Weston](#) /

› [Weston Pro 2300 Commercial Grade Vacuum Sealer Instruction Manual](#)

Weston 65-0201

Weston Pro 2300 Commercial Grade Vacuum Sealer Instruction Manual

Model: 65-0201

INTRODUCTION

This instruction manual provides detailed information on the safe and efficient operation, maintenance, and troubleshooting of your Weston Pro 2300 Commercial Grade Vacuum Sealer. Please read this manual thoroughly before using the appliance to ensure proper function and longevity.

The Weston Pro 2300 is designed for preserving food by removing air from specially designed bags and sealing them, extending freshness and preventing freezer burn. Its robust construction and powerful motor are built for continuous, repetitive use.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.

- Read all instructions before operating the vacuum sealer.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- This product is for household use only.
- Proposition 65 Warning: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

SETUP AND INITIAL USE

Unpacking

Carefully remove the vacuum sealer from its packaging. Inspect the unit for any signs of damage. Retain the packaging for future storage or transport.



Figure 1: Front view of the Weston Pro 2300 Commercial Grade Vacuum Sealer.

Placement

Place the vacuum sealer on a stable, flat, and dry surface. Ensure there is adequate space around the unit for ventilation, especially around the fan-cooled motor area.

Power Connection

The unit operates on 120 Volts and has a wattage of 935 watts. Connect the detachable power cord to the appliance and then to a standard 120V AC electrical outlet. The power cord can be stored in the convenient compartment at the back of the unit when not in use.



Detachable power cord with convenient storage compartment

Figure 2: Rear view illustrating the detachable power cord and its storage compartment.

The unit features an easy-to-access 10 Amp fuse for protection. Ensure the fuse is properly seated before operation.

SIMPLE ONE-TOUCH OPERATION

PRESERVE FOOD WITH THE TOUCH OF A BUTTON OR
USE THE MANUAL OPTION FOR SOFT OR DELICATE ITEMS




Figure 3: Detail of the 10 Amp fuse and power cord port.

OPERATING INSTRUCTIONS

The Weston Pro 2300 offers both automatic and manual sealing modes for versatile food preservation.



**EASY-TO-ACCESS
10 AMP FUSE**
AND 6 FOOT DETACHABLE CORD

Figure 4: Control panel with LED indicators and operation buttons.

Preparing Bags

Use vacuum sealer bags specifically designed for food preservation. The Pro 2300 features an extra-long 15-inch (38 cm) seal bar, allowing it to seal bags up to 15 inches wide. Ensure the bag is clean and dry at the sealing area.



Figure 5: Detail of the extra-wide 5mm seal bar, designed for strong, dependable seals.

Automatic Sealing Mode

1. Place the open end of the bag into the vacuum channel, ensuring it lies flat across the sealing bar. The transparent acrylic lid allows for precise bag alignment.
2. Close the lid firmly.
3. Press the **START** button. The unit will automatically begin the vacuum process, indicated by the **VACUUM** LED.
4. Once the desired vacuum level is reached, the unit will automatically switch to sealing, indicated by the **SEAL** LED.
5. After sealing, the unit will release the vacuum and the **COOL** LED may illuminate briefly. Open the lid and remove the sealed bag.

935 WATTS OF POWER

FAN-COOLED MOTOR FOR REPETITIVE USE WITHOUT OVERHEATING



Figure 6: The vacuum sealer in operation, preserving various food items.

Manual Seal Mode

The manual seal mode provides greater control, ideal for delicate or soft foods where full vacuum pressure might cause crushing or liquid extraction.

1. Place the open end of the bag into the vacuum channel.
2. Close the lid firmly.
3. Press the **START** button to begin vacuuming.
4. Monitor the vacuum process through the transparent lid. When the desired amount of air has been removed (before liquids are drawn into the vacuum chamber for moist foods), press the **MANUAL SEAL** button. This will immediately stop the vacuum and initiate the sealing process.
5. The **SEAL** LED will illuminate. Once sealing is complete, the unit will release the vacuum. Open the lid and remove the sealed bag.

To stop any operation at any time, press the **STOP** button.



Figure 7: Examples of food items successfully vacuum-sealed using the Weston Pro 2300.

CARE AND MAINTENANCE

Proper care and maintenance will ensure the longevity and optimal performance of your Weston Pro 2300 Vacuum Sealer.

Cleaning

Always unplug the unit before cleaning. The stainless steel housing is durable and easy to clean. Wipe down the exterior with a damp cloth and mild detergent. Do not use abrasive cleaners or immerse the unit in water.



Figure 8: The stainless steel housing is designed for durability and easy cleaning.

Clean the vacuum channel and sealing bar regularly. If liquids are accidentally drawn into the vacuum chamber, clean it immediately with a damp cloth. While the unit is designed to handle some moisture, excessive liquid can affect performance and hygiene. Ensure all parts are dry before next use.

Seal Bar and Gaskets

Periodically inspect the sealing bar and rubber gaskets for any debris or damage. A clean and intact sealing bar and gasket are crucial for a proper seal. Replace gaskets if they show signs of wear or cracking.

Motor Cooling

The fan-cooled motor is designed for continuous, repetitive use without overheating. Ensure the ventilation openings are not blocked during operation.

TROUBLESHOOTING

If you encounter issues with your vacuum sealer, refer to the following common problems and their solutions:

Problem	Possible Cause	Solution
Unit does not power on.	No power to the unit; Fuse blown.	Check if the power cord is securely plugged into the unit and the outlet. Verify the outlet is functional. Check and replace the 10 Amp fuse if necessary.
No vacuum or weak vacuum.	Lid not closed properly; Bag not positioned correctly; Gaskets are dirty or damaged; Vacuum channel is wet.	Ensure the lid is firmly closed and latched. Reposition the bag so it lies flat within the vacuum channel. Clean the gaskets and vacuum channel. Ensure the vacuum channel is dry.

Problem	Possible Cause	Solution
Bag does not seal properly (leaks).	Seal bar is dirty or damaged; Bag material is unsuitable; Moisture in the sealing area; Bag is wrinkled.	Clean the sealing bar. Ensure you are using proper vacuum sealer bags. Make sure the sealing area of the bag is dry. Smooth out any wrinkles in the bag before sealing. Ensure the 5mm seal bar is clean and free of debris.
Liquids are drawn into the vacuum chamber.	Excessive vacuum for moist foods; Bag overfilled.	Use the Manual Seal mode to control vacuum pressure for moist or delicate foods. Do not overfill bags; leave sufficient space from the top. Clean the vacuum chamber immediately after such incidents.
Unit overheats or stops during prolonged use.	Ventilation blocked; Continuous heavy use beyond design limits.	Ensure ventilation openings are clear. While designed for continuous use, allow the unit to cool down if it feels excessively hot or if performance degrades.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Weston
Model Number	65-0201
Material	Stainless Steel
Color	Commercial Grade Pro 2300 Stainless Steel
Product Dimensions (L x W x H)	23"L x 15.3"W x 9"H
Item Weight	22 Pounds
Power Source	Corded Electric
Operation Mode	Semi-Automatic
Wattage	935 watts
Voltage	120 Volts
UPC	834742005913
Seal Bar Width	15 inches (38 cm)
Seal Bar Thickness	5mm

WARRANTY AND SUPPORT

Warranty Information

Specific warranty details for the Weston Pro 2300 Commercial Grade Vacuum Sealer are typically provided with the product packaging or can be found on the official Weston website. Please retain your proof of purchase for warranty claims.


Customer Support

For technical assistance, replacement parts, or any inquiries regarding your Weston product, please contact Weston customer support. Refer to the official Weston website or product packaging for the most current contact information. An official User Manual PDF is available for download: [Download User Manual \(PDF\)](#)

© 2024 Weston Brands. All rights reserved.

Related Documents - 65-0201

	<p>Weston Professional Advantage Vacuum Sealer 65-0501-W User Manual and Guide</p> <p>This comprehensive user manual for the Weston Professional Advantage Vacuum Sealer (Model 65-0501-W) provides detailed instructions on operation, safety, maintenance, and food preservation techniques. Learn how to extend food freshness and reduce waste with this essential kitchen appliance.</p>
	<p>Weston Vacuum Sealer 65-1601-W: Use and Care Guide</p> <p>Comprehensive guide for the Weston 65-1601-W Vacuum Sealer, covering setup, operation, maintenance, troubleshooting, and warranty information.</p>
	<p>Weston PRO-3500 Stainless Steel Vacuum Sealer: Use and Care Guide</p> <p>Comprehensive guide for the Weston PRO-3500 Stainless Steel Vacuum Sealer, covering important safeguards, component lists, operation instructions, cleaning, maintenance, and warranty information.</p>
	<p>Weston PRO-2500 Chamber Vacuum Sealer: Use and Care Manual</p> <p>This manual provides comprehensive instructions for operating and maintaining the Weston PRO-2500 Chamber Vacuum Sealer, covering setup, usage, safety guidelines, and troubleshooting for effective food preservation.</p>



[Weston PRO-1000 Stainless Steel 10 Tray Food Dehydrator User Manual](#)

Comprehensive user manual for the Weston PRO-1000 Stainless Steel 10 Tray Food Dehydrator, covering safety, operation, cleaning, assembly, and food preparation tips. Model 74-1001-W.



[Weston Commercial Grade Electric Meat Grinder and Sausage Stuffer Manual & Recipes](#)

Comprehensive user manual, safety instructions, recipes, and component list for the Weston Commercial Grade Electric Meat Grinder and Sausage Stuffer models #8, #12, #22, and #32. Includes warranty information, food safety guidelines, and assembly/operation instructions.