

[Manuals.plus](#) /

› [Audi](#) /

› 2009 Audi A6 Owner's Manual and Operating Instructions

Audi A6

2009 Audi A6 Owner's Manual

Your comprehensive guide to operating and maintaining your Audi A6.

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your 2009 Audi A6. It contains detailed instructions on vehicle features, controls, maintenance procedures, and important safety warnings. Please read this manual thoroughly to familiarize yourself with your vehicle's capabilities and to ensure a safe driving experience.

Keep this manual in your vehicle for quick reference. If you sell your vehicle, please ensure this manual remains with it for the new owner.



Image: Front cover of the official 2009 Audi A6 Owner's Manual. This document serves as the primary reference for all vehicle operations and features.

2. SETUP AND INITIAL FAMILIARIZATION

Before driving your Audi A6, it is important to familiarize yourself with its basic controls and settings. This section covers initial setup procedures and key components.

2.1 Driver's Cockpit Overview

- **Ignition Switch:** Insert the key and turn to start the engine.
- **Steering Wheel Controls:** Buttons for audio, phone, and cruise control.
- **Instrument Cluster:** Displays speed, RPM, fuel level, and warning lights.
- **Seat Adjustment:** Adjust seat position, height, and lumbar support for optimal comfort and safety.

2.2 Lighting and Visibility

- **Headlight Switch:** Located on the dashboard, controls headlights, parking lights, and fog lights.
- **Wiper/Washer Stalk:** Controls front and rear wipers, and windshield washer fluid.
- **Mirror Adjustment:** Use the control knob on the driver's door to adjust side mirrors.

3. OPERATING YOUR AUDI A6

This section details the procedures for starting, driving, and stopping your vehicle, along with explanations of key driving

features.

3.1 Starting and Driving

1. Ensure the transmission is in Park (P) or Neutral (N).
2. Press the brake pedal firmly.
3. Insert the key into the ignition and turn it to the START position. Release the key once the engine starts.
4. Select the desired gear (Drive, Reverse) and release the parking brake.

3.2 Transmission and Driving Modes

The 2009 Audi A6 features an automatic transmission with various driving modes. Consult your main owner's manual for detailed information on specific modes like Sport mode or manual shifting options.

3.3 Climate Control

The automatic climate control system allows you to set and maintain a desired temperature in the cabin. Use the temperature dials and fan speed controls to adjust settings. The AUTO function optimizes airflow and temperature distribution.

4. INFOTAINMENT/MMI OPERATING INSTRUCTIONS

Your Audi A6 is equipped with the Multi Media Interface (MMI) system, which controls audio, navigation, communication, and vehicle settings. This section provides a general overview of its operation.



Image: Front cover of the dedicated Infotainment/MMI Operating Instructions manual for the 2009 Audi A6. This manual provides in-depth

4.1 MMI Control Panel

The MMI control panel, typically located on the center console, features a central control knob, surrounding function buttons (e.g., RADIO, MEDIA, NAV, TEL, CAR), and selection buttons. Use the central knob to navigate menus displayed on the MMI screen.

4.2 Audio System

- **Radio:** Select RADIO to access AM/FM bands and store presets.
- **Media:** Select MEDIA to play audio from CD/DVD, SD cards, or external devices connected via AUX input.

4.3 Navigation System

If equipped, the navigation system allows you to input destinations and receive turn-by-turn directions. Access this function via the NAV button on the MMI control panel.

4.4 Telephone (Bluetooth)

Pair your compatible mobile phone via Bluetooth to make and receive calls hands-free. Refer to the MMI manual for detailed pairing instructions.

5. MAINTENANCE

Regular maintenance is crucial for the longevity, safety, and performance of your Audi A6. Adhere to the recommended service intervals outlined in your service schedule booklet.

5.1 Routine Checks

- **Engine Oil Level:** Check regularly, ideally before long journeys.
- **Coolant Level:** Ensure it is between the MIN and MAX marks.
- **Brake Fluid Level:** Check periodically.
- **Tire Pressure:** Maintain correct tire pressure as specified on the driver's side door jamb or in the manual.
- **Wiper Blades:** Replace if streaking or chattering occurs.

5.2 Service Intervals

Your Audi A6 requires scheduled maintenance at specific mileage or time intervals. These services include oil changes, filter replacements, fluid checks, and inspections of critical components. Refer to your service schedule for exact details.

5.3 Tire Care

Regularly inspect tires for wear, damage, and proper inflation. Rotate tires according to the recommended schedule to ensure even wear and extend tire life.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your Audi A6 and provides basic troubleshooting steps.

6.1 Warning Lights

- **Check Engine Light:** If illuminated, it indicates an engine or emissions system fault. Consult a qualified service technician.

- **Oil Pressure Warning:** Stop the vehicle immediately and check the oil level. Do not drive if the light remains on.
- **Brake System Warning:** Indicates a fault in the brake system. Drive cautiously to a service center or have the vehicle towed.

6.2 Engine Not Starting

- Check if the transmission is in Park (P) or Neutral (N).
- Ensure the battery is charged. Look for dim lights or slow cranking.
- Verify there is sufficient fuel in the tank.

6.3 Flat Tire

Refer to your main owner's manual for instructions on how to safely change a flat tire using the spare tire and tools provided with your vehicle.

7. SPECIFICATIONS

Key specifications for the 2009 Audi A6 are provided below. For detailed technical data, refer to the complete owner's manual.

Specification	Detail
ASIN	B001HBX52Q
Publisher	Audi
Publication date	January 1, 2009
Edition	First Edition
Language	English

8. WARRANTY AND SUPPORT

Your 2009 Audi A6 comes with a manufacturer's warranty. Details regarding coverage, terms, and conditions are provided in a separate warranty booklet.



Image: Front cover of the USA Warranty & Maintenance manual for 2009 Audi Models. This document contains specific warranty terms and recommended maintenance schedules.

8.1 Warranty Information

The warranty covers defects in materials or workmanship under normal use and service. Specific components and durations may vary. Please consult the 'USA Warranty & Maintenance' booklet for complete details on your vehicle's warranty.

8.2 Customer Support

For further assistance, service appointments, or technical inquiries, please contact your authorized Audi dealership. They have trained technicians and genuine Audi parts to ensure your vehicle receives the best care.

You can also visit the official Audi website for additional resources and support information.

© 2009 Audi. All rights reserved. Information subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B001HBX52Q>

More documents and user manuals: **<https://manuals.plus/>**