

- Manuals.plus /
- › Escali /
- › Escali US180B Ultra Slim Digital Bathroom Scale User Manual

Escali US180B

Escali US180B Ultra Slim Digital Bathroom Scale User Manual

Model: US180B | Brand: Escali

INTRODUCTION

The Escali US180B Ultra Slim Digital Bathroom Scale is designed for accurate body weight measurement with a sleek, modern aesthetic. Its ultra-slim profile and instant-on technology provide a convenient and reliable weighing experience. The large blue backlit display ensures clear readability in various lighting conditions.



Figure 1: Escali US180B Ultra Slim Digital Bathroom Scale.

WHAT'S IN THE BOX

- Escali US180B Ultra Slim Digital Bathroom Scale
- 4 AAA Batteries (pre-installed or included separately)

KEY FEATURES

- **Ultra Slim Design:** Easy to step on and provides a low center of gravity for enhanced stability.
- **Instant On Technology:** Automatically activates the scale the moment you step onto the platform.
- **Easy-to-Read Backlit Display:** The bright blue backlight ensures clear visibility of weight measurements in any light condition.
- **Display Hold Feature:** Keeps the weight measurements visible for 10 seconds after they are first displayed, allowing ample time to read.

- **Automatic Shut-off:** Conserves and extends battery life by turning off the scale when not in use.
- **High Capacity:** Supports up to 400 lb (180 kg).

- ① **Easy to Read**
Back-light Display
- ② **Modern Design**
Stainless Steel Accent
- ③ **Extended Battery Life**
Instant-on & Automatic-off
- ④ **Ultra Slim Design**
Safe and Stable Platform



Figure 2: Overview of key features.

SETUP

1. Battery Installation

The scale requires 4 AAA batteries. These are typically included. Open the battery compartment on the underside of the scale and insert the batteries, ensuring correct polarity (+/-) as indicated.

2. Placement

For accurate readings, place the scale on a hard, flat surface. Avoid placing it on carpet or uneven flooring, as this can affect measurement accuracy.

3. Initial Use / Calibration

Before the first use or after moving the scale, it is recommended to calibrate it. Simply step onto the scale briefly, then step off. The display will show '0.0' or similar, indicating it's ready for use. This process ensures the scale is properly zeroed.

OPERATING INSTRUCTIONS

1. Taking a Measurement

1. Ensure the scale is on a hard, flat surface.
2. Gently step onto the center of the scale platform. The scale will automatically turn on.
3. Stand still until your weight is displayed and locks on the screen. The display will hold the reading for approximately 10 seconds before automatically turning off.



Figure 3: Taking a weight measurement.

2. Changing Units

The Escali US180B scale can display weight in pounds (lb), kilograms (kg), or stones (st). To change the unit, locate the unit conversion button on the underside of the scale (usually near the battery compartment). Press this button to cycle through the

available units.

Measuring Units



Figure 4: Display showing available measuring units.

3. Product Overview Video

Your browser does not support the video tag.

Video 1: An overview of the Escali US180B Ultra Slim Bathroom Scale, demonstrating its features and ease of use.

MAINTENANCE

1. Cleaning

Clean the scale with a damp cloth and mild detergent. Do not use abrasive cleaners or immerse the scale in water. Wipe dry immediately after cleaning.

2. Battery Care

If the scale is not going to be used for an extended period, remove the batteries to prevent leakage and damage. Replace

batteries when the display indicates low power or becomes dim.

3. Storage

Store the scale in a cool, dry place. Avoid extreme temperatures and direct sunlight. Do not store anything on top of the scale, as this can affect its calibration.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Inaccurate or inconsistent readings	Scale on uneven surface (e.g., carpet); Scale not calibrated; User movement during measurement.	Place scale on a hard, flat surface. Step on and off the scale to re-calibrate. Stand still and centered on the scale.
Display not turning on	Low or dead batteries; Incorrect battery installation.	Replace all 4 AAA batteries. Ensure batteries are inserted with correct polarity.
"Lo" or "Err" message on display	Low batteries ("Lo"); Overload or error ("Err").	Replace batteries. Ensure weight does not exceed 400 lb (180 kg). Step off the scale and try again.

SPECIFICATIONS

Feature	Detail
Model Number	US180B
Brand	Escali
Product Dimensions	13 x 1.5 x 13 inches
Weight	2 Pounds
Capacity	400 lb (180 kg)
Display Type	Backlit Digital LCD
Power Source	4 AAA batteries (included)
Color	Black with Stainless Steel Accent



Figure 5: Product Dimensions.

WARRANTY & SUPPORT

Escali products are designed for durability and accuracy. For specific warranty information, product registration, or technical support, please visit the official Escali website or refer to the documentation included with your purchase. You can also refer to the official PDF user manual for more detailed information:[Official User Manual \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B001HL001K>

More documents and user manuals: <https://manuals.plus/>