PEET M97-FSB

PEET Original 2-Shoe Electric Dryer Instruction Manual

Model: M97-FSB

Introduction

The PEET Original 2-Shoe Electric Dryer is designed to gently and effectively dry footwear, removing moisture and odors. This silent, energy-efficient dryer utilizes a patented DryPort system to circulate air, preserving the life of your footwear and gear.
This manual provides essential information for the safe and efficient operation and maintenance of your PEET Original Dryer.

Safety Information

- Always place the dryer on a flat, stable surface.
- Ensure the power cord is not damaged or pinched.
- Do not immerse the dryer in water or other liquids.
- Keep out of reach of children and pets.
- Do not block the air vents on the base or the DryPorts.
- This appliance is for drying footwear and gear only. Do not use for other purposes.
- Unplug the unit from the electrical outlet when not in use or before cleaning.

Product Components

The PEET Original 2-Shoe Electric Dryer consists of the following main components:

- Base Unit with heating element and air vents.
- Two AirChambers (vertical tubes).
- Two DryPorts (angled tops for footwear).
- Power Cord.




Image: The PEET Original 2-Shoe Electric Dryer with a pair of boots being dried. This image illustrates the assembled unit with footwear in place.

How It Works: Convection Drying

The PEET Original Dryer utilizes a silent convection heating process to dry footwear effectively and safely. This method ensures gentle drying without damaging materials.

1. **Air Intake:** Air is drawn through the vents located at the base of the unit.
2. **Warming:** The air is gently warmed by the internal heating element.
3. **Circulation:** The warm air naturally rises up through the AirChamber tubes and into the footwear placed on the DryPorts.
4. **Drying:** This continuous circulation of warm air removes moisture from the inside of the footwear, eliminating dampness and odors.



Image: A diagram showing how air is drawn into the base, warmed, and then circulates up through the tubes to dry footwear by convection.

Setup Instructions

1. **Unpack the Unit:** Carefully remove all components from the packaging.
2. **Assemble the Dryer:**
    - Insert the two AirChamber tubes into the designated openings on the base unit. Ensure they are securely seated.
    - Place the two DryPort tops onto the AirChamber tubes. The angled openings should face downwards to allow footwear to rest properly.
3. **Position the Dryer:** Place the assembled dryer on a flat, stable surface in an area with adequate ventilation.
4. **Connect to Power:** Plug the power cord into a standard 120V US electrical outlet. The unit does not have an on/off switch or indicator light; it begins operating silently once plugged in.



Image: The PEET Original 2-Shoe Electric Dryer, showing its compact design and two drying ports, ready for setup.

Operating Instructions

The PEET Original Dryer operates silently using gentle convection heat to dry footwear from the inside out. This process is safe for all materials and helps eliminate moisture, odor, and mildew.

1. **Prepare Footwear:** For best results, remove any excess dirt or debris from your footwear before placing it on the dryer.
2. **Place Footwear:** Invert your shoes or boots and place them over the DryPort tubes. Ensure the openings of the footwear are positioned over the tubes, allowing air to circulate freely into the toe area.
3. **Drying Process:** The dryer will begin to gently warm and circulate air. Drying typically occurs overnight (8-12 hours) for most footwear. Heavily saturated items may require longer.
4. **Continuous Operation:** The unit is designed for continuous, always-on operation. You can leave it plugged in 24/7 to ensure your footwear is always dry and ready.
5. **Optional Attachments:** The PEET Original Dryer is compatible with various attachments (sold separately) for drying helmets, gloves, mittens, and taller boots. Refer to the attachment's specific instructions for use.



Image: A pair of work boots placed upside down on the PEET dryer's tubes for drying.



Image: The PEET dryer demonstrating its versatility with optional attachments for drying sneakers and gloves, alongside boots.

Maintenance

The PEET Original Dryer requires minimal maintenance to ensure long-lasting performance.

- **Cleaning:** Periodically wipe the exterior of the dryer with a damp cloth. Do not use abrasive cleaners or immerse the unit in water. Ensure the unit is unplugged before cleaning.
- **Storage:** When not in use for extended periods, unplug the dryer and store it in a dry, cool place.
- **Inspection:** Regularly inspect the power cord and the unit for any signs of damage. If damage is found, discontinue use and contact customer support.

Troubleshooting

If you encounter issues with your PEET Original Dryer, refer to the following common solutions:

Problem	Possible Cause	Solution
Dryer does not seem to be working (no sound, no indicator light).	The PEET Original Dryer operates silently and does not have an indicator light or on/off switch. It uses gentle convection heat.	This is normal operation. Ensure the unit is plugged into a live outlet. You may feel a slight warmth from the base after some time.
Footwear is not drying effectively.	◦ Footwear is extremely wet. ◦ DryPorts are not properly inserted into footwear. ◦ Ambient room temperature is too low.	◦ Allow more drying time (up to 24 hours for very wet items). ◦ Ensure footwear openings are fully over the DryPorts. ◦ Use the dryer in a room with a moderate temperature.
Unit feels too hot or shows signs of melting.	Overheating due to blocked vents or internal malfunction.	Immediately unplug the unit. Do not use it again. Contact PEET customer support for assistance.

Specifications

Feature	Detail
Model Number	M97-FSB
Power Consumption	36W (120V US standard plug)
Dimensions (L x W x H)	9.5" x 9.5" x 22"
Weight	2.5 lbs
Drying Method	Silent Convection
Compatibility	Safe for leather, rubber, neoprene, vinyl, canvas, synthetics, fleece, microfiber. Compatible with PEET Helmet DryPort, Glove DryPort, Mitten DryPort, and 12-inch Boot Extension attachments (sold separately).
Origin	Made in the USA

Warranty and Support

The PEET Original Dryer comes with a **25-year warranty**. To ensure coverage, it is recommended to register your product within 10 days of purchase.
For warranty claims, technical support, or inquiries about optional attachments, please visit the official PEET website or contact their customer service department.
Contact Information: Refer to the product packaging or the official PEET website for the most current contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question