

Schonbek 1242-76

Schonbek Bagatelle Collection 10 1/2" Crystal Ceiling Light Instruction Manual

Model: 1242-76

1. INTRODUCTION

Thank you for choosing the Schonbek Bagatelle Collection 10 1/2" Crystal Ceiling Light. This fixture is designed to provide elegant illumination for various indoor spaces. This manual contains important information regarding the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before beginning installation and retain them for future reference.



Figure 1: Full view of the Schonbek Bagatelle Collection Crystal Ceiling Light.

2. IMPORTANT SAFETY INFORMATION

WARNING: Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing. Consult a qualified electrician if you are unsure about the installation process.

- Read all instructions carefully before proceeding.
- Ensure all electrical connections comply with local codes and ordinances, as well as the National Electric Code (NEC).
- Do not install this fixture in wet or damp locations. This product is designed for indoor use only.
- Use only bulbs of the specified type and wattage (B10-3, 40W Max). Exceeding the maximum wattage can cause overheating and damage to the fixture or create a fire hazard.
- Handle crystal components with care to prevent breakage.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

3. PACKAGE CONTENTS

Carefully unpack your fixture and check that all parts are included. If any parts are missing or damaged, do not attempt to assemble or install the fixture. Contact customer service for assistance.

- Schonbek Bagatelle Crystal Ceiling Light Fixture (1)
- Mounting Hardware Kit (1)
- Installation Instructions (This manual)

Note: Light bulbs (B10-3, 40W Max) are **not included** and must be purchased separately.

4. SETUP AND INSTALLATION

This fixture is designed for semi-flush mount installation. No assembly is required for the main fixture body, but crystal elements may need to be attached.

Tools Required (Not Included):

- Phillips Head Screwdriver
- Wire Strippers
- Electrical Tape
- Ladder

Installation Steps:

1. **Turn Off Power:** Locate the circuit breaker or fuse box that controls the power to the ceiling outlet box. Turn off the power completely before starting installation.
2. **Prepare Mounting:** If replacing an existing fixture, carefully remove it. Attach the mounting bracket (from the hardware kit) to the ceiling outlet box using the provided screws. Ensure the bracket is securely fastened.
3. **Make Electrical Connections:**
 - Connect the bare copper ground wire from the fixture to the ground wire from the outlet box (usually bare copper or green) using a wire nut.
 - Connect the white wire from the fixture to the white (neutral) wire from the outlet box using a wire nut.
 - Connect the black wire from the fixture to the black (hot) wire from the outlet box using a wire nut.
 - Secure all wire connections with electrical tape.
4. **Mount the Fixture:** Carefully lift the fixture and align the holes on the fixture canopy with the screws on the mounting bracket. Secure the fixture to the mounting bracket using the decorative nuts or screws provided.
5. **Install Bulbs:** Screw in three B10-3 base bulbs (max 40W each) into the sockets. Do not overtighten.
6. **Attach Crystal Elements:** If any crystal elements are packaged separately, carefully attach them according to the diagrams provided with the fixture (if applicable). Refer to Figure 2 for an example of crystal detailing.



Figure 2: Detailed view of the crystal elements and bronze finish.

- **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker or fuse box. Test the light fixture.



Figure 3: The Schonbek Bagatelle Ceiling Light installed in an indoor setting.

5. OPERATING INSTRUCTIONS

The Schonbek Bagatelle Ceiling Light is operated by a standard wall toggle switch (not included). Once installed and powered, simply use the wall switch to turn the light fixture on or off.

6. MAINTENANCE

Cleaning:

- Always disconnect power before cleaning.
- To clean the crystal components, use a soft, lint-free cloth dampened with a mild glass cleaner or distilled water. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish and crystal.
- For the metal finish (Heirloom Bronze), wipe with a soft, dry cloth. Do not use polishes or abrasive materials.

Bulb Replacement:

- Ensure power is turned off at the circuit breaker before replacing bulbs.
- Allow bulbs to cool completely before touching them.
- Carefully unscrew the old bulb and screw in a new B10-3 base bulb, not exceeding 40 watts.
- Restore power and test the fixture.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker or fuse. Ensure wall switch is ON.
	Loose wire connections.	Turn off power. Check and tighten all wire connections.
	Faulty bulb.	Replace bulb with a new one of the correct type and wattage.
Light flickers.	Loose bulb or connection.	Turn off power. Tighten bulb. Check wire connections.
	Incorrect bulb type.	Ensure bulbs are B10-3 base, 40W Max.

8. SPECIFICATIONS

Feature	Detail
Brand	Schonbek
Model Number	1242-76
Material	Crystal
Color	Heirloom Bronze (Fixture Finish), Crystal (Shade Color)
Installation Type	Semi Flush Mount
Number of Light Sources	3
Bulb Type (Not Included)	B10-3 Base
Max Wattage per Bulb	40 Watts
Voltage	110 Volts
Power Source	Corded Electric
Switch Type	Toggle (Wall Switch)
Brightness	1350 Lumen (Total, with appropriate bulbs)
Item Weight	8 Pounds
Indoor/Outdoor Usage	Indoor Only

Feature	Detail
Required Assembly	No (for main fixture body)

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Schonbek customer service directly. Refer to the contact information provided with your purchase documentation or visit the official Schonbek website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question