SEB XA900110

Moulinex XA900110 Bread Machine Paddles User Manual

For Home Bread XXL and Home Bread Baguette Models

1. Introduction

This manual provides essential instructions for the proper use, installation, and maintenance of your Moulinex XA900110 kneading paddles. These paddles are specifically designed for Moulinex Home Bread XXL and Home Bread Baguette bread machines to ensure optimal dough mixing and bread quality.

2. Safety Instructions

- Always unplug the bread machine before installing, removing, or cleaning the paddles.
- Ensure paddles are securely seated on the drive shafts before starting the bread machine.
- Avoid touching the paddles during operation.
- Use only the provided accessory hook to remove hot paddles from baked bread to prevent burns.
- Keep out of reach of children.

3. Setup and Installation

The Moulinex XA900110 set includes two kneading paddles. Follow these steps for correct installation:

1. Ensure your bread machine is unplugged and the baking pan is clean and empty.
2. Locate the two drive shafts at the bottom of the baking pan.
3. Align each paddle with a drive shaft, ensuring the paddle's opening fits snugly onto the shaft.
4. Press down gently until each paddle is fully seated and cannot be easily dislodged.
5. Verify that both paddles can rotate freely.



Figure 1: Two grey metallic kneading paddles, designed for use in bread machines. Each paddle features a central shaft opening for attachment to the bread maker's drive mechanism and a broad, curved blade for efficient dough mixing.

4. Operating Instructions

Once the paddles are installed and ingredients are added to the baking pan, the paddles will automatically engage during the kneading cycles of your bread machine program. They are designed to thoroughly mix and knead the dough, contributing to an even texture and consistent bread quality.
After baking, the paddles will often be embedded in the finished loaf. Use the provided accessory hook (usually included with your bread machine) to carefully remove them from the bread before slicing. This prevents damage to the paddles and ensures safe handling.

5. Maintenance and Cleaning

Proper cleaning and maintenance extend the lifespan of your kneading paddles:

- **After Each Use:** Remove the paddles from the baking pan. Wash them immediately with warm, soapy water to prevent dough residue from hardening.
- **Stubborn Residue:** If dough is stuck, soak the paddles in warm water for a few minutes before scrubbing with a non-abrasive sponge or brush.
- **Drying:** Dry the paddles thoroughly before storing them to prevent rust or corrosion.
- **Storage:** Store paddles in a dry place, preferably with your bread machine accessories.

6. Troubleshooting

- **Paddles not turning:** Ensure they are correctly seated on the drive shafts. Check if the bread machine program has started correctly.
- **Dough sticking to paddles:** This is normal. Ensure thorough cleaning after each use. Using a small amount of cooking oil on the paddles before adding ingredients can sometimes help reduce sticking.
- **Difficulty removing paddles from bread:** Use the accessory hook. If still difficult, allow the bread to cool slightly, as this can sometimes make removal easier.

7. Specifications

Feature	Detail
Model Number	XA900110
Brand	SEB (Moulinex)
Compatibility	Moulinex Home Bread XXL, Moulinex Home Bread Baguette
Quantity	2 paddles per set
Color	Metallic Grey
Material	Durable metal alloy
Weight	Approximately 59 g (for the set)

8. Warranty and Support

For warranty information or technical support regarding your Moulinex XA900110 kneading paddles, please refer to the documentation provided with your original Moulinex bread machine or visit the official SEB/Moulinex website. You may also contact customer service through the retailer where the product was purchased.
For additional information, you can visit theSEB Brand Store.

© 2024 SEB. All rights reserved.