



[Manuals.plus](#) /

> [amscan](#) /

> Unicorn Pinata User Manual

amscan 10032336

Unicorn Pinata User Manual

Model: 10032336 | Brand: amscan

INTRODUCTION

This manual provides instructions for the safe and proper use of your amscan Unicorn Pinata. This product is designed to provide entertainment for parties and celebrations. It is made from high-quality cardboard material, ensuring a fun and engaging experience.

SAFETY INFORMATION

- **Adult Supervision Required:** Always ensure adult supervision during the filling and use of the pinata, especially when children are participating.
- **Safe Striking Distance:** Ensure all participants and bystanders maintain a safe distance from the person striking the pinata to prevent accidental injury.
- **Appropriate Filling:** Fill the pinata with lightweight candies or small, soft toys. Avoid sharp, heavy, or fragile items that could cause injury when released.
- **Blindfold Use:** If using a blindfold, ensure the participant is properly oriented and has enough space to swing safely.
- **Single Use Item:** This pinata is designed for single use. Dispose of it properly after use.

SETUP

1. **Unpack the Pinata:** Carefully remove the Unicorn Pinata from its packaging.
2. **Locate Filling Opening:** Identify the designated opening for filling the pinata. This is typically a marked area on the back or top of the pinata.



Image: Close-up view of the Unicorn Pinata's filling opening, clearly marked with "TO FILL PRESS HERE UNDER ADULT SUPERVISION". This indicates the area where the pinata should be opened to insert treats.

3. **Fill with Treats:** Gently open the filling area and insert your chosen candies or small toys. Do not overfill, as this may make it too heavy or difficult to break. The manufacturer's suggested maximum weight is 2 pounds.
4. **Secure Opening:** Once filled, close and secure the opening.
5. **Hang the Pinata:** Use the sturdy loop provided at the top of the pinata to hang it from a secure support, such as a tree branch or a sturdy beam. Ensure it is hung at an appropriate height for the participants.



Image: A complete view of the Unicorn Pinata, showcasing its white body, pink accents on the hooves and snout, and a golden horn. This image illustrates the overall appearance of the product before use.

OPERATING INSTRUCTIONS

1. **Gather Participants:** Have all participants stand at a safe distance from the pinata.
2. **Blindfold (Optional):** If desired, blindfold the first participant.
3. **Spin (Optional):** Gently spin the blindfolded participant a few times to disorient them.
4. **Strike the Pinata:** Provide the participant with a stick or bat. Instruct them to strike the pinata until it breaks open and releases the contents.

- Collect Treats:** Once the pinata breaks, allow participants to safely collect the fallen treats. Ensure fair distribution and prevent pushing or shoving.

MAINTENANCE

The Unicorn Pinata is designed as a single-use item for party entertainment. No ongoing maintenance is required. Store in a dry place until ready for use to prevent damage to the cardboard material.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Pinata is too difficult to break.	May be due to the sturdy cardboard construction or insufficient force.	Allow more turns for participants. For younger children, consider using a lighter stick or allowing them to hit it without a blindfold. Adults may need to assist by hitting it once or twice.
Contents do not fall out easily.	Opening may be too small or contents are stuck.	Ensure the pinata is fully broken open. Gently shake the pinata or manually assist in releasing contents if safe to do so.

SPECIFICATIONS

Product Dimensions: 50.8 x 33.02 x 12.7 cm (20 x 13 x 5 inches)

Product Weight: 190 g (0.42 lbs)

Material: Cardboard

Model Number: 10032336

Recommended Age: 3 years and up

Maximum Fill

Weight: 2 pounds

Color: Multi-colored (primarily white with pink and rainbow accents)

UPC: 021505191000, 748579423416, 793631211715

WARRANTY AND SUPPORT

As the amscan Unicorn Pinata is a single-use party item, it does not come with a traditional warranty. For any questions regarding the product before use, please contact the retailer or manufacturer directly.