

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Matchbox](#) /

› [Matchbox Mega-Rig Powered Space Base Instruction Manual](#)

Matchbox 035995358546

Instruction Manual

MATCHBOX MEGA-RIG POWERED SPACE BASE

Model: 035995358546

Introduction

Welcome to the Matchbox Mega-Rig Powered Space Base. This playset allows for the construction of various space-themed vehicles and structures, fostering imaginative play. This manual provides essential information for assembly, operation, and maintenance to ensure a safe and enjoyable experience.

Package Contents

Please verify that all components listed below are present in your package before beginning assembly.

- 1 x Powered Space Base
- 2 x Space Shuttle
- 3 x Lunar Module
- 4 x Rover
- 1 x Remote Control



Figure 1: Unpacked components of the Mega-Rig Powered Space Base, including the main base parts, shuttle pieces, lunar modules, rovers, and the instruction sheet. This image shows the initial state of the product upon opening the box, with various plastic parts ready for assembly.

Setup and Assembly

The Matchbox Mega-Rig Powered Space Base is designed for modular assembly, allowing for multiple configurations. Follow the detailed instructions provided on the included instruction sheet for specific build options.

- 1. Unpack Components:** Carefully remove all parts from the packaging. Refer to the 'Package Contents' section to ensure all pieces are present.
- 2. Review Instructions:** Consult the separate instruction sheet for detailed diagrams and step-by-step guidance on constructing the various vehicles and the space base. The playset includes over 30 pieces that can be combined to create more than 20 different exciting toys.
- 3. Battery Installation (if applicable):** If any components require batteries for powered functions (e.g., the 'Powered Space Base' or remote control), locate the battery compartments. Insert the correct type and number of batteries, observing polarity (+/-) as indicated. *(Batteries not included unless specified on packaging.)*
- 4. Connect Modules:** Begin connecting the larger base and vehicle components as shown in the instruction diagrams. Ensure all connections are secure.
- 5. Attach Accessories:** Add smaller accessories, such as antennas, tools, or decorative elements, to complete your space base and vehicles.



Figure 2: The product packaging illustrating several possible configurations of the Mega-Rig Powered Space Base, including a large space station, shuttle, and lunar vehicles. This image provides examples of the playset's versatility once assembled.

Operation

Once assembled, the Mega-Rig Powered Space Base offers interactive play features. Refer to the specific assembly instructions for details on each configuration's unique functions.

- **Powered Functions:** If batteries are installed, activate any powered features by pressing designated buttons or switches on the base or vehicles. This may include lights, sounds, or motorized movement.
- **Remote Control:** Use the included remote control to operate specific functions of the space base or vehicles, if applicable. Ensure the remote control has fresh batteries and is within operational range.
- **Modular Play:** Experiment with different combinations of the Mega-Rig components to create new vehicles and structures. The design encourages creative building and role-playing scenarios.

Care and Maintenance

- **Cleaning:** Wipe surfaces with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Do not immerse electronic components in water.
- **Storage:** Store the playset in a cool, dry place away from direct sunlight to prevent material degradation. Disassemble larger structures for compact storage if desired.
- **Battery Replacement:** If powered functions become weak or stop working, replace batteries with new ones of the specified type. Always dispose of used batteries responsibly.
- **Inspection:** Periodically inspect all parts for damage or wear. Discontinue use if any part is broken or compromised to prevent injury.

Troubleshooting

- **No Power/Functionality:**

- Ensure batteries are correctly installed with proper polarity.
- Replace old batteries with new ones.
- Check for any loose connections or debris in battery compartments.

- **Parts Not Connecting Securely:**

- Verify that you are using the correct parts as per the assembly instructions.
- Ensure there is no foreign material obstructing the connection points.
- Apply gentle, even pressure when connecting pieces. Do not force.

- **Remote Control Not Responding:**

- Check and replace batteries in the remote control.
- Ensure there is a clear line of sight between the remote and the playset receiver.
- Confirm the playset itself is powered on.

Product Specifications

Feature	Detail
Product Dimensions	26 x 5 x 16 inches
Item Weight	5 pounds
ASIN	B001M08WMA
Item Model Number	035995358546
Manufacturer Recommended Age	3 years and up
Manufacturer	Mattel

Warranty and Support

Matchbox products are manufactured to high-quality standards. For any questions regarding product operation, missing parts, or potential defects, please refer to the contact information provided on the product packaging or visit the official Matchbox website for customer support. Please retain your proof of purchase for warranty claims.

For more information, you may visit the [Matchbox Store on Amazon](#).