

## RL LIVE YOUR LIGHT R5073-47

# Reality Leuchten LED Water Column R5073-47 User Manual

Model: R5073-47 | Brand: RL LIVE YOUR LIGHT

### PRODUCT OVERVIEW

The Reality Leuchten LED Water Column R5073-47 is a decorative floor lamp featuring a clear plastic column with a titan-colored base. It includes an energy-saving 3.6 Watt RGB LED with color-changing functionality and comes with five decorative fish that move within the bubbling water. This water column is designed for indoor use only and provides a calming visual effect with its light and motion.






Image: The Reality Leuchten LED Water Column R5073-47, showcasing its clear column, decorative fish, and titan-colored base.

## SETUP INSTRUCTIONS

---

Follow these steps to set up your LED Water Column:

1. **Unpacking:** Carefully remove all components from the packaging. Ensure you have the water column, the power adapter, and the five decorative fish.
2. **Placement:** Choose a stable, level surface indoors for the water column. The product dimensions are approximately 21 cm (depth) x 21 cm (width) x 130 cm (height). Ensure it is placed away from direct sunlight, heat sources, and areas where it might be easily knocked over.
3. **Filling with Water:** Fill the water column with **distilled water**. Using distilled water is crucial for optimal bubbling results and to prevent mineral buildup. Fill it up to the indicated maximum fill line, typically near the top of the column, leaving a small air gap.
4. **Adding Decorative Fish:** Gently place the five decorative fish into the water column. They are designed to float and move with the water's motion.
5. **Connecting Power:** Connect the power adapter to the water column's power input, usually located at the base. Then, plug the power adapter into a suitable electrical outlet.



R5073-XX

Image: Technical drawing showing the dimensions (130 cm height, 21.5 cm base) and components of the water column, including the power adapter and switch.

## OPERATING INSTRUCTIONS

---

Once set up, operating your LED Water Column is straightforward:

- **Power On/Off:** Locate the power switch, typically a rotary knob or button, on the base of the water column. Turn the switch to the 'ON' position to activate the bubbling effect and the LED lighting. Turn it to 'OFF' to power down the unit.
- **Color Changing Function:** The integrated RGB LED light automatically cycles through various colors, creating a dynamic and soothing visual display. There is no manual control for specific colors; the unit transitions through the spectrum automatically.
- **Bubbling Effect:** The internal pump creates a continuous stream of bubbles, causing the decorative fish to move and "swim" within the column.





Image: Graphic illustrating the RGB color changing capability of the LED light, showing red, green, and blue primary colors.



## MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your water column:

- **Water Replacement:** Regularly check the water level and clarity. If the water becomes cloudy or the bubbling effect diminishes, it may be time to replace the water. Always use distilled water to prevent mineral deposits and maintain clear operation.
- **Cleaning:** The plastic material is mold-resistant. For external cleaning, wipe the column and base with a soft, damp cloth. Do not use abrasive cleaners or solvents. For internal cleaning, if necessary, carefully drain the water and rinse the inside with distilled water.
- **Dusting:** Periodically dust the exterior of the unit to maintain its appearance.

## TROUBLESHOOTING

If you encounter any issues with your water column, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No bubbles or light	Power not connected, switch off, or internal pump/LED malfunction.	Ensure the power adapter is securely plugged into both the unit and the outlet. Check that the power switch is in the 'ON' position. If the issue persists, contact customer support.
Fish not moving or floating at top/bottom	Insufficient bubbling, air trapped in fish, or water quality issues.	Ensure the water level is correct and that distilled water is used. Gently tap the column to dislodge any trapped air in the fish. If bubbling is weak, consider replacing the water.
Loud humming noise	Vibration from the pump or unstable placement.	Ensure the water column is on a completely flat and stable surface. Placing a soft mat or pad underneath may help reduce vibrations.
Water appears cloudy	Mineral buildup from tap water or algae growth.	Drain the old water and thoroughly clean the inside of the column. Refill only with distilled water.

## SPECIFICATIONS

Feature	Detail
Model Number	R5073-47
Product Dimensions (L x W x H)	21 x 21 x 130 cm
Item Weight	1.58 Kilograms
Material	Plastic (clear column, titan-colored base)
Light Source	3.6 Watt RGB LED with color-changing function
Included Components	Light source, 5 decorative fish
Special Application	For indoor use only
Cable Length	130 Centimeters

## WARRANTY AND SUPPORT

---

Information regarding specific warranty terms or direct customer support contacts for the Reality Leuchten LED Water Column R5073-47 was not available in the provided product data. Please refer to the retailer or manufacturer's official website for the most up-to-date warranty information and support options.

For general inquiries or assistance, you may visit the brand's website: [RL LIVE YOUR LIGHT Official Website](#) *(Note: This link is a general placeholder for the brand's website and may not lead directly to support for this specific product.)*

## IMPORTANT SAFETY INFORMATION

---

- Always use distilled water to prevent damage to the pump and maintain water clarity.
- Do not immerse the electrical components (base, power adapter) in water.
- Ensure the unit is unplugged before performing any maintenance or cleaning.
- Keep out of reach of children and pets to prevent accidental tipping or damage.
- This product is for indoor use only. Do not expose to outdoor elements.