

Wiha 71480

Wiha 71480 CentroFix Bit Holder Instruction Manual

Model: **71480**

INTRODUCTION

This manual provides essential information for the safe and effective use of your Wiha 71480 CentroFix Bit Holder. Please read these instructions carefully before initial use and retain them for future reference. This product is designed for professional and DIY applications requiring secure and quick bit changes.

PRODUCT OVERVIEW

The Wiha 71480 CentroFix Bit Holder is a high-quality accessory designed to securely hold 1/4-inch hex power bits. Its CentroFix quick-release mechanism allows for fast and efficient bit changes, enhancing productivity. It is compatible with various drills, impact drivers, and power screwdrivers that accept 1/4-inch hex shanks.



Image: The Wiha 71480 CentroFix Bit Holder, a quick-release tool for 1/4-inch hex power bits.

SETUP

- Inspect the Bit Holder:** Before each use, visually inspect the CentroFix Bit Holder for any signs of damage, wear, or deformation. Do not use if damaged.
- Insert into Tool:** Insert the 1/4-inch hex shank of the bit holder firmly into the chuck of your drill, impact driver, or power screwdriver. Ensure it is seated correctly and tightened securely according to your power tool's instructions.
- Insert a Bit:** Pull back the collar of the CentroFix Bit Holder. Insert a 1/4-inch hex power bit into the holder until it clicks into place. Release the collar. Gently pull on the bit to ensure it is securely locked.

OPERATING INSTRUCTIONS

OPERATING INSTRUCTIONS

- **Secure Bit Insertion:** Always ensure the bit is fully engaged and locked by the CentroFix mechanism before operating your power tool. A properly inserted bit will not pull out easily without retracting the collar.
- **Bit Removal:** To remove a bit, pull back the collar of the bit holder. The bit will be released, allowing you to pull it out. Release the collar to prepare for the next bit.
- **Compatibility:** Use only with 1/4-inch hex power bits. Using incompatible bits may damage the bit holder or the bit itself.
- **Safety:** Always wear appropriate personal protective equipment (PPE), such as safety glasses, when operating power tools. Ensure the workpiece is stable and secure. Do not apply excessive force that could damage the bit holder or cause injury.

MAINTENANCE

- **Cleaning:** Keep the bit holder clean and free from dust, debris, and moisture. Use a dry cloth to wipe it down after each use. Avoid using harsh chemicals or solvents that could damage the finish or internal mechanism.
- **Lubrication:** Periodically, a small amount of light machine oil can be applied to the quick-release mechanism to ensure smooth operation. Wipe off any excess oil.
- **Storage:** Store the bit holder in a dry environment, away from extreme temperatures and corrosive substances. Keep it in a toolbox or organizer to prevent loss or damage.
- **Inspection:** Regularly inspect the bit holder for any signs of wear, such as a loose collar, difficulty in holding bits, or visible cracks. Replace the bit holder if any significant wear or damage is observed.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bit does not lock securely.	Bit not fully inserted; debris in mechanism; worn mechanism.	Ensure bit is fully pushed in until it clicks. Clean the mechanism. If worn, replace the bit holder.
Difficulty inserting/removing bit.	Collar not fully retracted; debris; lack of lubrication.	Pull collar back completely. Clean the mechanism. Apply a small amount of light machine oil.
Bit holder wobbles in tool chuck.	Tool chuck not tightened; bit holder shank worn.	Ensure tool chuck is tightened properly. Inspect bit holder shank for wear; replace if necessary.

SPECIFICATIONS

- **Model Number:** 71480
- **Bit Compatibility:** 1/4-inch Hex Power Bits
- **Mechanism:** CentroFix Quick Release
- **Product Dimensions:** Approximately 1 x 1 x 1 inches
- **Item Weight:** Approximately 1.44 ounces
- **Manufacturer:** WIHA

WARRANTY AND SUPPORT

For information regarding product warranty, technical support, or to explore other Wiha products, please visit the official Wiha website or contact their customer service. You can also visit the [Wiha Store on Amazon](#).

© 2023 Wiha. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question