

[Manuals.plus](#) /

> [Microsoft](#) /

> Microsoft Wired Keyboard 600 (Model ANB-00001) User Manual

## Microsoft ANB-00001

# Microsoft Wired Keyboard 600 User Manual

Model: ANB-00001

## INTRODUCTION

The Microsoft Wired Keyboard 600 is a reliable and functional keyboard designed for everyday use. It features a spill-resistant design, quiet touch keys, and convenient media hotkeys, making it suitable for various computing tasks. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your keyboard.

## PACKAGE CONTENTS

Verify that your package contains the following items:

- Microsoft Wired Keyboard 600 (Model ANB-00001)
- Integrated USB Cable

## SETUP

Setting up your Microsoft Wired Keyboard 600 is a straightforward process:

1. **Unpack the Keyboard:** Carefully remove the keyboard from its packaging.
2. **Connect to Computer:** Locate an available USB port on your computer. Insert the USB connector from the keyboard into the USB port.
3. **Driver Installation:** Your operating system (Windows or macOS) should automatically detect and install the necessary drivers. This process may take a few moments.
4. **Begin Use:** Once the drivers are installed, your keyboard is ready for use.



*Image: The Microsoft Wired Keyboard 600, showing its USB cable connection. Simply plug the USB cable into an available port on your computer to begin setup.*

## OPERATING INSTRUCTIONS

The Microsoft Wired Keyboard 600 offers standard typing functionality along with several convenient hotkeys:

- **Standard Typing:** Use the QWERTY layout for all standard character input.
- **Numeric Keypad:** The dedicated numeric keypad on the right provides efficient data entry. Ensure Num Lock is active (indicated by an LED).
- **Media Hotkeys:** Located above the function keys, these buttons allow quick control over media playback:
  - Play/Pause
  - Volume Up
  - Volume Down
  - Mute

- **Calculator Hotkey:** Press the dedicated calculator button to quickly launch the calculator application on your computer.
- **Windows Start Button:** The Windows key provides quick access to the Start Menu or other operating system functions.



*Image: A close-up view of the media control keys and calculator hotkey, positioned above the function row for easy access.*


Your browser does not support the video tag.

*Video: An official product video demonstrating the features and usage of the Microsoft Wired Keyboard 600. This video highlights key aspects of the keyboard's design and functionality.*

## FEATURES

---

- **Spill-Resistant Design:** Engineered with integrated water channels to help drain liquids away, protecting the keyboard from accidental spills.
- **Quiet Touch Keys:** Enjoy a comfortable and quiet typing experience with responsive keys.
- **USB Connectivity:** Simple plug-and-play setup with a standard USB connection.
- **Full-Size Layout:** Includes a numeric keypad and standard function keys for comprehensive input.
- **Media Hotkeys:** Dedicated keys for volume control (up, down, mute) and play/pause functionality.
- **Calculator Hotkey:** Instant access to your computer's calculator application.



*Image: Illustration of the keyboard's spill-resistant design, highlighting the integrated water channels that help protect against accidental liquid damage.*

## MAINTENANCE

To ensure the longevity and optimal performance of your keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, slightly damp cloth to wipe the surface of the keyboard. Avoid harsh chemicals or abrasive cleaners. For cleaning between keys, use compressed air to remove dust and debris.
- **Spill Management:** While the keyboard is spill-resistant, it is not waterproof. In case of a spill, immediately disconnect the keyboard from your computer, turn it upside down to drain liquid, and allow it to dry completely before reconnecting.
- **Storage:** Store the keyboard in a clean, dry environment away from extreme temperatures.

## TROUBLESHOOTING

If you encounter issues with your Microsoft Wired Keyboard 600, try the following steps:

- **Keyboard Not Responding:**
  - Ensure the USB cable is securely plugged into a working USB port on your computer.
  - Try plugging the keyboard into a different USB port.
  - Restart your computer.
- **Keys Not Working:**
  - Check for any physical obstructions under the keys.
  - Clean the keyboard as described in the Maintenance section.
- **Media Keys Not Functioning:**
  - Ensure your operating system and media player software are up to date.
  - Some media players may require specific settings to recognize keyboard media controls.
- **Unexpected Behavior:**
  - Disconnect and reconnect the keyboard.
  - Check your computer's device manager for any keyboard-related errors or outdated drivers.

## SPECIFICATIONS

Feature	Detail
Brand	Microsoft
Model Number	ANB-00001
Connectivity Technology	USB-A (Wired)
Keyboard Description	Gaming, Numeric, Integrated
Special Feature	Spill Proof
Color	Black
Product Dimensions (L x W x H)	18.6"L x 1.5"W x 6.9"H
Material	Plastic

Feature	Detail
Power Source	Corded Electric
Switch Type	Tactile
Keyboard Layout	QWERTY
Compatible Operating Systems	MacOS, Windows (Minimum Windows 10)
Item Weight	1.7 Pounds

## WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Microsoft support channels or the documentation included with your purchase. You can typically find support resources on the Microsoft website by searching for "Microsoft Wired Keyboard 600 support" or by visiting [microsoft.com/support](https://microsoft.com/support).

