### Manuals+

Q & A | Deep Search | Upload

### OttLite J59376

# OttLite J59376 Learning Light Table Lamp Instruction Manual

Model: J59376

# 1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your OttLite J59376 Learning Light Table Lamp. Designed to provide clear and accurate illumination, this lamp is ideal for reading and studying, helping to reduce glare and eyestrain.



Figure 1: The OttLite J59376 Learning Light Table Lamp in black, showcasing its sleek design and adjustable arm.

# 2. IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before using your OttLite lamp. Failure to follow these instructions may result in electric shock, fire, or serious injury.

• Always unplug the lamp from the electrical outlet before cleaning or changing the bulb.

- · Do not use with a dimmer switch.
- Do not operate the lamp if the cord or plug is damaged.
- · Keep the lamp away from water or other liquids.
- This lamp is for indoor use only.
- Ensure the lamp is placed on a stable, flat surface to prevent tipping.

# 3. PACKAGE CONTENTS

Carefully unpack your OttLite J59376 lamp and verify that all components are present:

- OttLite J59376 Learning Light Table Lamp (main unit)
- 13-watt energy-efficient fluorescent tube (pre-installed or included separately)
- Shade (integrated with the lamp head)

If any items are missing or damaged, please contact OttLite customer support.

## 4. SETUP INSTRUCTIONS

Follow these steps to set up your OttLite J59376 Learning Light Table Lamp:

- 1. **Unpack the Lamp:** Carefully remove all packaging materials from the lamp.
- 2. **Place the Lamp:** Position the lamp on a stable, flat surface such as a desk or table. Ensure there is adequate space around the lamp for adjustment.
- 3. Connect to Power: Insert the power cord plug firmly into a standard electrical outlet (120V AC, 60Hz).
- 4. **Bulb Installation (if not pre-installed):** If the 13-watt fluorescent tube is not already installed, gently insert it into the lamp head's socket, ensuring it is seated correctly. Refer to the bulb replacement section for detailed instructions if needed.



Figure 2: The OttLite lamp positioned on a desk, ready for use in a study environment.

# 5. OPERATING INSTRUCTIONS

Your OttLite J59376 lamp is designed for ease of use and optimal lighting for various tasks.

- Turning On/Off: Locate the power button on the lamp base. Press the button once to turn the lamp on, and press it again to turn the lamp off.
- Adjusting the Lamp Head: The lamp head is designed to be highly adjustable. You can:
  - Adjust the shade up and down to direct light precisely where needed.
  - Rotate the lamp head sideways to cover a wider area or focus on a specific point.

Gently move the lamp head to achieve your desired lighting angle. Avoid forcing the joints beyond their natural range of motion.



Figure 3: Illustration of the lamp head's adjustable movement, demonstrating its ability to pivot and rotate for optimal light positioning.




Figure 4: A user benefiting from the clear, focused illumination provided by the OttLite lamp while reading documents at a desk.

# 6. MAINTENANCE

Proper maintenance will ensure the longevity and optimal performance of your OttLite lamp.

### • Cleaning:

- Always unplug the lamp before cleaning.
- Wipe the lamp with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish
- Ensure the lamp is completely dry before plugging it back in.

### • Bulb Replacement:

The lamp uses an energy-efficient 13-watt fluorescent tube, rated to last up to 10,000 hours. When the bulb needs replacement:

- 1. Unplug the lamp from the power outlet.
- 2. Allow the bulb to cool completely if it has been recently in use.
- 3. Carefully remove the old bulb by gently pulling it straight out from the socket.
- 4. Insert the new 13-watt OttLite replacement tube into the socket, ensuring it is fully seated.
- 5. Dispose of the old bulb according to local regulations for fluorescent lamps.

# 7. TROUBLESHOOTING

If you encounter issues with your OttLite J59376 lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in.  Power outlet is not working.  Bulb is loose or burnt out.	Ensure the power cord is securely plugged into a working outlet.  Test the outlet with another device.  Check if the bulb is properly seated. Replace the bulb if it is burnt out.
Light flickers.	Bulb is loose. Bulb is nearing end of life.	Ensure the bulb is firmly seated in the socket.  Replace the bulb with a new 13-watt OttLite tube.
Lamp makes unusual noise.	Loose components. Internal electrical issue.	Unplug the lamp and check for any loose parts.  If the noise persists, discontinue use and contact customer support.

If the problem persists after trying these solutions, please contact OttLite customer support for further assistance.

# 8. SPECIFICATIONS

Feature	Detail
Model Number	J59376
Brand	OttLite
Colour	Black
Material	Plastic
Power Source	Corded Electric
Wattage	13 watts
Bulb Type	13-watt fluorescent tube (Type A)
Bulb Life	Up to 10,000 hours
Product Dimensions (L x W x H)	7.32 x 15.09 x 38.58 cm (2.88 x 5.94 x 15.19 inches)
Max Height	19.25 inches (48.9 cm)
Min Height	14.75 inches (37.47 cm)

Feature	Detail
Base Diameter	5.00 inches (12.7 cm)
Item Weight	975 g (2.15 lbs)
Special Features	Adjustable shade (up/down, sideways rotation)

### 9. WARRANTY AND SUPPORT

Your OttLite J59376 Learning Light Table Lamp comes with a limited warranty:

Lamp: 2-year limited warrantyBulb: 1-year limited warranty

For warranty claims, technical support, or replacement parts, please contact OttLite customer service. Keep your proof of purchase for warranty validation.

Visit the official OttLite website for the most up-to-date contact information and support resources:www.ottlite.com



© 2023 OttLite. All rights reserved.

Manual Version: 1.0

#### **Related Documents**



#### OttLite Learning Light Lamp User Manual and Safety Instructions

User manual for OttLite Learning Light lamps, including models J48006, J59376, J3000A-TSC, J30G5A-TSC, J3090A-TSC, ST-120, and ST120A. Provides detailed instructions for assembly, operation, light tube insertion and replacement, and important safety guidelines to ensure proper use and prevent electric shock. Learn how to set up and maintain your OttLite natural lighting product.



### Ottlite B1FSA & B1FSB LED Desk Lamps - Product Overview and Specifications

Detailed overview of the Ottlite B1FSA (black) and B1FSB (white) LED desk lamps, including features, power adapter specifications, and safety information.



### OttLite Rechargeable LED Travel Light User Manual and Specifications

Comprehensive guide for the OttLite Rechargeable LED Travel Light, including setup, operation, safety instructions, FCC compliance, and specifications. Features include dimmable LED, calendar, alarm, and temperature display.



### OttLite Vero Table Lamp User Manual and Safety Guide

Comprehensive guide for the OttLite Vero Table Lamp, covering assembly, operation, tube replacement, and essential safety instructions for optimal use.







### [pdf] User Manual Installation Guide Instructions

J59376 ottlite instructions


Instruction Manual 13W Learning Light Lamp J59376 INS50002Rev.0818 ENGLISH 13W Learning Light Lamp LAMP ASSEMBLY 1. Align base as shown. Install base screw loosely by hand. 2. Using provided key A tighten base screw until snug. OPERATION 1. As needed, tighten or loosen the two pivot joints ...

lang:en score:51 filesize: 103.34 K page count: 2 document date: 2005-08-18

### OttLite Learning Light Lamp User Manual and Safety Instructions

User manual for OttLite Learning Light lamps, including models J48006, J59376, J3000A-TSC, J30G5A-TSC, J3090A-TSC, ST-120, and ST120A. Provides detailed instructions for assembly, operation, light tube insertion and replacement, and important safety guidelines to ensure proper use and prevent electric shock. Learn how to set up and maintain your OttLite natural lighting product.

lang:en score:42 filesize: 814.02 K page\_count: 2 document date: 2013-06-21



### [pdf] Instructions

ArtiosCAD Plot joeb J59376 DIS ottlite instructions

- 1. Unfold base and Square up. Assembly Instructions 2. Fold Bottom flaps inward 3. Stand base upright. 4. Starting with bottom tray, insert tabs on base into slots on tray.
- 5. Repeat with top tray. Add Header. 6. Complete floor display. ...

lang:en score:34 filesize: 16.84 K page\_count: 1 document date: 2005-03-17