

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [simplehuman](#) /

> [simplehuman 6 Liter Semi-Round Bathroom Step Trash Can Instruction Manual](#)

simplehuman CW1834

simplehuman 6 Liter Semi-Round Bathroom Step Trash Can Instruction Manual

Model: CW1834

INTRODUCTION

Thank you for choosing the simplehuman 6 Liter Semi-Round Bathroom Step Trash Can. This manual provides essential information for the proper setup, operation, and maintenance of your new trash can. Designed for efficiency and durability, this product features a strong steel pedal, silent-close lid, and a fingerprint-proof brushed stainless steel finish, making it ideal for smaller spaces like bathrooms or offices.

SETUP

1. Unpacking

Carefully remove all packaging materials from the trash can. Ensure all components, including the inner bucket, are present and undamaged.

2. Inserting the Inner Bucket


Place the black inner bucket inside the stainless steel outer shell. Ensure it sits securely at the bottom.



Image: The simplehuman 6 Liter Semi-Round Trash Can with its lid open, revealing the removable black inner bucket.

3. Attaching a Liner

For optimal hygiene and ease of disposal, we recommend using simplehuman Code B custom fit liners. These liners are designed to fit perfectly without bunching or slipping. Alternatively, standard small trash bags can be used.



PERFECT FIT — EXTRA STRONG

Our custom fit liners fit perfectly so there's no bunching, slipping or messy bag overhang. They are also extra-thick and double-seamed so they don't rip, leak or tear.

Image: A visual representation of simplehuman Code B custom fit liners, demonstrating their perfect fit within the inner

bucket of the trash can.

4. Placement

Position the trash can in your desired location. Its semi-round shape is designed to fit flush against a wall or cabinet, maximizing space efficiency.



Image: The simplehuman Semi-Round Step Can positioned in a bathroom, illustrating its compact and space-efficient design.

OPERATING INSTRUCTIONS

1. Using the Step Pedal

To open the lid, gently press down on the strong steel pedal with your foot. The lid will open smoothly. Release the pedal to allow the lid to close.




Image: A detailed view of the durable steel pedal, designed for long-lasting use.

2. Silent-Close Lid

The lid features patented lid shox technology, ensuring a slow, silent close every time. This prevents slamming and reduces noise in your environment.

SILENT-CLOSE LID

Our patented lid shock technology controls the motion of the lid for a slow, silent close.



Image: A visual demonstrating the silent-close lid technology, showing the lid gently descending.

3. Fingerprint-Proof Finish

The brushed stainless steel exterior is treated with a fingerprint-proof finish, resisting smudges and keeping the surface clean and shiny with minimal effort.

CLEANER STAINLESS STEEL

Our invisible silver-ion coating resists fingerprints and the spread of germs without dulling the natural sheen and luster of the steel (brushed model only).



Image: A graphic highlighting the fingerprint-proof coating on the stainless steel, showing how it repels smudges.

4. Product Overview Video

Video: A detailed look at the features and functionality of the simplehuman 6 Liter Semi-Round Step Trash Can, demonstrating its design and operation.

MAINTENANCE

1. Cleaning the Exterior

Wipe the brushed stainless steel exterior with a soft, damp cloth and a mild stainless steel cleaner. Avoid abrasive cleaners or scouring pads, as these can damage the fingerprint-proof finish. Dry thoroughly with a soft cloth.

2. Cleaning the Inner Bucket

The inner bucket is removable for easy cleaning. Lift the inner bucket out of the outer shell. Wash it with warm, soapy water, rinse thoroughly, and dry completely before placing it back into the trash can.



Image: A hand demonstrating the removal of the inner bucket, facilitating easy cleaning and trash disposal.

3. Replacing Liners

When the liner is full, remove the inner bucket or simply lift the liner from the top. Replace with a new simplehuman Code B liner or a compatible standard trash bag.

TROUBLESHOOTING

Lid Not Closing Silently

Check for any obstructions around the lid mechanism or hinges. Ensure the lid shock mechanism is clean and free of debris. If the issue persists, gently clean the hinge area.

Pedal Not Functioning Smoothly

Inspect the pedal mechanism for any foreign objects or debris that might be impeding its movement. Clear any obstructions. The steel pedal is engineered for durability, but regular checks can prevent issues.

Excessive Smudges/Fingerprints

While the trash can is fingerprint-proof, heavy oils or residues may still leave marks. Clean the surface as described in the Maintenance section. For stubborn marks, a specialized stainless steel cleaner may be

used.

SPECIFICATIONS



Image: The simplehuman 6 Liter Semi-Round Trash Can with its key dimensions (height, width, depth) clearly indicated.

Feature	Detail
Brand	simplehuman
Model Number	CW1834
Capacity	6 Liters (1.6 Gallons)
Material	Brushed Stainless Steel, 75% Post-Consumer Recycled Plastic Inner Bucket
Dimensions (L x W x H)	9.3" x 8.9" x 13.6"

Opening Mechanism	Step-On Pedal
Special Feature	Silent Close Lid, Fingerprint-Proof
Shape	Semi-Circular

WARRANTY

The simplehuman 6 Liter Semi-Round Bathroom Step Trash Can is backed by a 10-year warranty. This warranty covers defects in material and workmanship under normal household use. For detailed warranty terms and conditions, please visit the official simplehuman website.

Video: A user review highlighting the long-term durability and performance of the simplehuman trash can over 10 years of use.

SUPPORT

For further assistance, product registration, or to purchase replacement parts and custom fit liners, please visit the official simplehuman website at www.simplehuman.com. You can also find additional support resources and FAQs there.