

[Manuals.plus](#) /

› [Lawn-Boy](#) /

› Lawn Boy 89963 20-Inch Replacement Lawn Mower Blade User Manual

Lawn-Boy 89963P

Lawn-Boy 89963 20-Inch Replacement Lawn Mower Blade User Manual

Model: 89963P

INTRODUCTION

This manual provides essential information for the safe and effective use, installation, and maintenance of your Lawn-Boy 89963 20-Inch Replacement Lawn Mower Blade. This blade is specifically designed to maintain the peak performance of your Lawn-Boy mower, offering a high-quality cut and enhanced durability for efficient mulching and bagging.



Image: The Lawn-Boy 89963 20-inch replacement lawn mower blade, a dark metal blade with three circular holes in the center for mounting, and notched ends for efficient cutting and mulching.

SAFETY INFORMATION

Always prioritize safety when handling and installing mower blades. Failure to follow these instructions may result in serious injury.

- **Disconnect Spark Plug:** Before performing any maintenance or blade replacement, always disconnect the spark plug wire from the spark plug to prevent accidental engine starting.
- **Wear Protective Gear:** Always wear heavy-duty gloves and eye protection when handling the blade. Blades are sharp and can cause cuts.
- **Secure the Mower:** Ensure the mower is stable and cannot tip over during blade removal or installation.
- **Allow Engine to Cool:** If the mower has been recently used, allow the engine and blade to cool down before touching them.
- **Use Correct Tools:** Use appropriate tools for blade removal and installation to ensure a secure fit and prevent damage.

Setup & Installation

Follow these steps to safely replace your lawn mower blade:

1. **Prepare the Mower:** Ensure the mower's engine is off and cool. Disconnect the spark plug wire.
2. **Tilt the Mower:** Carefully tilt the mower onto its side, ensuring the carburetor and air filter are facing upwards to prevent fuel or oil leaks.
3. **Secure the Blade:** Use a block of wood or a blade removal tool to secure the old blade from turning.
4. **Remove Old Blade:** Using a wrench, loosen and remove the blade bolt(s) that hold the blade to the crankshaft. Keep track of any washers or spacers.
5. **Inspect Components:** Inspect the blade adapter and any washers for wear or damage. Replace if necessary.
6. **Install New Blade:** Position the new Lawn-Boy 89963 blade onto the blade adapter, ensuring the cutting edge faces the correct direction (usually indicated by an arrow or

Ask a Question About This Manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question