

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Playmobil](#) /

› [Playmobil 5878 Policeman with Bandit Instruction Manual](#)

Playmobil 5878

Playmobil 5878 Policeman with Bandit Instruction Manual

INTRODUCTION

This manual provides instructions for the assembly, use, and care of your Playmobil 5878 Policeman with Bandit playset. Please read these instructions carefully before use and retain them for future reference.



This image displays the complete Playmobil 5878 set, featuring the Policeman figure, the Bandit figure, and various small accessories such as a hat, handcuffs, and a money bag. All components are shown in their assembled state, ready for play.

IMPORTANT SAFETY INFORMATION

- **WARNING: CHOKING HAZARD**
 - Small parts. Not for children under 3 years.
- Recommended age: 4 years and up.
- Adult supervision is recommended during play.
- Keep packaging materials away from children to prevent suffocation.

PACKAGE CONTENTS

Please check that all parts listed below are present in your package. If any parts are missing or damaged, please contact customer support.

- 1x Playmobil Policeman figure
- 1x Playmobil Bandit figure

- Assorted accessories (e.g., hat, handcuffs, money bag)

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Playmobil figures and accessories:

1. **Attach Head to Body:** Gently push the head onto the neck peg of each figure until it is securely in place.
2. **Add Headwear:** Place the policeman's hat onto the policeman's head.
3. **Position Accessories:** Place accessories such as handcuffs or the money bag into the figures' hands as desired. The figures' hands are designed to hold these items securely.

PLAYING WITH YOUR PLAYMOBIL SET

Your Playmobil Policeman and Bandit figures are designed for imaginative play. Encourage storytelling and role-playing scenarios.

- The figures' arms and legs are articulated, allowing for various poses.
- Accessories can be interchanged between figures for different play scenarios.

MAINTENANCE AND CARE

To ensure the longevity of your Playmobil set, please follow these care instructions:

- **Cleaning:** Wipe figures and accessories with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the set in a clean, dry place away from direct sunlight and extreme temperatures.
- **Avoid Damage:** Do not bend or twist parts excessively, as this may cause breakage.

TROUBLESHOOTING

If you encounter any issues with your Playmobil set, please refer to the following common solutions:

- **Missing Parts:** If a part is missing from a new set, please contact Playmobil customer support with your product model number.
- **Damaged Parts:** For damaged parts, contact customer support for assistance.
- **Figures Not Holding Accessories:** Ensure accessories are correctly placed in the figures' hands. Some accessories may require a gentle push to secure.

SPECIFICATIONS

Feature	Detail
Model Number	5878
Product Dimensions	5.9 x 5.9 x 1.6 inches (15 x 15 x 4 cm)
Item Weight	1.44 ounces (40.8 grams)
Recommended Age	4 years and up

Feature	Detail
Brand	Playmobil

WARRANTY AND SUPPORT

Playmobil products are manufactured to high-quality standards. For information regarding warranty, replacement parts, or customer support, please visit the official Playmobil website or contact their customer service department.

Online Support: www.playmobil.com/service