

[Manuals.plus](#) /

› [iLive Electronics](#) /

› iLive ISP209B Portable Speaker System with Alarm Clock and Dock for iPod and iPhone - User Manual

iLive Electronics ISP209B

iLive ISP209B Portable Speaker System with Alarm Clock and Dock for iPod and iPhone - User Manual

INTRODUCTION

Welcome to the user manual for your iLive ISP209B Portable Speaker System. This guide provides comprehensive instructions for setting up, operating, and maintaining your device, ensuring optimal performance and longevity. Please read this manual thoroughly before using the product.

PRODUCT OVERVIEW

Key Features

- Plays and charges: iPod mini; iPod nano 1G, 2G, 3G, 4G; iPod classic 4G, 5G, 5.5G, 6G; iPod touch 1G, 2G; iPhone 1G, 3G
- Alarm clock with options to wake to iPod music or buzzer; includes gradual wake mode
- 0.9-inch LCD with white backlight for clear visibility
- Flexible power options: AC adapter or six AA batteries for portability
- 3.5-mm auxiliary input for use with external audio devices

Components and Controls

Familiarize yourself with the main unit and its controls, as well as the included remote control.



Figure 1: The iLive ISP209B Portable Speaker System with an iPod docked, displaying the time and volume. The main unit features integrated speakers, a central display, and control buttons along the top panel.



Figure 2: The iLive ISP209B Portable Speaker System with an iPhone docked, showcasing its compatibility with various Apple devices. The design allows for secure placement and charging of your device.





Figure 3: The remote control for the iLive ISP209B, featuring buttons for power, mute, source selection, bass adjustment, volume control, and track navigation (skip, play/pause, random).

SETUP

Powering the Unit

1. **AC Power:** Connect the included AC/DC adapter to the DC input jack on the back of the unit and plug the other end into a standard wall outlet.
2. **Battery Power:** For portable use, open the battery compartment on the bottom of the unit and insert six (6) AA

batteries, ensuring correct polarity. Close the compartment securely.

Docking Your Device

1. Select the appropriate docking bracket for your specific iPod or iPhone model.
2. Insert the chosen bracket into the docking bay on the speaker system.
3. Carefully place your iPod or iPhone onto the dock connector, ensuring it is securely seated. The device should begin charging automatically if the unit is powered.

OPERATION

Playing Audio

- **From Docked Device:** Once your iPod or iPhone is docked, select the 'iPod' source using the Source button on the unit or remote. Use your device's controls or the remote to play, pause, skip tracks, and adjust volume.
- **From Auxiliary Input:** Connect an external audio device (e.g., iPod Shuffle, MP3 player) to the 3.5mm auxiliary input jack on the unit using a 3.5mm audio cable (not included). Select the 'AUX' source. Control playback from your external device and adjust volume using the unit or remote.

Alarm Clock Functions

The ISP209B features a digital alarm clock with dual alarm settings.

- **Setting Time:** Refer to the detailed instructions in your quick start guide for initial time setting.
- **Setting Alarms:** You can set two independent alarms. Each alarm can be configured to wake you with either your docked iPod/iPhone music or a buzzer sound. The gradual wake mode increases the alarm volume slowly.
- **Turning Off Alarms:** To temporarily silence a sounding alarm, press the 'Alarm Off' button. To disable an alarm permanently or for a specific period (e.g., for the weekend), **hold down the 'Alarm Off' button while repeatedly pressing the 'Source' button until the alarm icon disappears from the display.**

Remote Control Usage

The included remote control allows convenient operation from a distance. Ensure the battery is inserted correctly.

- **Power:** Turns the unit on or off.
- **Mute:** Silences the audio output.
- **Source:** Cycles through input sources (iPod, AUX).
- **Volume +/-:** Adjusts the audio volume.
- **Bass:** Adjusts the bass level.
- **Skip (Forward/Backward):** Navigates tracks on a docked device.
- **Play/Pause:** Controls playback for a docked device.
- **Random:** Activates random playback for a docked device.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the unit. Do not use abrasive cleaners or solvents.
- **Battery Care:** If using batteries, replace all six AA batteries simultaneously when they are depleted. Remove batteries if the unit will not be used for an extended period to prevent leakage.
- **Storage:** Store the unit in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your iLive ISP209B, refer to the following common problems and solutions:

- **No Power:** Ensure the AC adapter is securely connected to both the unit and a working power outlet. If using batteries, check that they are correctly inserted and not depleted.
- **No Audio from Docked Device:** Verify that your iPod/iPhone is securely seated in the dock. Ensure the unit's source is set to 'iPod' and the volume is turned up. Check your device's volume settings. If connection issues persist, try re-seating the device or using the auxiliary input.
- **No Audio from Auxiliary Input:** Confirm the 3.5mm audio cable is fully inserted into both the unit's AUX input and your external device. Ensure the unit's source is set to 'AUX' and the volume is turned up. Check your external device's volume.
- **Alarm Not Sounding:** Check that the alarm is activated and set to the correct time. Ensure the volume is not set to minimum. Refer to the 'Turning Off Alarms' section if you suspect the alarm has been disabled.
- **Remote Control Not Working:** Ensure there is a clear line of sight between the remote and the unit. Check and replace the remote control battery if necessary.

SPECIFICATIONS

Model Number	ISP209B
Brand	iLive Electronics
Product Dimensions	10.39 x 3.19 x 3.23 inches
Item Weight	1.04 pounds
Compatible Devices	iPod Nano, iPod Touch, iPhone (1G, 3G)
Power Source	AC Adapter or 6 x AA Batteries
Manufacturer	DPI

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact iLive Electronics customer service directly. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details.](#)

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question