Goki 55963

Goki Low Loader Toy Figure Instruction Manual

Brand: Goki | **Model:** 55963

1. Introduction

Thank you for choosing the Goki Low Loader Toy Figure. This wooden vehicle set is designed for imaginative play, featuring a low loader truck and an accompanying vehicle. Crafted with attention to detail, this toy promotes creative development and fine motor skills.

The Goki Low Loader Toy Figure is characterized by its timeless and elegant design. All parts are painted with acrylic water-based paints, ensuring safety and durability. The natural wood grain remains visible, and the wood is saliva and sweat resistant. Most figures are made of maple, with oak, beech, and birch also processed. Each figure is unique, reflecting its handmade production.



Image 1.1: The Goki Low Loader Toy Figure, featuring a red truck cab, a natural wood trailer, and a yellow loader vehicle.

2. Safety Information

Please read and understand all safety information before allowing children to play with this toy.

- **Age Recommendation:** This toy is suitable for children aged 36 months (3 years) to 96 months (8 years).
- **Choking Hazard:** Contains small parts and balls. Not suitable for children under 3 years due to potential choking hazards. Adult supervision is recommended for all young children.
- **Material Safety:** The toy is made from natural wood and painted with acrylic water-based paints that are saliva and sweat resistant. Ensure the toy is used as intended.
- **Inspection:** Regularly inspect the toy for any damage, loose parts, or splinters. Discontinue use if any damage is found to prevent injury.

3. What's in the Box

Upon unpacking, you will find the following components:

- 1 x Goki Low Loader Toy Figure (consisting of a truck, trailer, and loader vehicle)



Image 3.1: The Goki Low Loader Toy Figure as packaged, illustrating the contents within the retail box.

4. Setup

The Goki Low Loader Toy Figure requires no assembly. It is ready for play directly out of the box.

- Carefully remove the toy from its packaging.
- Ensure all packaging materials are disposed of properly and kept away from children.
- Verify that all parts of the low loader and the accompanying vehicle are intact and undamaged before play.

5. Operating Instructions

The Goki Low Loader Toy Figure is designed for push-and-play operation, encouraging imaginative scenarios.

- **Connecting the Trailer:** The low loader truck and its trailer are designed to connect securely. Align the hitch on the truck with the receiver on the trailer and gently push them together.
- **Loading the Vehicle:** The trailer features a ramp or a flatbed design suitable for transporting the accompanying loader vehicle. Position the loader onto the trailer.
- **Movement:** Push the low loader along flat surfaces. The wheels are designed for smooth movement.
- **Interactive Parts:** The loader vehicle may have moving parts, such as a scoop or articulated arm, allowing for interactive play. Operate these parts manually.
- **Creative Play:** Encourage children to create various construction or transport scenarios, enhancing their storytelling and problem-solving skills.



Image 5.1: A child engaging in play with the Goki Low Loader Toy Figure, illustrating typical use.

6. Maintenance

Proper care will ensure the longevity of your Goki Low Loader Toy Figure.

- **Cleaning:** Wipe the toy with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners, as these can damage the wood and paint finish. Dry thoroughly immediately after cleaning.
- **Storage:** Store the toy in a dry place, away from direct sunlight and extreme temperatures, to prevent warping or fading of the wood and paint.
- **Inspection:** Periodically check for any signs of wear and tear, such as loose wheels, chipped paint, or splinters. Address any issues promptly to maintain safety and functionality.

7. Troubleshooting

Most issues with this simple toy can be resolved with basic checks.

- **Wheels Not Rolling Smoothly:** Check for any debris (e.g., hair, lint) caught in the axles. Clean the wheels and axles if necessary. Ensure the toy is used on a clean, flat surface.
- **Parts Becoming Loose:** If any wooden parts feel loose, inspect for damage. If a part has detached, and it is not designed to be removable, discontinue use to prevent choking hazards.
- **Paint Chipping:** While durable, paint can chip with rough play. If chipping occurs, ensure no small pieces are ingested. Minor chips do not typically affect functionality but monitor for further deterioration.

8. Specifications

Feature	Detail
Brand	Goki
Model Number	55963
Material	Wood (Maple, Oak, Beech, Birch)

Item Dimensions (L x W x H)	10.83 x 3.94 x 6.5 inches (27.5 x 10 x 16.5 cm approx.)
Item Weight	2 Pounds (0.91 kg)
Age Range Description	36 months to 96 months
Included Components	Low loader (truck, trailer, loader vehicle)
Assembly Required	No
Batteries Required	No

9. Warranty and Support

Warranty: This Goki product comes with a 1-year warranty against manufacturer defects from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, or normal wear and tear.

Claiming Warranty: In the event of a defect covered by the warranty, please retain your proof of purchase and contact the retailer from whom the product was purchased. They will guide you through the warranty claim process.

Customer Support: For any questions, concerns, or assistance regarding your Goki Low Loader Toy Figure, please contact the retailer or visit the official Goki website for further support information.

© 2026 Goki. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question