Diversey B001W873CC

Diversey Profi Floor Cleaner & Degreaser - Gallon User Manual

Model: B001W873CC

Product Overview

The Diversey Profi Floor Cleaner & Degreaser is a neutral pH cleaning solution designed for effective and safe cleaning of rubber floors. This product is formulated to remove silicon and paraffin coatings while protecting the integrity of sensitive rubber surfaces. It is suitable for use on floors treated with manufacturer-applied silicon and paraffin wax compounds.

Image: Diversey Profi Floor Cleaner & Degreaser in a gallon container. The label indicates it is a neutral pH formula for floor cleaning.

Safety Information

Read all instructions and safety precautions before using this product. Failure to do so may result in injury or property damage.

- **Keep Out of Reach:** Store this product out of reach of children and pets.
- **Eye and Skin Contact:** Avoid direct contact with eyes and skin. In case of contact, rinse immediately and thoroughly with plenty of water. If irritation persists, seek medical attention.
- **Ingestion:** Do not ingest. If swallowed, do not induce vomiting. Drink plenty of water and seek immediate medical attention.
- **Ventilation:** Use in a well-ventilated area to avoid inhalation of vapors.
- **Protective Gear:** Wear appropriate protective gloves and eye protection when handling and applying the product.
- **Mixing:** Do not mix Diversey Profi with other cleaning agents or chemicals, as this may produce hazardous reactions.
- **Storage:** Store in a cool, dry place away from direct sunlight and incompatible materials. Keep container tightly

closed when not in use.

Product Features

- **Neutral pH Formula:** Safely cleans rubber floors without causing damage to the surface.
- **Coating Compatibility:** Works effectively on floors treated with silicon and paraffin wax compounds applied by manufacturers.
- **Rubber Flooring Protection:** Its neutral pH (approximately 8) protects sensitive rubber flooring from damage that can be caused by high pH strippers.
- **Coating Removal:** Effectively cleans floors by removing silicon and paraffin coatings while maintaining floor integrity.
- **Easy Application:** Designed for simple application using a rag or mop.
- **Professional Grade:** Gallon size provides ample supply for maintaining large rubber floor surfaces.

Preparation

Before applying Diversey Profi Floor Cleaner & Degreaser, ensure the area is properly prepared:

1. **Clear the Area:** Remove all furniture, rugs, and other items from the floor surface to be cleaned.
2. **Sweep or Vacuum:** Thoroughly sweep or vacuum the floor to remove loose dirt, dust, and debris.
3. **Ventilation:** Ensure the cleaning area is well-ventilated by opening windows or using exhaust fans.
4. **Personal Protective Equipment:** Put on appropriate protective gloves and eye protection.

Application Instructions

Follow these steps for effective cleaning of your rubber floors:

1. **Dilution:** Diversey Profi is typically used undiluted for heavy degreasing or diluted with water for general cleaning. Refer to the product label for specific dilution ratios based on the cleaning task.
2. **Apply Solution:** Apply the cleaning solution directly to the floor surface using a clean rag or mop. Ensure even coverage.
3. **Dwell Time:** Allow the solution to dwell on the surface for a few minutes to penetrate and loosen dirt and coatings. Avoid letting the solution dry on the floor.
4. **Scrub (if necessary):** For stubborn dirt or heavy degreasing, gently scrub the area with a brush or scrub pad suitable for rubber floors.
5. **Remove Solution:** Mop up the dirty solution with a clean mop or wet vacuum. Rinse the mop frequently in clean water.
6. **Rinse:** Rinse the floor thoroughly with clean water to remove any remaining cleaner residue. This is crucial to prevent streaks or slipperiness.
7. **Dry:** Allow the floor to air dry completely or use a clean, dry mop to speed up the drying process.

Post-Cleaning Care

After cleaning your rubber floors with Diversey Profi, consider the following for ongoing maintenance:

- **Regular Sweeping:** Regularly sweep or vacuum the floor to prevent accumulation of dirt and abrasive particles.
- **Spot Cleaning:** Address spills and spots promptly with a damp cloth and a small amount of diluted Diversey Profi to prevent staining.
- **Avoid Harsh Chemicals:** Continue to avoid using harsh, high-pH cleaners or abrasive tools on rubber flooring, as

these can damage the surface.

Troubleshooting

- **Issue: Streaks or Residue on Floor**

  Solution: Ensure the product is properly diluted according to instructions. Rinse the floor thoroughly with clean water after cleaning. Ensure your mop or rag is clean and rinsed frequently during the process.

- **Issue: Ineffective Cleaning / Dirt Remains**

  Solution: Verify the dilution ratio; a stronger solution may be needed for heavy soil. Allow adequate dwell time for the cleaner to work before scrubbing or wiping. Ensure the floor was properly swept or vacuumed before wet cleaning.

- **Issue: Strong Odor During/After Cleaning**

  Solution: Diversey Profi is unscented. If an odor is present, ensure the cleaning area is well-ventilated during and after use. If the odor persists, ensure no other cleaning products were mixed with Diversey Profi.

Product Specifications

Specification	Detail
Brand	Diversey
Item Form	Liquid
Scent	Unscented
Specific Uses For Product	Floor
Surface Recommendation	Rubber
Special Features	Neutral pH
Cleaning Agent Formulation	Degreaser, Detergent, Hard Surface Cleaner
Item Volume	1 Gallon
Unit Count	128.0 Fluid Ounces
UPC	807174500639
ASIN	B001W873CC

Support and Warranty

For product support, technical assistance, or inquiries regarding warranty information, please contact Diversey directly through their official website or customer service channels. Specific warranty details may vary and are typically provided by the manufacturer.

Please retain your purchase receipt for any warranty claims or product inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question