

Playskool Pals Monty

Playskool Kota and Pals Monty T-Rex User Manual

Model: Pals Monty (14258)

1. INTRODUCTION

The Playskool Kota and Pals Monty T-Rex is an interactive dinosaur toy designed to provide engaging play with lifelike movements and sounds. This manual provides instructions for setting up, operating, and maintaining your Monty T-Rex toy.

2. SAFETY INFORMATION

Please read all instructions before use. Adult supervision is recommended. Keep small parts away from young children to prevent choking hazards. Do not immerse the toy in water. Use only the recommended battery type.

3. PACKAGE CONTENTS

- 1 x Playskool Kota and Pals Monty T-Rex Figure
- 1 x Discovery Sheet

4. SETUP

4.1 Battery Installation

Monty T-Rex requires 4 C batteries for operation. Batteries are included with new products. Follow these steps to install or replace batteries:

1. Locate the battery compartment on the underside of the toy.
2. Using a Phillips head screwdriver, open the battery compartment cover.

3. Insert 4 C batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

Note: Always use fresh batteries. Do not mix old and new batteries, or different types of batteries. Remove batteries if the toy will not be used for an extended period.



Figure 1: Side view of Monty T-Rex, showing the general location of the battery compartment on the underside.

5. OPERATING INSTRUCTIONS

Monty T-Rex is designed to respond to touch and sound, bringing the dinosaur to life with various actions and noises.

5.1 Basic Interaction

- **Activation:** Once batteries are installed, Monty T-Rex is ready for interaction.
- **Walking and Roaring:** Touch Monty's back to activate stomping, roaring, and purring sounds and movements.
- **Head and Arm Movement:** Monty's arms and head move realistically during interactions.
- **Sniffing and Sneezing:** The toy features sniffing and sneezing sounds for added realism.



Figure 2: Front view of Monty T-Rex, highlighting its expressive face and movable arms.

5.2 Sound and Music Features

- **Roar Response:** Monty T-Rex will roar back when you roar at him.
- **Dino Tunes:** The toy plays three distinct