

## FurReal 93065

# FurReal Friends Cuddle Chimp Instruction Manual

Model: 93065

## 1. INTRODUCTION

---

The FurReal Friends Cuddle Chimp is an interactive electronic pet designed to provide engaging play. This realistic-looking chimpanzee responds to interaction with various sounds and movements, offering a lifelike companion experience. It is designed to hug back, make happy chimp sounds, and react to feeding and tickling.

## 2. SAFETY INFORMATION

---

- **Recommended Age:** This product is suitable for children aged 4 years and up.
- **Battery Safety:**
  - Always use 3 x 1.5V 'C' or LR14 size alkaline batteries.
  - Ensure batteries are inserted with correct polarity (+ and -).
  - Do not mix old and new batteries, or different types of batteries.
  - Remove exhausted batteries promptly.
  - Remove batteries if the toy will not be used for an extended period.
  - Non-rechargeable batteries are not to be recharged.
  - Rechargeable batteries are only to be charged under adult supervision.
  - Do not short-circuit the supply terminals.
- **Choking Hazard:** Keep small parts and accessories away from young children to prevent choking.
- **General Care:** Do not immerse the toy in water. Surface clean only.

## 3. PACKAGE CONTENTS

---

Upon opening the package, please ensure all the following items are present:

- 1 x FurReal Friends Cuddle Chimp
- 1 x Banana Bottle Accessory
- 3 x 'C' Batteries (pre-installed or included separately)



*Image: The FurReal Friends Cuddle Chimp displayed in its retail packaging, alongside its banana bottle accessory. The packaging highlights the 'TRY ME!' feature and battery requirements.*

## 4. SETUP: BATTERY INSTALLATION

---

Your Cuddle Chimp requires 3 x 1.5V 'C' or LR14 size alkaline batteries. These batteries are typically included with the product. Follow these steps to install or replace them:

1. Locate the battery compartment on the back or underside of the Cuddle Chimp.
2. Using a Phillips/cross head screwdriver (not included), carefully unscrew the battery compartment cover.
3. Remove any old batteries and dispose of them properly.
4. Insert three new 1.5V 'C' or LR14 alkaline batteries, ensuring that the positive (+) and negative (-) terminals match the markings inside the compartment.
5. Replace the battery compartment cover and secure it with the screw.
6. Once batteries are installed, the Cuddle Chimp is ready for activation.

## 5. OPERATING INSTRUCTIONS

---

The Cuddle Chimp offers several interactive features:

- **Activation:** To bring your Cuddle Chimp to life, locate and press the 'TRY ME!' button or sensor, often found on its foot as indicated on the packaging.
- **Hugging:** Give your Cuddle Chimp a hug, and it will hug you back by stretching out its arms and making happy chimp sounds.

- **Feeding:** Place the banana bottle accessory into the Cuddle Chimp's mouth. It will make slurping sounds as if it is drinking.
- **Back Stroking:** Gently stroke the Cuddle Chimp along its back to elicit various responses and sounds.
- **Tickling:** Tickle the Cuddle Chimp to hear it make excited baby chimp noises and clap its hands, indicating it is 'going bananas'.
- **Facial Expressions:** Observe the Cuddle Chimp's eyes and facial expressions as they change during interactions.

## 6. MAINTENANCE

---

- **Cleaning:** To clean your Cuddle Chimp, use a soft, damp cloth to wipe its surface. Do not use harsh chemicals or abrasive cleaners. Do not immerse the toy in water.
- **Storage:** Store the Cuddle Chimp in a clean, dry place away from direct sunlight and extreme temperatures. For long-term storage, it is recommended to remove the batteries to prevent leakage.
- **Hair Care:** The Cuddle Chimp's fur may shed slightly, especially with initial use. Gently brush the fur if needed.

## 7. TROUBLESHOOTING

---

- **Chimp is not responding or movements are weak:**
  - Check that the batteries are correctly installed with the proper polarity.
  - Replace the batteries with fresh 1.5V 'C' or LR14 alkaline batteries.
  - Ensure the toy's power switch (if present) is in the 'ON' position.
- **Sounds are distorted or intermittent:**
  - This often indicates low battery power. Replace the batteries.
- **Mechanical sounds are audible during operation:**
  - Some mechanical sounds are normal as the internal mechanisms operate the toy's movements. If sounds are excessively loud or unusual, ensure no obstructions are present.

## 8. SPECIFICATIONS

---

<b>Product Dimensions</b>	10 x 11 x 12 inches
<b>Item Weight</b>	1 pound
<b>Model Number</b>	93065
<b>Recommended Age</b>	4 years and up
<b>Batteries Required</b>	3 x 1.5V 'C' or LR14 alkaline batteries (included)
<b>Manufacturer</b>	Hasbro

## 9. WARRANTY AND SUPPORT

---

For warranty information or technical support regarding your FurReal Friends Cuddle Chimp, please refer to the documentation included with your purchase or contact the manufacturer, Hasbro, directly through their official customer service channels. Specific warranty terms may vary by region and purchase date.

