

[Manuals.plus](#) /

› [Intex](#) /

› Intex Filter Cartridge Type A (59900E) - Replacement Type A and C For Easy Set Pool Filters - 12 Pack

Intex 29000E

Intex Filter Cartridge Type A/C Instruction Manual

Model: 29000E (Also compatible with 59900E)

1. INTRODUCTION

This manual provides essential information for the proper use and maintenance of your Intex Filter Cartridge Type A/C. Designed for Intex Easy Set Pool Filters, these cartridges are crucial for maintaining clean and clear pool water. Please read this manual thoroughly before installation and use.

2. PRODUCT OVERVIEW

The Intex Filter Cartridge Type A/C (Model 29000E, compatible with 59900E) is a genuine replacement filter designed to work seamlessly with various Intex filter pumps. Each cartridge is made from durable Dacron filter material, engineered for effective filtration and easy cleaning.

Key features include:

- Genuine Intex Type A filter cartridges.
- Constructed from easy-to-clean Dacron filter material.
- Designed for optimal filtration to keep pool water sparkling clean.



Figure 2.1: A 12-pack of Intex Filter Cartridges Type A/C.




Figure 2.2: Side view of an Intex Type A/C filter cartridge, showing the pleated filter material.

3. SETUP AND INSTALLATION

These filter cartridges are designed for easy replacement in compatible Intex filter pumps. Always refer to your specific filter pump's owner's manual for detailed installation instructions and safety precautions.

Compatible Pump Models:

- 530 GPH, 1,000 GPH, and 1,500 GPH Filter Pumps.
- Specifically compatible with pump models: 58603E, 58604E, 56635E, 56636E, 56637E, 56638E & 58623.

General Installation Steps:

1. **Turn off and unplug** your filter pump from the power source.
2. **Close the plunger valves** on your pool's inlet and outlet to prevent water flow.
3. **Unscrew the filter housing collar** and remove the top cover.
4. **Remove the old, dirty filter cartridge.**
5. **Insert the new Intex Type A/C filter cartridge** into the filter housing, ensuring it seats properly.
6. **Replace the top cover and tighten the collar securely.**
7. **Open the plunger valves** and plug in the filter pump to resume operation.

INTEX®

FILTER CARTRIDGE CARTUCHO DE FILTRO



*Model/Modelos
603 & 604/G*



*Model/Modelos
635T & 636T/G*



*Model/Modelos
637R & 638R/G*



*Model/Modelos CS7111
& CS7221/7231,
EC07111 &
EC07221/7231*



CAUTION

FOR USE BY ADULTS ONLY. READ AND
FOLLOW FILTER PUMP OWNER'S MANUAL.



ADVERTENCIA

One Cartridge Un Cartucho

LEA Y SIGA EL MANUAL DEL PROPIETARIO ADJUNTO.
EL PRODUCTO SÓLO DEBE SER UTILIZADO POR
ADULTOS.

INTEX®

©2015 Intex Marketing Ltd. – Intex Development Co., Ltd. -
Intex Trading Ltd.- Intex Recreation Corp.
All rights reserved./ Todos los derechos reservados.
®™ Trademarks used in some countries of the world under
license from Intex Marketing Ltd./ ®™ Marcas registradas usadas
en algunos países del mundo bajo licencia de Intex Trading Ltd.,
Intex Development Co., Ltd., G.P.O Box 28829, Hong Kong &
Intex Recreation Corp., P.O. Box 1440, Long Beach, CA 90801
Made in China / Hecho En China www.intexcorp.com

#29000E



*Manufactured by / Fabricado por
Intex Industries (Xiamen) Co., Ltd.,
Xiamen, Fujian, P.R.C.*

Figure 3.1: Packaging of the Intex Filter Cartridge, highlighting its compatibility with different pump models (Model 29000E shown).

4. OPERATING THE FILTER SYSTEM

Once installed, the filter cartridge works by trapping debris and impurities as water passes through its pleated Dacron material. For optimal water clarity, ensure your filter pump runs for an adequate duration each day, typically 8-12 hours, depending on pool size and usage.

5. MAINTENANCE

Regular cleaning and timely replacement of your filter cartridge are essential for efficient pool filtration and longevity of your pump.

Cleaning the Cartridge:

The Dacron filter material is designed to be easy to clean. To clean, remove the cartridge from the pump (following the first four steps of installation in Section 3) and rinse it thoroughly with a garden hose. A high-pressure nozzle can help dislodge trapped debris from the pleats. Do not use harsh chemicals or stiff brushes, as these can damage the filter material.

Replacement Schedule:

For best results and to maintain sparkling clean pool water, it is recommended to replace the filter cartridge every two weeks. Depending on pool usage, water quality, and environmental factors, more frequent cleaning or replacement may be necessary.



Figure 5.1: Top view of the filter cartridge, illustrating its design for efficient water flow and debris capture.

6. TROUBLESHOOTING

If you experience issues with your pool's filtration, consider the following common troubleshooting steps related to the filter cartridge:

- **Reduced Water Flow:** This is often an indication of a clogged filter cartridge. Remove and thoroughly clean or replace the cartridge.
- **Cloudy Pool Water:** While multiple factors can cause cloudy water, a dirty or old filter cartridge can contribute. Ensure the cartridge is clean and replaced regularly. Also, check if the pump is running for sufficient hours.
- **Pump Not Priming:** Ensure the filter cartridge is correctly seated in the housing and the housing lid is securely tightened. Air leaks can prevent the pump from priming.

For persistent issues, consult your filter pump's owner's manual or contact Intex customer support.

7. SPECIFICATIONS

Below are the technical specifications for the Intex Filter Cartridge Type A/C:

Attribute	Value
Product Model Number	29000E (Also known as 59900E)
Material	Dacron
Dimensions (Single Cartridge)	8"H x 4.25"W (4.25" OD x 8.25" Long x 2" ID)

Attribute	Value
Compatible Devices	Intex Pool Filter Pumps (530, 1000, 1500 GPH models)
Reusability	Reusable (through cleaning)




Figure 7.1: Dimensions of the Intex Type A/C filter cartridge.

8. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the official Intex website or contact Intex customer service directly. Keep your purchase receipt as proof of purchase. You can visit the official Intex Store for more products and support:[Intex Store on Amazon](#).

© 2025 Intex Recreation Corp. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question