GoodCook 04550

GoodCook Everyday Nonstick Baking Sheet Set

Model: 04550

Introduction

The GoodCook Everyday Nonstick Baking Sheet Set is designed to simplify your baking and cooking experience. This versatile 3-piece set includes baking sheets in three convenient sizes: 13 inches x 9 inches, 15 inches x 10 inches, and 17 inches x 11 inches. Crafted from heavy-duty carbon steel, these pans are engineered to resist warping and ensure even heat distribution for consistent baking results. The superior nonstick coating facilitates easy food release and quick cleanup, making them ideal for a variety of culinary tasks, from baking cookies to roasting vegetables.



Image: The GoodCook Everyday Nonstick Baking Sheet Set, featuring the small, medium, and large pans.

Product Features

- **Set of 3 Baking Sheets:** Includes one small (13" x 9"), one medium (15" x 10"), and one large (17" x 11") baking sheet to accommodate various baking needs.
- **Even Bake, Every Time:** Heavy-duty carbon steel construction ensures long-lasting durability and promotes even heat distribution for thorough and consistent baking.
- **Durable Carbon Steel:** Constructed from robust carbon steel material, these pans resist warping and scratching, ensuring extended daily use in your kitchen.
- **Scratch-Resistant Nonstick Coating:** Features a high-quality nonstick coating for effortless food release and simplified cleanup. This exclusive GoodCook formula offers enhanced performance.
- **Metal Utensil Safe:** Designed to withstand the use of metal utensils without compromising the nonstick surface, providing bakery-quality results.



Image: A visual representation of the three baking sheet sizes included in the set.



Image: Cookies baked on two GoodCook nonstick sheets, demonstrating easy release and clean surface.

Setup

Before first use, wash the baking sheets thoroughly with warm, soapy water. Rinse completely and dry immediately to prevent water spots. It is recommended to lightly grease the pan with butter, shortening, or cooking spray for the first few uses, even with the nonstick coating, to help condition the surface.

Operating Instructions

These baking sheets are suitable for use in conventional ovens. Always preheat your oven to the desired temperature before placing the baking sheets inside. The carbon steel construction ensures even heat distribution, which is crucial for consistent baking and roasting. The nonstick surface allows for easy removal of baked goods and roasted items.

- For optimal results, avoid using temperatures exceeding 450°F (232°C).

- When baking multiple items, ensure adequate space between them for proper air circulation and even cooking.
- The assorted sizes allow for flexibility; use the smaller pans for individual portions or side dishes, and the larger pan for bigger batches of cookies or sheet pan meals.



Image: Cookies baked evenly on a GoodCook baking sheet.



Image: A baking sheet with cookies being taken out of an oven, showcasing its durability and metal utensil compatibility.

Your browser does not support the video tag. Please update your browser or use a different device to view this content.

Video: Overview of the GoodCook Everyday Nonstick Steel 3-piece Baking Sheet Set, demonstrating its features and versatility for various baking tasks.

Your browser does not support the video tag. Please update your browser or use a different device to view this content.

Video: A detailed look at the GoodCook Premium 3-Piece Cookie Sheet Set, highlighting its quality and suitability for baking.

Maintenance and Care

Proper care will extend the life and performance of your GoodCook Nonstick Baking Sheets.

- **Cleaning:** The nonstick bakeware set is dishwasher safe for convenience. However, hand washing with warm, soapy water and a soft sponge is recommended for longer-lasting use and to preserve the nonstick coating. Avoid abrasive cleaners or scouring pads that can damage the

surface.

- **Drying:** Dry the baking sheets thoroughly immediately after washing to prevent water spots and potential rust, especially on the edges.
- **Storage:** Store the pans carefully to prevent scratching the nonstick surface. If stacking, place a soft cloth or paper towel between each pan.
- **Avoid Sharp Objects:** While metal utensil safe, extreme care should be taken with sharp objects like knives, which can still scratch the nonstick surface.

Troubleshooting

- **Food Sticking:** Ensure the pan is clean and lightly greased, especially for the first few uses or if the nonstick performance seems to diminish. Overheating can also affect nonstick properties.
- **Uneven Baking:** Verify your oven temperature with an oven thermometer. Ensure the pans are not overcrowded and there is adequate space for air circulation.
- **Warping:** While designed to resist warping, extreme temperature changes (e.g., placing a hot pan directly into cold water) can cause thermal shock. Allow pans to cool before washing.

Specifications

Feature	Detail
Brand	GoodCook
Model Number	04550
Material	Alloy Steel (Carbon Steel)
Color	Dark Gray
Sizes Included	13" x 9", 15" x 10", 17" x 11" (Assorted 3-Piece Set)
Product Dimensions	19.6"L x 12.6"W x 6.8"H (Overall packaging/nested dimensions)
Item Weight	0.25 Kilograms (approx. 8.8 ounces)
Dishwasher Safe	Yes (Hand wash recommended for longevity)
Material Type Free	PTFE Free
Specific Use	Cookie, Baking




Image: A GoodCook baking sheet with a visual representation of its width measurement.

Warranty and Support

The GoodCook Everyday Nonstick Baking Sheet Set comes with a **Limited Lifetime Warranty**. For specific details regarding warranty coverage, claims, or product support, please refer to the manufacturer's official website or contact GoodCook customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance, visit the GoodCook Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question