

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BRIО](#) /

› [BRIО World 33698 Clever Crane Wagon Set - Instruction Manual](#)

## BRIO 33698

# BRIO World 33698 Clever Crane Wagon Set

## INSTRUCTION MANUAL



### Introduction

This manual provides essential information for the safe and proper use of your BRIO World 33698 Clever Crane Wagon Set. Please read these instructions carefully before assembly and operation. This set is designed to encourage imaginative play and is compatible with other BRIO railway toys.

### Product Components

The BRIO World 33698 Clever Crane Wagon Set includes the following 4 pieces:

- 1x Crane Car
- 1x Wagon
- 2x Load (magnetic rock)


4  
PIECES



x 1



x 1



x 1

Image: All components included in the set.

## Setup

---

To set up your Clever Crane Wagon Set:

- 1. Unpack Components:** Carefully remove all pieces from the packaging.
- 2. Assemble Wagon:** Place one magnetic rock load onto the green wagon base. The magnetic connection will secure it.
- 3. Connect Cars:** Use the magnetic connectors on the front and back of the crane car and wagon to link them together. Ensure a secure connection for smooth operation on tracks.



Image: The crane car and wagon assembled and ready for play.

## Operating Instructions

---

The Clever Crane Wagon Set offers interactive features for engaging play:

- **Crane Operation:** The crane features a rotating cabin and an adjustable boom. Turn the orange knob on the side of the crane to move the boom up and down.
- **Magnetic Lifting:** The crane's hook is magnetic, allowing it to lift and move the magnetic rock loads. Position the crane over a load, lower the hook, and the magnet will attach.
- **Loading and Unloading:** Once a load is attached, rotate the crane cabin and adjust the boom to place the load onto the wagon or another desired location.
- **Wagon Functionality:** The wagon has removable sides, allowing for versatile loading and unloading of various cargo items.
- **Compatibility:** This set is fully compatible with all other BRIO railway toys, enabling expansion of your railway system.



Image: The crane in action, demonstrating its lifting capability.



Image: The crane car and wagon with cargo.

## Maintenance

To ensure the longevity of your BRIO World Clever Crane Wagon Set:

- **Cleaning:** Wipe the wooden and plastic parts with a damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the set in a dry place away from direct sunlight and extreme temperatures to prevent warping or damage to the wood.
- **Inspection:** Periodically check for any loose parts or signs of wear. Discontinue use if any damage is found and contact customer support if necessary.

## Troubleshooting

If you encounter any issues with your Clever Crane Wagon Set, consider the following:

- **Magnets Not Connecting:** Ensure that the magnetic surfaces are clean and free from debris. Verify that the cars are aligned correctly for connection.
- **Wheels Not Rolling Smoothly:** Check for any obstructions in the wheels or axles. Clean any dust or small particles that may be hindering movement.
- **Crane Movement Issues:** If the crane's boom or rotation is stiff, ensure no foreign objects are lodged in the mechanism. Avoid forcing movement.

## Specifications

Product Dimensions	5.91 x 1.18 x 2.76 inches
Item Weight	5.8 ounces
Model Number	33698
Manufacturer Recommended Age	36 months - 10 years
Material	FSC-certified Beech Wood, Plastic






Image: Approximate size of the crane car in hand.

## Warranty and Support

BRIO is committed to producing high-quality, safe, and durable toys. For detailed warranty information, product support, or to contact customer service, please refer to the official BRIO website or the contact information provided on the product packaging. Always ensure to purchase from authorized retailers to guarantee product authenticity and warranty coverage.

## Related Documents - 33698

	<p><b><a href="#">BRIO World Remote Control Travel Train Troubleshooting Guide</a></b></p> <p>Provides essential troubleshooting steps for the BRIO World Remote Control Travel Train, helping users resolve issues related to infrared control, channel synchronization, remote operation, and battery performance.</p>
	<p><b><a href="#">BRIO Lift &amp; Load Warehouse Set 33887 Assembly Instructions</a></b></p> <p>Detailed assembly instructions and layout suggestions for the BRIO Lift &amp; Load Warehouse Set 33887, a wooden toy train accessory from BRIO.</p>
	<p><b><a href="#">BRIO Battery-Operated Steaming Train - User Manual and Instructions</a></b></p> <p>Comprehensive guide for the BRIO Battery-Operated Steaming Train (model 33884). Learn how to install batteries, operate the train, generate steam, and understand safety precautions. Includes tips for optimal play and maintenance.</p>
	<p><b><a href="#">BRIO Builder Motor Set 34591: Inspiration and Assembly Guide</a></b></p> <p>Explore the BRIO Builder Motor Set 34591 with this inspiration booklet. Learn how to assemble various models using the included parts and motor unit, with instructions and safety information.</p>
	<p><b><a href="#">BRIO Rote Lola 33592: Questions and Answers</a></b></p> <p>Find answers to common questions about the BRIO Rote Lola 33592 toy train, including operation, troubleshooting, and battery replacement. This guide provides information on how to use, maintain, and resolve issues with the toy.</p>
	<p><b><a href="#">BRIO Remote Control Train - User Manual and Operating Instructions</a></b></p> <p>Comprehensive guide for the BRIO Remote Control Train, covering operation, battery installation, safety precautions, and FCC compliance. Learn how to set up and enjoy your BRIO RC train.</p>