

Gold N Hot GH5135V1

Gold N Hot Elite 1875 Watt Ionic Full Hood Professional Hair
Dryer Instruction Manual

Model: GH5135V1

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, burns, fire, or injury to persons:

- Keep out of reach of children.
- Do not use near water or while bathing.
- Always unplug the hair dryer when not in use.
- Do not use a damaged power cord.
- Allow the hair dryer to cool before storing.
- Keep the power plug and cord away from heated surfaces.

PRODUCT OVERVIEW

The Gold N Hot Elite 1875 Watt Ionic Full Hood Professional Hair Dryer is designed for efficient, hands-free hair drying and conditioning treatments. Its powerful 1875 watts ensure a forceful airflow for salon-quality results.

Key Features:

- Ionic technology reduces frizz, promoting healthier-looking, shiny, and silky hair.
- 1875-Watt motor provides powerful airflow for fast styling.
- Four heat/speed combinations offer versatile styling options for all hair types.
- Full-sized hood accommodates large rollers, with double vents for even heat distribution.



Image: Gold N Hot Elite 1875 Watt Ionic Full Hood Professional Hair Dryer. The dryer features a black hood with gold speckles and a white base, designed for hands-free hair drying.

SETUP INSTRUCTIONS

Follow these steps to safely set up your bonnet dryer:

1. Pull the latch outward, then lower the latch and hold it in place while raising the bonnet.
2. While holding the bonnet latch handle, push the neck latch down until the bonnet contacts the neck, then release the latch to secure the bonnet in place.
3. To lower the bonnet for storage, hold the bonnet by the handle while moving the neck latch down.
4. Release the neck latch and fold the bonnet down.

5. Ensure the bonnet is tightly secured by the front and back latches.



Image: Close-up of the dryer's base, showing the latch and neck adjustment mechanism for setting up and storing the hood. The base also displays illustrated instructions for assembly.

OPERATING INSTRUCTIONS

To operate your Gold N Hot Elite Hair Dryer:

1. Ensure the dryer is placed on a stable, flat surface.
2. Plug the power cord into a suitable electrical outlet.
3. Adjust the hood height to comfortably fit over your head and rollers.
4. Select your desired heat and speed setting using the controls located on the unit. The dryer offers four heat/speed combinations for

customized drying.

- 5. For optimal results, ensure hair is evenly distributed under the hood.
- 6. After use, turn off the dryer and unplug it from the outlet. Allow it to cool completely before storing.

Your browser does not support the video tag.

Video: A seller demonstrates the features and operation of a full hood professional hair dryer, including adjusting the hood and showing the control panel. This video provides a visual guide to using the Gold N Hot Elite Hair Dryer.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your hair dryer:

- Always unplug the dryer before cleaning.
- Wipe the exterior of the dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Regularly check the air intake and exhaust vents for any lint or hair buildup. Clean them gently with a soft brush or vacuum cleaner attachment to maintain proper airflow.
- Do not immerse the dryer in water or any other liquid.
- Store the dryer in a cool, dry place when not in use. Ensure the cord is not wrapped tightly around the unit, which can cause damage.

SPECIFICATIONS

Feature	Detail
Brand	Gold N Hot
Model Number	GH5135V1
Wattage	1875 Watts
Power Source	Corded Electric
Product Dimensions	14 x 14.25 x 14 inches
Item Weight	2 Pounds
Material	Plastic
Color	Gold
Manufacturer	Helen of Troy

WARRANTY AND SUPPORT

The Gold N Hot Elite 1875 Watt Ionic Full Hood Professional Hair Dryer comes with a one-year Limited Warranty, guaranteeing dependable performance and consistent results. For warranty claims or technical support, please refer to the contact information provided in your product packaging or visit the official Gold N Hot website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0027ZCA4K>

More documents and user manuals: **<https://manuals.plus/>**