

Brother SA132

Brother SA132 Quilting Guide Instruction Manual

Model: SA132

INTRODUCTION

The Brother SA132 Quilting Guide is an accessory designed to assist in creating precise, parallel stitch lines for quilting and other sewing projects. This guide attaches to your sewing machine's presser foot ankle or walking foot, allowing for consistent spacing between stitch rows.

It is a genuine Brother accessory, compatible with all 7mm feed dog machines, and offers easy adjustment for various measurement changes.

SETUP AND INSTALLATION

Follow these steps to properly install the Brother SA132 Quilting Guide onto your sewing machine:

1. **Identify the Guide Hole:** Locate the small guide hole on the back of your sewing machine's presser foot ankle or walking foot. This hole is specifically designed for accessories like the quilting guide.
2. **Insert the Guide Bar:** Gently slide the straight metal bar of the SA132 Quilting Guide into this guide hole. Ensure it is inserted securely.
3. **Adjust Position:** The guide should slide freely left and right within the hole. Position it to the desired distance from your needle, which will determine the spacing of your parallel stitch lines.
4. **Verify Stability:** Ensure the guide is stable and does not interfere with the needle or other moving parts of the sewing machine.



Image: The Brother SA132 Quilting Guide installed on a sewing machine, actively being used to sew parallel lines on blue fabric. The guide's bar is inserted into the presser foot, and its curved end runs along a previously sewn stitch line, ensuring even spacing for the current stitch.

OPERATING INSTRUCTIONS

Once the quilting guide is installed, follow these steps for effective use:

1. **Set Initial Stitch:** Sew your first line of stitches on your fabric as a reference.
2. **Position the Guide:** Adjust the SA132 Quilting Guide so that its curved end runs along the previously sewn stitch line. The distance between the needle and the guide's end will be the spacing for your new

stitch line.

- 3. **Sew Parallel Lines:** Begin sewing, keeping the guide's end consistently aligned with the previous stitch line. This will ensure your new stitch line is perfectly parallel and evenly spaced.
- 4. **Adjust Spacing:** To change the spacing between stitch lines, simply slide the guide bar left or right within the presser foot's guide hole before sewing the next line.

This method allows for quick and accurate creation of multiple parallel stitch lines, ideal for quilting, topstitching, and decorative sewing.

MAINTENANCE

To ensure the longevity and optimal performance of your Brother SA132 Quilting Guide:

- **Cleaning:** Periodically wipe the guide with a soft, dry cloth to remove any lint or dust accumulation. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the guide in a clean, dry place when not in use to prevent damage or loss.
- **Inspection:** Regularly inspect the guide for any signs of wear or damage. If the guide becomes bent or broken, it may affect stitching accuracy and should be replaced.

TROUBLESHOOTING

If you encounter issues while using the Brother SA132 Quilting Guide, consider the following:

- **Uneven Stitching:** Ensure the guide is securely inserted into the presser foot's guide hole and that you are consistently aligning it with the previous stitch line. Check that the fabric is feeding smoothly.
- **Guide Not Fitting:** Verify that your sewing machine's presser foot ankle or walking foot has a compatible guide hole. The SA132 is designed for specific Brother models and 7mm feed dog machines. Refer to the "Compatible Models" section.
- **Difficulty Sliding:** If the guide does not slide smoothly, check for any obstructions in the guide hole or on the guide bar itself. Clean as necessary.

For persistent issues, consult your sewing machine's manual or contact Brother customer support.

SPECIFICATIONS

Feature	Detail
Model Number	SA132
Brand	Brother
Material	Plastic
Style	Compact
Product Dimensions	4.52"L x 3.18"W
Item Weight	0.32 ounces
Set Name	Brother SA Series

COMPATIBLE SEWING MACHINE MODELS

The Brother SA132 Quilting Guide is designed to fit the guide hole on the presser foot ankle or walking foot of various Brother sewing machines, including but not limited to:

- Brother PE770
- Brother LS2125i
- Brother XL2230
- Brother XL2600i
- Brother XL2610
- Brother XL3510
- Brother XL3750
- Brother ES2000
- Brother CP6500
- Brother CP7500
- Brother 1034D
- Brother PC210PRW
- Brother PC420PRW
- Brother SE400
- Brother LB6800PRW

This guide is also generally compatible with all Brother sewing machines featuring a 7mm feed dog system and an appropriate guide hole on the presser foot or walking foot.

WARRANTY INFORMATION

For specific warranty details regarding the Brother SA132 Quilting Guide, please refer to the warranty documentation included with your original purchase or visit the official Brother support website. Warranty terms typically cover manufacturing defects for a specified period.

CUSTOMER SUPPORT

If you require further assistance, have questions about installation, operation, or compatibility, please contact Brother customer support. You can typically find contact information on the official Brother website or in your sewing machine's user manual.

Online Resources: Visit the [Brother Store on Amazon](#) for additional product information and accessories.