

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Acctim](#) /

› [Acctim Wall Clock Model 93/723BRC Instruction Manual](#)

Acctim 93/723BRC

Acctim Wall Clock Model 93/723BRC Instruction Manual

Your guide to setting up and maintaining your Acctim Radio Controlled Wall Clock.

PRODUCT OVERVIEW

The Acctim Wall Clock Model 93/723BRC is a 26.5 cm (10.43 inch) radio-controlled analog wall clock designed for indoor use. It features a black case, an easy-to-read Arabic dial with 12/24 hour markings, and an energy-efficient movement. This clock automatically synchronizes with the atomic time signal, ensuring precise timekeeping and eliminating the need for manual time adjustments, including daylight saving changes. Please note that the radio control function is specifically designed for the UK and Ireland time signal.



Image: Front view of the Acctim Wall Clock, Model 93/723BRC. The clock features a black frame, a white dial, and clear black Arabic numerals for easy readability. The hands are black, and the clock has a classic round design.

SETUP INSTRUCTIONS

- Unpacking:** Carefully remove the clock from its packaging. Inspect for any damage.
- Battery Installation:** Locate the battery compartment on the back of the clock. Insert one (1) AA battery, ensuring the polarity (+ and -) matches the indicators inside the compartment.
Note: An AA battery is required and is not included with the product.
- Initial Synchronization:** After inserting the battery, the clock hands will automatically move to the 12 o'clock position and then begin searching for the radio time signal. This process can take several minutes to several hours, depending on your location and signal strength.
 - For best reception, place the clock near a window, away from electronic devices that may cause interference.
 - The radio control function is optimized for reception within the UK and Ireland. Operation outside these regions may

result in the clock not synchronizing automatically.

4. **Mounting:** Once the clock has set itself to the correct time, choose a suitable indoor location for wall mounting. Use a secure hook or screw appropriate for your wall type.

OPERATING INSTRUCTIONS

The Acctim Wall Clock is designed for automatic operation once the battery is installed and the radio signal is received. No manual time setting is typically required.

- **Automatic Time Adjustment:** The clock will automatically adjust for Daylight Saving Time (Summer/Winter time changes) within the UK and Ireland signal range.
- **Signal Reception:** The clock periodically attempts to receive the radio time signal to maintain accuracy. If the signal is lost or weak, the clock will continue to run on its internal quartz movement until a signal is re-established.
- **12/24 Hour Dial:** The clock features an Arabic dial that displays both 12-hour and 24-hour markings for versatile time reading.

MAINTENANCE

- **Cleaning:** To clean the clock, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the finish or internal components.
- **Battery Replacement:** Replace the AA battery annually, or when the clock hands stop moving or begin to lose time. Always use a fresh, high-quality AA alkaline battery. Dispose of used batteries responsibly.
- **Environmental Conditions:** This clock is designed for indoor use only. Avoid exposing it to extreme temperatures, direct sunlight, high humidity, or dusty environments.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not running or hands stuck.	Dead or incorrectly installed battery.	Check battery polarity. Replace with a fresh AA battery.
Clock shows incorrect time.	Poor radio signal reception or outside UK/Ireland.	<ul style="list-style-type: none">• Relocate the clock closer to a window or an external wall.• Ensure no electronic devices are causing interference nearby.• If outside UK/Ireland, the radio control feature may not function. The clock will operate as a standard quartz clock, but manual time setting is not available.• Remove battery, wait 1 minute, reinsert to force a new signal search.
Clock does not adjust for Daylight Saving Time.	Poor radio signal reception or outside UK/Ireland.	<ul style="list-style-type: none">• Ensure good signal reception (see above).• This feature relies on the radio signal, which is specific to UK/Ireland time zones.

SPECIFICATIONS

Model Number	93/723BRC
--------------	-----------

Brand	Acctim
Type	Radio Controlled Wall Clock
Display Type	Analog
Color	Black
Diameter	26.5 cm (10.43 inches)
Material	Plastic (Frame)
Power Source	1 x AA Battery (not included)
Mounting Type	Wall Mount
Item Weight	0.39 kg (13.7 ounces)
Radio Control Region	UK and Ireland only

WARRANTY INFORMATION

This Acctim product is backed by a **1-year guarantee** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accidents, unauthorized repairs, or normal wear and tear. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries, please contact Acctim Customer Service. Refer to the packaging or the official Acctim website for the most current contact information.

Please note: The radio control feature of this clock is designed to receive signals within the UK and Ireland. Performance may vary or be unavailable in other regions.

