

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [BRIO](#) /
- › [BRIO World - 33697 Speedy Bullet Train Instruction Manual](#)

BRIO 33697

BRIO World - 33697 Speedy Bullet Train

Instruction Manual
Model: 33697 | Brand: BRIO

INTRODUCTION

The BRIO World 33697 Speedy Bullet Train is an engaging 2-piece wooden toy train set designed to stimulate imagination and enhance fine motor skills in children aged 3 and up. This set is a perfect addition to any BRIO railway system, offering seamless compatibility and endless play possibilities. Crafted with attention to detail and safety, it provides a durable and enjoyable play experience.



Image: The Speedy Bullet Train, featuring its sleek design and magnetic connectors.

WHAT'S IN THE BOX

Your BRIO World 33697 Speedy Bullet Train set includes the following components:

- **1x Train Engine:** The main locomotive with multiple wheels and a front magnetic connector.
- **1x Wagon (Tender):** A coal tender wagon that connects magnetically to the engine.



Image: The Speedy Bullet Train set as packaged, showing both the engine and tender.

SETUP

The Speedy Bullet Train is designed for immediate play with minimal setup. It is compatible with all BRIO wooden railway tracks and other BRIO railway toys.

1. **Unpack:** Carefully remove the train engine and wagon from their packaging.
2. **Connect:** The engine and wagon feature magnetic connectors. Simply bring the magnetic ends of the engine and tender close together, and they will snap into place. Ensure the magnets are properly aligned for a secure connection.
3. **Place on Track:** Position the train set onto any standard BRIO wooden railway track. Ensure all wheels are properly seated within the track grooves.

OPERATING INSTRUCTIONS

The Speedy Bullet Train is a push-along toy, designed for manual operation and imaginative play.

- **Manual Movement:** Gently push the train along the wooden tracks. The wheels are designed for smooth movement, allowing for easy navigation around curves and inclines.
- **Adding Cars:** The magnetic connector at the rear of the tender allows for additional BRIO railway cars or wagons to be attached, expanding your train's length and play scenarios.
- **Creative Play:** Encourage children to create their own railway adventures, developing storytelling and problem-solving skills as they build layouts and operate their trains.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your Speedy Bullet Train, follow these simple care guidelines:

- **Cleaning:** Wipe the train with a damp cloth to remove dust and dirt. Avoid using harsh chemicals or abrasive cleaners, as these may damage the paint or wood finish.
- **Drying:** Ensure the train is completely dry before storing to prevent moisture damage to the wood.
- **Storage:** Store the train in a dry place, away from direct sunlight or extreme temperatures, which can cause warping or fading.
- **Inspection:** Periodically check for any loose parts or damage. While BRIO toys are built to be sturdy, regular inspection helps ensure continued safe play.

TROUBLESHOOTING

Most issues with the Speedy Bullet Train can be resolved with simple checks:

- **Train Not Rolling Smoothly:**
 - Check if any debris (e.g., dust, hair) is caught in the wheels. Clean as necessary.
 - Ensure the train is properly aligned on the track and all wheels are within the grooves.
- **Magnetic Connectors Not Holding:**
 - Verify that the magnetic ends are clean and free from obstructions.
 - Ensure the magnets are facing each other correctly (they will repel if facing the wrong way).

SAFETY INFORMATION

BRIO toys are designed with the highest safety standards. Please observe the following:

- **Age Recommendation:** Suitable for children aged 36 months to 10 years. Small parts may be a choking hazard for younger children.
- **Materials:** Made from durable wood, plastic, and metal components. All materials are non-toxic and safe for children. BRIO ensures over 1,000 safety tests annually.
- **Supervision:** Adult supervision is recommended during play, especially with younger children, to ensure safe interaction with the toy and other play elements.

SPECIFICATIONS







Product Dimensions	7.48 x 1.18 x 1.97 inches
Item Weight	6.7 ounces
Item Model Number	33697
Manufacturer Recommended Age	36 months - 10 years
Materials	Wood, Plastic, Metal (FSC Certified Materials)
Release Date	May 8, 2012

WARRANTY AND SUPPORT

BRIO stands behind the quality of its products. For specific warranty information or support inquiries, please refer to the official BRIO website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

© 2024 BRIO. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Related Documents - 33697

	<p>BRIO World Remote Control Travel Train Troubleshooting Guide</p> <p>Provides essential troubleshooting steps for the BRIO World Remote Control Travel Train, helping users resolve issues related to infrared control, channel synchronization, remote operation, and battery performance.</p>
	<p>BRIO Lift & Load Warehouse Set 33887 Assembly Instructions</p> <p>Detailed assembly instructions and layout suggestions for the BRIO Lift & Load Warehouse Set 33887, a wooden toy train accessory from BRIO.</p>
	<p>BRIO Builder Motor Set 34591: Inspiration and Assembly Guide</p> <p>Explore the BRIO Builder Motor Set 34591 with this inspiration booklet. Learn how to assemble various models using the included parts and motor unit, with instructions and safety information.</p>
	<p>BRIO Rote Lola 33592: Questions and Answers</p> <p>Find answers to common questions about the BRIO Rote Lola 33592 toy train, including operation, troubleshooting, and battery replacement. This guide provides information on how to use, maintain, and resolve issues with the toy.</p>
	<p>BRIO Battery-Operated Steaming Train - User Manual and Instructions</p> <p>Comprehensive guide for the BRIO Battery-Operated Steaming Train (model 33884). Learn how to install batteries, operate the train, generate steam, and understand safety precautions. Includes tips for optimal play and maintenance.</p>
	<p>BRIO Remote Control Train - User Manual and Operating Instructions</p> <p>Comprehensive guide for the BRIO Remote Control Train, covering operation, battery installation, safety precautions, and FCC compliance. Learn how to set up and enjoy your BRIO RC train.</p>