Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Schylling GBB

Schylling Classic Retro Gumball Coin Bank

Model: GBB

1. Introduction

Thank you for choosing the Schylling Classic Retro Gumball Coin Bank. This product combines the fun of a gumball machine with the practicality of a coin bank, encouraging saving while providing a sweet reward. Designed for ages 3 and up, this durable plastic unit is a classic addition to any space.



Figure 1: Schylling Classic Retro Gumball Coin Bank.

2. Safety Information

WARNING: CHOKING HAZARD – Small parts. Not for children under 3 years.
Ensure all small parts, including gumballs, are kept away from young children who may put them in their mouths. Adult supervision is recommended during use, especially when refilling or retrieving coins.

3. Parts of the Gumball Bank

- **Gumball Globe:** Clear plastic sphere that holds the gumballs.
- **Top Cover:** Red, removable cap for refilling gumballs.
- **Coin Slot:** Opening for inserting coins.
- **Dispensing Knob:** Turn to release a gumball.
- **Gumball Tray:** Area where dispensed gumballs land.

- **Base:** Red plastic base that houses the coin mechanism and coin retrieval opening.
- **Coin Retrieval Cap:** Removable cap on the bottom of the base to access saved coins.

4. Setup

1. **Unpack:** Carefully remove the gumball bank and included gumballs from the packaging.
2. **Open Top Cover:** Twist and remove the red top cover from the clear gumball globe.
3. **Fill with Gumballs:** Pour the included Dubble Bubble gumballs (or other suitable small candies) into the opening. The machine can hold over 50 gumballs.
4. **Replace Top Cover:** Securely twist the red top cover back onto the gumball globe.



Figure 2: Visual instructions for filling and using the gumball bank.

5. Operating Instructions

1. **Insert Coin:** Place a coin (e.g., quarter) into the coin slot located on the front of the machine.
2. **Turn Knob:** Turn the dispensing knob clockwise until a gumball is released into the gumball tray.
3. **Retrieve Gumball:** Collect your gumball from the tray.

The gumball bank is designed to accept various coin sizes, typically quarters, for dispensing. The inserted coin will drop into the internal coin bank.

Your browser does not support the video tag.

Video 1: Product Summary Video demonstrating the gumball bank's features and operation.

6. Coin Bank Feature

To retrieve saved coins, locate the coin retrieval cap on the bottom of the red base. Twist or slide this cap to open the compartment and access your coins. Replace the cap securely after retrieving coins.

7. Care and Maintenance

- **Cleaning:** Wipe the exterior of the gumball bank with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Gumball Globe:** The clear plastic globe can be removed and washed thoroughly with mild soap and water before initial use and when refilling. Ensure it is completely dry before adding new gumballs.
- **Storage:** Store in a cool, dry place away from direct sunlight to maintain gumball freshness.

8. Troubleshooting

- **Gumball Not Dispensing:**
  - Ensure a coin has been properly inserted into the slot.
  - Check if the dispensing knob has been turned fully clockwise.
  - Verify that the gumball globe is not empty.
  - Confirm that the gumballs are the correct size for the mechanism.
- **Coin Mechanism Jammed:**
  - Ensure only one coin is inserted at a time.
  - Avoid forcing the knob if resistance is met.

9. Specifications

- **Brand:** Schylling
- **Model Number:** GBB (Manufacturer Part Number: YN-655)
- **Height:** Approximately 8.5 inches (8.75"L x 5.38"W x 5.13"H)
- **Material:** Durable Plastic
- **Color:** Red
- **Included:** 1 Gumball Bank, 45 Dubble Bubble Gumballs (over 50 count mentioned in description)
- **Recommended Age:** 3 years and up



Figure 3: Gumball Bank with approximate dimensions.

10. Warranty and Support

For any questions, concerns, or support regarding your Schylling Classic Retro Gumball Coin Bank, please refer to the manufacturer's contact information provided on the product packaging or visit the official Schylling website. Keep your purchase receipt for any warranty claims.

© 2026 Schylling. All rights reserved.
Dubble Bubble is a registered trademark.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B002C4L4BG

More documents and user manuals: **https://manuals.plus/**