

[Manuals.plus](#) /

› [Pfister](#) /

› Pfister 940-702A Savannah Series Decorative Hub User Manual

Pfister 940702A

Pfister 940-702A Savannah Series Decorative Hub User Manual

Model: 940702A | Brand: Pfister

INTRODUCTION

This manual provides essential information for the installation, operation, maintenance, and troubleshooting of your Pfister 940-702A Savannah Series Decorative Hub. This genuine Pfister part features all-metal construction and a polished chrome finish, designed for compatibility with Pfister's 36, 43, 49, and 801 series faucets. Please read these instructions carefully before proceeding with installation or use.



Image: The Pfister 940-702A Savannah Series Decorative Hub, showcasing its polished chrome finish.

SETUP & INSTALLATION

The Pfister 940-702A Decorative Hub is designed for straightforward installation. Ensure you have the necessary tools and follow these general steps. For specific faucet model instructions, refer to your faucet's original manual.

1. **Preparation:** Before beginning, turn off the water supply to the faucet at the shut-off valves under the sink. Clear the work area and ensure you have a clean cloth and any required tools (e.g., adjustable wrench, screwdriver).
2. **Remove Existing Part (if applicable):** If replacing an old decorative hub, carefully remove it. This may involve unscrewing a retaining nut or collar.
3. **Position the New Hub:** Place the Pfister 940-702A Decorative Hub onto the faucet body. Ensure it aligns correctly with any grooves or connection points.
4. **Secure the Hub:** Hand-tighten any retaining nuts or screws to secure the hub in place. Use a wrench for a final snug tightening, but avoid over-tightening, which can damage the finish or threads.
5. **Test for Leaks:** Turn the water supply back on slowly. Check for any leaks around the newly installed hub. If leaks occur, gently tighten the connections further.



Image: A detailed view of the Pfister 940-702A Decorative Hub, showing its construction and finish, useful for installation reference.

OPERATION

The Pfister 940-702A Decorative Hub is a static component of your faucet assembly. Once correctly installed, it requires no specific operational steps. Its primary function is to provide a finished aesthetic and structural support for the faucet's internal components. Operate your faucet as usual according to its specific model instructions.

MAINTENANCE

To maintain the polished chrome finish and ensure the longevity of your decorative hub, follow these guidelines:

- **Regular Cleaning:** Clean the surface regularly with a soft, damp cloth.
- **Mild Soap:** For more thorough cleaning, use a mild soap and water solution. Rinse thoroughly with clean water and dry immediately with a soft cloth to prevent water spots.
- **Avoid Abrasives:** Do not use abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the chrome

- finish.
- **Spot Defense:** Pfister products often feature Spot Defense finishes. While this hub has a standard chrome finish, general care practices help maintain its appearance.



Image: An illustration demonstrating the effectiveness of a Spot Defense finish in preventing water spots and fingerprints, highlighting the importance of proper cleaning for all finishes.

TROUBLESHOOTING

The decorative hub is a simple component, and issues directly related to it are rare. Most problems will stem from the faucet assembly itself. However, if you encounter issues that seem related to the hub, consider the following:

- **Loose Hub:** If the decorative hub feels loose, gently re-tighten any visible retaining nuts or screws. Avoid excessive force.
- **Finish Discoloration/Damage:** Ensure you are using only mild, non-abrasive cleaners. Harsh chemicals can cause permanent damage to the chrome finish. Refer to the Maintenance section for proper cleaning instructions.
- **Water Leaks Around Hub:** While the hub itself does not seal water, a loose hub might indicate an underlying issue with the faucet's internal seals or connections. Recheck the installation steps and ensure all faucet components are properly seated and tightened. If leaks persist, consult a professional plumber or Pfister customer support.

SPECIFICATIONS

Manufacturer	Pfister
Part Number	940-702A
Item Model Number	940702A
Item Weight	3.52 ounces
Product Dimensions	2 x 2 x 2 inches
Color	Polished Chrome
Finish	Polished Chrome
Material	Metal
Shape	Round
Installation Method	Countertop (as part of faucet assembly)

Item Package Quantity	1
Number Of Holes	1 (for faucet stem)
Usage	Inside
Compatible Series	Pfister 36, 43, 49, and 801 series faucets

WARRANTY INFORMATION

The Pfister 940-702A Savannah Series Decorative Hub is backed by Pfister's**Limited Lifetime Warranty**. This warranty covers the finish and function of the product for as long as you own your home. For detailed terms and conditions, please refer to the official Pfister warranty documentation or contact customer support.



Image: The Pfister Limited Lifetime Warranty badge, signifying commitment to product quality and durability.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact Pfister customer service. You can find contact information and additional resources on the official Pfister website.
Online Resources: Visit the [Pfister Store on Amazon](#) for product information and support.

ABOUT PFISTER

Pfister has been a leader in plumbing fixtures for over 100 years, known for innovation and quality. The company is committed to designing fixtures that meet the needs of everyday life.

Your browser does not support the video tag.

Video: "Pfister Design Made Right" - This video highlights Pfister’s design philosophy and commitment to quality in their plumbing fixtures.

Your browser does not support the video tag.

Video: "Why Pfister Brand Video" - This video provides an overview of the Pfister brand, emphasizing their heritage and dedication to innovative plumbing solutions.



