



[Manuals.plus](#) /

› [Moen](#) /

› Moen 136103C Spray Head and Hose Assembly User Manual

Moen 136103C

Moen 136103C Spray Head and Hose Assembly User Manual

Model: 136103C

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Moen 136103C Spray Head and Hose Assembly. Please read these instructions carefully before beginning installation or use to ensure proper function and longevity of the product.

PRODUCT OVERVIEW

The Moen 136103C is a genuine replacement spray head and hose assembly designed for Moen faucets. It features a polished chrome finish and a Hydrolock connection for secure installation.

Key Features:

- **Chrome Finish:** Highly reflective, mirror-like appearance.
- **Replacement Part:** Ideal for repairing existing plumbing fixtures.
- **Authentic Moen:** Ensures compatibility and quality.
- **Hassle-Free Installation:** Designed for straightforward setup.
- **Hydrolock Connection:** Provides a secure and leak-free connection.



Figure 1: Moen 136103C Spray Head and Hose Assembly. This image shows the complete spray head and hose unit, highlighting its chrome finish and design.

SETUP AND INSTALLATION

Before you begin, ensure you have the necessary tools and that the water supply to your faucet is turned off. Refer to your faucet's original installation guide for specific instructions on removing the old spray head and hose.

Tools Required:

- Adjustable wrench
- Towel or bucket (to catch drips)

Installation Steps:

1. **Prepare the Area:** Turn off the hot and cold water supply valves located under the sink. Open the faucet handle to relieve any remaining water pressure.

2. **Remove Old Assembly:** Disconnect the old spray head and hose assembly from the faucet. This typically involves unscrewing the spray head from the hose and then disconnecting the hose from the main water line or faucet body. Note the type of connection for reference.
3. **Connect New Hose:** Attach the new Moen 136103C hose to the faucet's water supply connection. Ensure the Hydrolock connection clicks securely into place. Hand-tighten first, then use an adjustable wrench for a quarter turn if necessary, being careful not to overtighten.
4. **Attach Spray Head:** Screw the new spray head onto the end of the hose. Hand-tighten until snug.
5. **Check for Leaks:** Slowly turn on the hot and cold water supply valves. Check all connections for leaks. If leaks occur, gently tighten the connections.
6. **Test Functionality:** Turn on the faucet and test the spray head's functionality, including spray patterns and retraction.

***Important:** If you are unsure about any step, consult a qualified plumber.*

OPERATING INSTRUCTIONS

The Moen 136103C Spray Head and Hose Assembly is designed for simple operation.

- **Activating Water Flow:** Use your faucet's handle to turn the water on and off, and to adjust temperature and flow rate.
- **Spray Function:** The spray head typically features a button or switch to toggle between stream and spray modes. Press this control to select your desired water output.
- **Retraction:** After use, the hose is designed to retract smoothly back into the faucet body. Ensure there are no obstructions under the sink that could hinder its movement.

MAINTENANCE

Regular maintenance will help preserve the finish and functionality of your Moen spray head and hose assembly.

Cleaning the Finish:

- Clean the chrome finish with a soft, damp cloth and mild soap.
- Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots.

Cleaning the Spray Nozzles:

- Over time, mineral deposits can accumulate in the spray nozzles, affecting water flow.
- Gently rub the rubber nozzles with your finger or a soft brush to dislodge any mineral buildup.
- For stubborn deposits, a solution of equal parts white vinegar and water can be applied to the nozzles for a few minutes before scrubbing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Flow	Mineral buildup in spray nozzles.	Clean spray nozzles as described in the Maintenance section.

Problem	Possible Cause	Solution
Leaking at Connections	Loose connection or damaged O-ring.	Ensure all connections are tight. Check O-rings for damage and replace if necessary.
Hose Not Retracting	Obstruction under the sink or weight not properly positioned.	Clear any obstructions. Ensure the hose weight is correctly installed and positioned to allow smooth retraction.
Spray Mode Not Working	Debris in the spray head mechanism.	Remove the spray head and inspect for debris. Rinse thoroughly.

If problems persist after attempting these solutions, contact Moen customer support or a qualified plumber.

SPECIFICATIONS

- **Brand:** Moen
- **Model Number:** 136103C
- **Finish Type:** Chrome
- **Material:** Chrome
- **Included Components:** Replacement Parts or Service Kit (Spray Head and Hose Assembly)
- **Item Weight:** 8.64 ounces
- **Item Length:** 60 Inches (Hose)
- **UPC:** 026508172384

WARRANTY AND SUPPORT

This Moen product is backed by Moen's One Year Limited Warranty. For detailed warranty information, claims, or technical support, please visit the official Moen website or contact Moen customer service directly.

Moen Customer Service: Refer to your product packaging or the official Moen website for the most current contact information.

ABOUT MOEN

Moen is a leading brand in plumbing fixtures, known for its commitment to quality, innovation, and design. They offer a wide range of products for kitchens and bathrooms, focusing on enhancing the water experience.



Video 1: Moen Brand Video. This video provides an overview of the Moen brand philosophy and its connection to water.



Video 2: Must Be A Moen - Brand Story. This video showcases various Moen products in everyday scenarios, emphasizing their design and utility.