

[Manuals.plus](#) /

› [Case Logic](#) /

› Case Logic SLRC-206 SLR Camera and 15.4-Inch Laptop Backpack User Manual

Case Logic SLRC-206BLACK

Case Logic SLRC-206 SLR Camera and 15.4-Inch Laptop Backpack User Manual

Model: SLRC-206BLACK

INTRODUCTION

The Case Logic SLRC-206 is a robust and versatile backpack designed for photographers and tech enthusiasts. It provides secure storage and easy access for your SLR camera, lenses, accessories, and a laptop up to 15.4 inches. Its thoughtful design ensures protection and comfort for your gear on the go.

Key Features

- Accommodates SLR camera body with attached lens, a DJI Mavic Pro (or similar drones), and various accessories.
- Features a patent-pending hammock system to suspend your SLR, offering superior impact protection.
- Equipped with a water-proof EVA base for stability and protection against elements.
- Memory foam on the interior lid protects delicate LCD screens.
- Dedicated computer compartment compatible with 16" laptops and 17" MacBook Pro models.

SETUP AND CONFIGURATION

Before using your SLRC-206 backpack, familiarize yourself with its compartments and adjustable features to optimize storage for your specific equipment.

Main Compartment Organization

The main compartment features adjustable, padded dividers that allow you to customize the layout to fit your camera body, lenses, and other photography equipment securely. The bright yellow interior helps in easily locating items.



Image: Customizable interior with padded dividers for camera and lenses.

SLR Suspension System

The patent-pending hammock system is designed to suspend your SLR camera above the bottom of the case, providing enhanced impact protection. Place your camera body with an attached lens into this suspended section for optimal security.



Image: Detail of the SLR Suspension System.

Laptop Compartment

A dedicated padded compartment at the back of the backpack is designed to securely hold laptops up to 15.4 inches, including 16" laptops and 17" MacBook Pro models. Ensure the laptop is fully inserted and the zipper is closed completely to prevent accidental slippage.



Image: Laptop compartment in use.

OPERATING THE BACKPACK

The SLRC-206 backpack is designed for ease of use and secure transport of your valuable equipment.

Carrying and Comfort

The backpack features padded shoulder straps and an air mesh back panel for breathability and comfort during extended wear. Adjust the straps to ensure a snug and balanced fit.



Image: Padded back panel and shoulder straps.

Accessory Storage

Multiple pockets and compartments are available for organizing smaller accessories such as cables, batteries, memory cards, and personal items. The front and side pockets offer quick access to frequently used items.



Image: Organized side pocket for accessories.

Tripod Attachment

The backpack includes external straps designed to secure a tripod or monopod to the side. Ensure the tripod is balanced and securely fastened before carrying.



Image: Tripod attached to the side of the backpack.

MAINTENANCE AND CARE

Proper care will extend the life and maintain the appearance of your Case Logic SLRC-206 backpack.

- **Cleaning:** For general cleaning, wipe the exterior nylon fabric with a damp cloth and mild soap. Avoid harsh detergents or abrasive cleaners.
- **EVA Base:** The water-proof EVA base can be easily wiped clean with a damp cloth.
- **Drying:** Allow the backpack to air dry completely before storing, especially if it has been exposed to moisture. Do not machine wash or tumble dry.
- **Storage:** Store the backpack in a cool, dry place away from direct sunlight when not in use.
- **Zippers:** Periodically check zippers for smooth operation. If they become stiff, a small amount of zipper lubricant or wax can be applied.

TROUBLESHOOTING AND TIPS

This section provides guidance for common observations and tips for optimal use.

- **Zipper Security:** To prevent accidental unzipping, especially of the laptop compartment, ensure zippers are fully closed. Consider zipping both pulls to one side (e.g., the bottom) rather than leaving them partially open at the top.
- **Screen Protection:** When placing your camera into the suspension system, ensure the camera's LCD screen is protected, as it may be in proximity to the zipper. A screen protector is recommended.
- **Tripod Balance:** When attaching a tripod, distribute its weight as evenly as possible to maintain backpack balance.
- **Capacity Management:** While the backpack is spacious, avoid overpacking to prevent strain on zippers and seams, and to maintain comfort.

SPECIFICATIONS

Product Dimensions	10.63 x 5.51 x 12.6 inches
Item Weight	2.69 pounds (1220 Grams)
Model Number	SLRC-206BLACK
Material	Nylon (exterior), EVA (base)
Laptop Compatibility	Up to 15.4-inch laptops, 16" laptops, 17" MacBook Pro (Fits devices 10.4 x 4.7 x 15.4 inches)
Capacity Total	20 Liters
Manufacturer	CASE LOGIC
Date First Available	June 17, 2003



Image: Product dimensions diagram.

WARRANTY AND SUPPORT

Information regarding product warranty and customer support is typically provided with the product packaging or available on the manufacturer's official website. Please refer to the official Case Logic website for the most current warranty terms and support contact information.

Note: The provided product information does not include specific warranty details.

ADDITIONAL PRODUCT VIEWS



Side View



Front View



Camera Compartment

OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were provided in the available data for this manual.

© 2023 Case Logic. All rights reserved.
For more information, visit www.casellogic.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question