Dornbracht 33880888-000010

Dornbracht Tara Classic Single Hole Single Lever Kit Instruction Manual

Model: 33880888-000010

Introduction

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your Dornbracht Tara Classic Single Hole Single Lever Kit. Please read this manual thoroughly before installation and use to ensure proper function and longevity of your product.
For additional information or support, please refer to the contact details provided in the Warranty and Support section.

Safety Information

Important: Always turn off the main water supply before beginning any installation or maintenance work. Ensure all connections are secure to prevent leaks. If you are unsure about any step, consult a qualified plumber.

- Wear appropriate personal protective equipment (PPE) during installation.
- Do not overtighten connections, as this may damage components.
- Keep small parts away from children.

Package Contents

Verify that all components are present before beginning installation:

- Single-lever mixer body
- Mounting hardware (gasket, washer, nut)
- Flexible connection hoses (hot and cold)
- Installation instructions (this manual)



Image: Main components of the Dornbracht Tara Classic Single Hole Single Lever Kit. This image shows the faucet body, handle, and typical connection points.

Setup and Installation

Tools Required:

- Adjustable wrench
- Phillips head screwdriver
- Basin wrench (optional, for tight spaces)
- Sealant tape (Teflon tape)
- Flashlight

Installation Steps:

1. **Prepare the Installation Area:** Turn off the main water supply. Clear the area under the sink. Remove any existing faucet. Clean the sink surface around the faucet hole.
2. **Install the Faucet Body:** Place the rubber gasket onto the base of the faucet. Insert the faucet body through the single hole in the sink or countertop.
3. **Secure the Faucet:** From underneath the sink, slide the metal washer and then the mounting nut onto the threaded shank of the faucet. Hand-tighten the nut, then use a basin wrench to fully secure it. Do not overtighten.
4. **Connect Water Supply Lines:** Attach the flexible hot and cold water supply hoses to the corresponding inlets on the faucet body. Ensure the hot water line connects to the hot inlet (usually marked with red or 'H') and the cold water line to the cold inlet (blue or 'C'). Use sealant tape on the threads of the supply stops before connecting the hoses.
5. **Connect to Water Supply:** Connect the other ends of the flexible hoses to the hot and cold water supply valves under the sink. Tighten securely with an adjustable wrench.
6. **Check for Leaks:** Slowly turn on the main water supply. Check all connections for leaks. If leaks are present, tighten the connections slightly until they stop.

7. **Flush the Faucet:** Remove the aerator from the faucet spout. Turn on both hot and cold water to full flow for several minutes to flush out any debris from the lines. Turn off the water, reattach the aerator.

Operating Instructions

The Dornbracht Tara Classic Single Hole Single Lever Kit features a single lever for controlling both water flow and temperature.

- **Water Flow:** Lift the lever upwards to increase water flow. Push it downwards to decrease or turn off the water.
- **Water Temperature:** Move the lever to the left for hot water and to the right for cold water. The temperature will adjust gradually as the lever is moved between these positions.

Familiarize yourself with the lever's movement to achieve the desired flow and temperature settings.

Maintenance and Care

Regular cleaning and maintenance will ensure the longevity and appearance of your Dornbracht faucet.

- **Cleaning the Finish:** Clean the faucet regularly with a soft cloth and mild soap and water. Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the polished finish. Rinse thoroughly and dry with a soft cloth.
- **Aerator Cleaning:** If water flow becomes restricted or uneven, the aerator may be clogged. Unscrew the aerator from the spout, clean any debris or mineral deposits, and rinse thoroughly. Reattach the aerator.
- **Leak Checks:** Periodically check under the sink for any signs of leaks around the connections. Address any leaks promptly to prevent water damage.

Troubleshooting

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed supply valve; debris in water lines.	Clean or replace aerator. Fully open supply valves. Flush water lines.
Leaking at Faucet Base	Loose mounting nut; damaged gasket.	Tighten mounting nut. Inspect and replace gasket if damaged.
Leaking from Spout	Worn cartridge.	Contact customer support for a replacement cartridge.
Inconsistent Water Temperature	Issues with water heater; faulty cartridge.	Check water heater settings. Contact customer support for cartridge inspection.

If the problem persists after attempting these solutions, please contact Dornbracht customer support.

Specifications

- **Model:** 33880888-000010
- **Brand:** Dornbracht
- **Type:** Single Hole Single Lever Kitchen Mixer
- **Mounting Type:** Deck Mount
- **Finish:** Polished

- **Number of Handles:** 1
- **Hole Count:** 1
- **Included Components:** Mixer

Warranty and Support

Dornbracht products are manufactured to high-quality standards and are backed by a manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Dornbracht website.
For technical assistance, replacement parts, or warranty claims, please contact Dornbracht customer support:

- **Website:** www.dornbracht.com
- **Customer Service:** Refer to the website for regional contact information.

When contacting support, please have your model number (33880888-000010) and date of purchase available.

© 2024 Dornbracht. All rights reserved.
This manual is subject to change without notice.